

Step 2: Association

Apply Sample

Analyte : Analyte-1(0.4 nM)

Buffer : PBS

then Press "Continue"