


● Instrument Status:

Current Stage Position (mm) X: 0.000 Y: 0.000 X:

Slide 131 [TMA569-MD]



Current stage position: Target stage position:

Target Point: X: Y:

Move Stage to Target

Target Selection:

FOVs

Import FOVs

| Notes | Name | FOV Center |
|-------|------|------------|
|-------|------|------------|


Estimated Run Time (hh:mm:ss):

on / Target Estimate

Contact support

Exchange Sample

Please verify that the slide is in the correct position. Assign a slide id to continue. If the slide is improperly positioned, press cancel to open the instrument door and reposition the slide.



Select a Project:

Mouse panel [9]

Select a Slide:

Slide 134 [47232LN/Mix-2]

Continue

Cancel