JoVE: Science Education Dye Sensitized Solar Cells --Manuscript Draft--

Manuscript Number:	10328
Full Title:	Dye Sensitized Solar Cells
Article Type:	Manuscript
Section/Category:	Manuscript Submission
Corresponding Author:	Caroline Saouma
	UNITED STATES
Corresponding Author Secondary Information:	
Corresponding Author's Institution:	
Corresponding Author's Secondary Institution:	
First Author:	Caroline Saouma
First Author Secondary Information:	
Order of Authors:	Caroline Saouma
Order of Authors Secondary Information:	

PI Name: Tamara Powers, Texas A&M

Science Education Title: Dye Sensitized Solar Cells

Overview

Today's modern world requires the use of a large amount of energy. While we harness energy from fossil fuels such as coal and oil, these sources are nonrenewable and thus the supply is limited. To maintain our global lifestyle, we must extract energy from renewable sources. The most promising renewable source, in terms of abundance, is the sun, which provides us with more than enough solar energy to fully fuel our planet many times over.

So how do we extract energy from the sun? Nature was the first to figure it out. You may recall from biology that photosynthesis is the process whereby plants convert water and carbon dioxide to carbohydrates and oxygen. This process occurs in the leaves of plants, and relies on the chlorophyll pigments that color the leaves green. It is these colored molecules that absorb the energy from sunlight, and this absorbed energy which drives the chemical reactions.

In 1839, Edmond Becquerel, then a 19-year old French physicist experimenting in his father's lab, created the first photovoltaic cell. He illuminated an acidic solution of silver chloride that was connected to platinum electrodes which generated a voltage and current.¹ Many discoveries and advances were made in the late 19th and first half the 20th century, and it was only in 1954 that the first practical solar cell was built by Bell Laboratories. Starting in the 1950s, solar cells were used to power satellites in space.²

Solar cells are electrical devices that utilize light to create a current. In this video, you will prepare and test one such type of cell, the dye-sensitized solar cell (DSSC). First invented at UC Berkeley by Brian O'Regan and Michael Grätzel, Grätzel pursued this work at the École Polytechnique Fédérale de Lausanne in Switzerland, culminating in the first highly efficient DSSC in 1991.³ These solar cells, like plants, use a dye to help harness energy from the sun.

Principles

Band theory

When *two* atoms come together to form molecular orbitals, *two* orbitals are formed, one with a bonding and the other with an antibonding symmetry.⁴ These are separated by a certain amount of energy. When *n* atoms come together to form molecular orbitals, such as in a solid, *n* molecular orbitals form. When *n* is large, the number of orbitals that are closely spaced in energy is likewise large. The result is a *band* of orbitals of similar energy (**Figure 1**). Electrons from the atoms reside in these bands. The *valance band* is the highest energy band that is populated with electrons. It is akin to the HOMO of molecules. The *conduction band* is the lowest band that is not populated by electrons, and is akin to the LUMO of molecules. The band gap is the energy difference between these two bands.

When the band gap is large, the solid material is an insulator: electrons cannot freely flow within the material (**Figure 1**). By contrast, conductors are those in which the valance-

Commented [TP1]: Band theory is something that is covered in many inorganic chemistry classes – I think that this module definitely has a place in this collection.

conduction band gap is blurred. In a conductor, such as a metal, applying a voltage raises some of the electrons in the valence band to the conduction band. These excited electrons are free to move. The electrons leave behind positive holes, which are also free to move. In reality, the holes do not move, but rather electrons move to fill the positive holes. In conductors, as the temperature increases, molecular vibrations increase, thereby obstructing the flow of electrons and decreasing the conductivity.

Semi-conductors are materials which act as insulators at 0 Kelvin, but become conductors as the temperature increases (**Figure 1**). This is because the band gap—the energy between the valence and conduction bands—is small, so thermal energy is sufficient enough to excite electrons into the conduction band. Typical intrinsic semiconductors include silicon and germanium.

Photovoltaic effect

When light hits a semi-conductor, it can excite an electron from the valence band to the conduction band. This electron can then recombine with the hole it left behind, resulting in no net flow of electrons. Or, it can move through the semi-conductor, around a circuit, and recombine with a hole at the other end of the circuit. This flow of electrons created from exposure to sunlight is termed the *photovoltaic effect*. This latter scenario is desired to generate electricity, and thus systems must be designed to favor this over recombination.

One way to favor this is to design cells with a p-n junction. This is just what it sounds like- a junction between an n- and p-doped semiconductor. These are semi-conductors whereby some of the atoms have been replaces be neighboring atoms on the periodic table. In an n-doped semi-conductor, these are replaced by atoms that have more electrons, and in p-doped semi-conductors, these are replaced by atoms that have fewer electrons. "Traditional" silicon-based solar cells make use of this approach.

However, an emerging type of solar cells are dye-sensitized solar cells, often referred to as the Grätzel cell.⁵ These are promising in that they are semi-translucent, and their cost is significantly less. These solar cells still make use of semi-conductors, but it is a dye that is used to absorb the light from the sun.

Components of a Dye-Sensitized Solar Cell (DSSC)

There are many components to a dye-sensitized solar cell, which is shown in **Figure 2**.

Dye. To promote the photovoltaic effect, DSSC make use of dyes. The dye molecule absorbs light, promoting an electron from a bonding orbital to an anti-bonding orbital. This excited electron can then drop back down to the bonding orbital, resulting in no flow of electrons. Or, it can be injected into a semi-conductor, the productive pathway of DSSCs. This leaves behind a hole, which must be filled to complete the circuit. For the productive pathway, the energy of the excited-state electron in the dye must be greater than the conduction band of the semi-conductor. The dye should also absorb much of the solar spectrum, to improve efficiency of the cell. Typical dyes are Ru-based, and hence limits DSSCs, as this metal is not very economical.

In this experiment, we will be utilizing a natural dye (anthocyanins) found in some berries, such as blackberries and raspberries. The structure of the anthocyanin dye must feature several =0 or -OH groups, which allow for the dye to bind to the $Ti^{IV}O_2$ surface (**Figure 3**).

Semi-conductor. The excited electron then flows to the conduction band of the semi-conductor. The semi-conductor we will be using in this experiment is TiO₂.

Anode. The electron flows from the semi-conductor to the anode, which in this case, is SnO_2 -coated glass. The SnO_2 allows for a conductive surface to be on the glass, which otherwise would be an insulator.

 $\it Cathode$. After passing through a load, the electron comes to the cathode, which is likewise covered in SnO₂. The cathode is additionally covered with a catalyst, in this case, graphite, which helps promote the redox reaction of the mediator.

Mediator. The electron passes from the cathode to I_3 , reducing it to I. This reduced molecule can then donate an electron to the hole left behind in the dye molecule, completing the circuit. This process regenerates I_3 . The difference between the I_3 -/I- cell potential and the Fermi level corresponds to the open circuit potential of the solar cell, or the maximum voltage that can be produced with the cell.

In this video, you will prepare a dye-sensitized solar cell and evaluate its performance.

Procedure⁶

1. Preparation of TiO₂ Paste

- **1.1.** Mass out 6 g of colloidal TiO₂ powder, and place it in a mortar.
- **1.2.** Carefully add 2-3 mL of vinegar to the TiO_2 , and begin grinding the suspension with the pestle until a uniform paste is obtained. The grinding serves to break up aggregated clumps in the powder.
- **1.3.** Keep adding vinegar, in ~ 1 mL increments while grinding, up to ~ 9 mL total volume. Prior to each addition, the consistency of the paste should be uniform and free of lumps. The final paste should be thick, but not so thick that it cannot be squeezed out of a dropper bottle.
- $\textbf{1.4.} \ \, \text{Add} \ 1 \ \text{drop of dish soap to} \ 1 \ \text{mL of distilled water, gently mix}.$
- **1.5.** Add the dish soap solution to the TiO_2 suspension and gently mix, being careful not to produce bubbles.
- **1.6.** Allow the suspension to equilibrate for 15 min. The dish soap serves as a surfactant, helping make the suspension more readily spread out into a uniform film on the glass.

2. Deposition of TiO2 on Glass

2.1. Clean two conductive glass slides. Soak a kimwipe with ethanol and use it to wipe clean two conductive glass slides. Place the clean slides on a fresh kimwipe.

- **2.2.** Determine which side of the glass is conductive. Using a multimeter set to ohms, touch both leads to one side of the glass. If a reading between 10 and 30 ohms is observed, it is the conductive side. A reading of 0 indicates the non-conductive side.
- **2.3.** *Mask the slide.* Place one glass slide with its conductive side up and the other with its conductive side down. Carefully keeping the slides touching, tape the glass slides to the bench top. Place Scotch tape on three of the four sides of the slides, making sure that ~5-8 mm of the slide is covered by tape on each of the three sides (**Figure 4**). Press the tape firmly, to ensure that there are no air bubbles.
- **2.4.** *Apply the TiO*² *paste.* Using a glass rod, apply a thin line of paste across the masked top edge of the slide. Use the glass rod to carefully roll the paste down the length of the slide, and back up. Repeat this motion 2-3x without lifting the rod, or until a uniform film is obtained.
 - **2.4.1.** If the film is not uniform, simply wipe it off with a kimwipe, clean the glass with ethanol, and once dry, try again.
- **2.5.** Allow the film to dry a little, then carefully remove the tape from the glass. *You want the slide with the TiO_2 film on the conductive side.* The other slide can be cleaned and used later.
- **2.6.** Anneal the TiO₂ film. Carefully place the slide (TiO₂ side up) on a hot plate that is set to 450 °C. Watch as the TiO₂ darkens to a purple/brown color, and regains its white color. At this point, turn the hotplate off and allow the film to slowly cool. If the slide is cooled to quickly, it may crack or shatter.
- **2.7.** With a ruler, measure the surface area that is covered with the film, and note this value.

3. Stain the TiO₂ Film with Dye

- **3.1.** Place a few blackberries, raspberries, or cherries in a mortar and crush them with a pestle.
- **3.2.** Filter the solution through a coffee filter and into a Petri dish. You may need to add a few mL of water to the juice.
- **3.3.** Place the cooled TiO_2 film, face side down in the Petri dish. Be careful to not scratch off any TiO_2 . Allow the dye to be adsorbed onto the film. This may take several minutes.
- **3.4.** Once the film is fully coated (it should be dark red or purple and there are no white spots), lift the slide up with tongs (be careful to only tough the glass and not the film), and rinse the slide with water, then ethanol. Blot the film dry with a kimwipe, and use immediately.
 - **3.4.1.** If not used immediately, then store the film in a Petri dish that contains acetic acid at pH 3-5, and cover the dish with the lid and wrap in foil.

4. Prepare the Counter Electrode

- **4.1.** Using another conductive glass slide, follow steps 2.1-2.2.
- **4.2.** Apply the carbon catalyst on the conductive side. Using tweezers, hold the slide, conductive side down, over the tip of a Bunsen burner. Move the slide around so that the soot collects on the entire surface, but no longer than 30 s. Let the slide cool, and wipe the soot along one side of the slide with a cotton swab.

4.2.1. Alternatively, using an HB pencil, cover the entire conductive surface with graphite. This gives a more robust electrode, but one that performs less well.

5. Assemble the Solar Cell

- **5.1.** Dry the stained film. This is done by rinsing with ethanol and placing it on a kimwipe. Gently blot the film with a second kimwipe. The film must be dry as to not impact the electrolyte solution.
- **5.2.** With the electrode film side up, gently place the carbon coated electrode on top (carbon face down). Be sure to offset the slides so that the exposed sides of both electrodes can be clipped to wires. Place two binder clips on sides adjacent to the offset glass.
- **5.3.** Place a few drops of the electrolyte solution along one edge of the slides, and carefully open/close each side of the cell by alternately opening/closing the binder clips. Be sure that all of the stained area is in contact with the electrolyte solution, and repeat step 5.2 if necessary.
- **5.4.** Wipe off the excess electrolyte from the exposed areas using kimwipes and ethanol.
- **5.5.** Fasten alligator clips to the two exposed sides of the solar cell.

6. Measuring Cell Performance

Ideally, these measurements are to be done outside. However, if the weather is not permitting, they can be done inside using a halogen lamp. All measurements should be done with no movement of the cell so that they are done under identical conditions.

- **6.1.** Be sure to orient the cell so that the TiO₂ film is facing up towards the sun, and place a polycarbonate cover over the cell. This protects the cell from UV damage.
- **6.2.** Connect the negative electrode (TiO₂-coated glass) to the negative wire of the multimeter, and the positive electrode (C) to the positive wire of the multimeter. (**Figure 5**)
- **6.3.** Set the multimeter to volts, and measure the voltage. This is the open circuit potential (maximum voltage at zero current). Cover the cell with your hand to ensure that the voltage decreases.
- **6.4.** Set the multimeter to milliamperes, and measure the maximum current. This is the short circuit current (maximum current at zero voltage). Cover the cell with your hand to ensure that the current decreases.
- **6.5.** Record a full current-voltage curve using a 500-ohm potentiometer as a variable load.
 - 6.5.1. Determine which lead on the potentiometer is the central tap. This lead allows for the resistance to be varied. To do this, connect the multimeter (set to ohms) to two of the leads on the potentiometer, and vary the resistance on the potentiometer. Note if the resistance changes. Repeat this with the other two combinations of leads. You should see changes in resistance in two of the 3 combinations. The lead that was used in both combinations that gave changes is the central tap, and the other two are functionally identical.
 - 6.5.2. Assemble the circuit as shown in **Figure 5** (right).
 - 6.5.3. Set the potentiometer to full (or zero) resistance, and note the current and voltage.

6.5.4. Change the resistance on the potentiometer in small increments and note the current and voltage so that you have several points and span the entire range of the potentiometer. Be sure to not move the cell during these measurements. Once the current starts to change, be sure to collect many data points; fewer data points may be obtained when it is constant.

Representative Results

For each data point collected in 6.5.3-6.5.4, calculate the current density (mA/cm²) and the power density (mW/cm²). To calculate the current density, divide the current by the surface area of the film that was determined in step 2.7. To calculate the power density multiply the voltage by current density. Plot the current (mA) versus voltage (mV) for the data you collected in steps 6.3, 6.4, and 6.5.3-6.5.4. Plot the current density versus volts for all your data, as you did in 7.2. On the plot of 7.3, label the maximum power point (look at your data from 7.1.2). This should be near the "knee" of your curve. Determine the sunlight to electrical energy conversion efficiency. This is done by dividing the maximum power (mW/cm²) by the incoming solar power, taken to be 800-1,000 W/m²), and multiplying by 100%.

The analysis of data and preparation of I-V curves is standard in the solar cell literature, as a means to compare the performance of cells. The open-circuit voltage measured should be between 0.3 and 0.5 V, and a short circuit potential of 1-2 mA/cm 2 should be obtained.

Summary

This video showed the preparation and analysis of a simple dye-sensitized solar cell.

Applications

Solar cells are becoming more common, and there is much research being done to advance their performances. Traditional solar cells that are based on silicon semi-conductors are used to make solar panels that are used in space and on earth. The Denver International Airport makes use of Colorado's sunny climate and has four solar arrays which provides 6% of the airport's energy needs.

DSSCs operate at efficiencies up to 15%,7 compared to 14—17% efficiency for traditional low-cost commercial silicon panels. While operating efficiencies of DSSCs are competitive, the high cost of materials (such as the Ru dye) is problematic for large-scale applications. Possibly the greatest disadvantage of DSSCs is the use of a liquid electrolyte that is sensitive to temperature changes. The liquid electrolyte can freeze at low temperatures, thereby halting power production and/or resulting in structural damage to the solar panel. At high temperatures the liquid electrolyte expands, which makes sealing the panels challenging.

Legend

Commented [TP2]: I would like to provide actual data (collect data and generate the graphs here)

Figure 1. Band diagram for an insulator, semi-conductor, and conductor. Shaded bands are filled with electrons, while white bands are empty. Discrete electrons are indicated by a red sphere, while discrete holes are indicated by a white sphere.

Figure 2. Schematic of a DSSC. Sunlight is absorbed by the dye, raising an electron to an anti-bonding orbital in the dye. This electron then moves to the TiO_2 conduction band, leaving behind a hole. The electron goes around the circuit and passes a load, and is used to reduce I_3 to I_3 , which is then oxidized back to I_3 as the electron fills the hole left in the dye.

Figure 3. Anthocyanin pigment found in some berries will chelate to the TiO₂ surface.

Figure 4. Deposition of TiO₂ on glass.

Figure 5. Circuit diagram to measure the open-circuit potential and short circuit current (left, steps 6.3 and 6.4), and to record the I-V curve (right).

Materials List

Name	Comments
Conductive (tin dioxide	Can purchase
coated) transparent glass,	from Hartford
2.5 x 2.5 cm (2)	Glass Co.
Colloidal TiO ₂ (12 g)	Degussa P25 TiO ₂
<u>V</u> vinegar	
Deionized water	
Ethanol	
Potassium Iodide	
Iodine	
Ethylene glycol	
(anhydrous)	
Hot plate (must be able to	
heat to 450 °C)	
Small dropper bottles (2)	
Solvent squirt bottles (3)	
Pipettes	
Blackberries	
Dish soap (clear)	
Scotch tape	
Mortar and Pestle	
Kimwipes	
Binder clips (2)	
Tweezers	
Glass stirring rod	

1	1
Filter paper	
Candle or HB pencil	
Multimeter (2)	
Wires with alligator clips on each end	
500-ohm Potentiometer	
Polycarbonate lens	
Petri dish	
Aluminum foil	
Spatula	
Tungsten halogen light	
source or overhead	
projector (optional)	

References

- 1. R. Williams, *The Journal of Chemical Physics*, 1960, **32**, 1505-1514.
- 2. Wikipedia page: Solar Cells, https://en.wikipedia.org/wiki/Solar_cell#History, Accessed 28 June 2016.
- 3. B. O'Regan and M. Gratzel, *Nature*, 1991, **353**, 737-740.
- 4. G. L. Miessler, P. J. Fischer and D. A. Tarr, *Inorganic Chemistry*, Pearson, 2014.
- 5. Wikipedia page: Dye-sensitized solar cell, https://en.wikipedia.org/wiki/Dye-sensitized_solar_cell, Accessed June 29 2016.
- Smestad, G. P.; Grätzel, M. Demonstrating Electron Transfer and Nanotechnology: A Natural Dye-Sensitized Nanocrystalline Energy Converter J. Chem. Ed. 1998, 75, 752.
- 7. Burschka, J.; Pellet, N.; Moon, S.-J.; Humphry-Baker, R.; Nazeeruddin, M. K.; Grätzel, M. Sequential deposition as a route to high-performance perovskite-sensitized solar cells *Nature* **2013**, *499*, 316.




Figure 1.




Figure 2.




Figure 3.




Figure 4.




Figure 5.