

Journal of Visualized Experiments

Tissue engineering by intrinsic vascularization in an in vivo tissue engineering chamber --Manuscript Draft--

Manuscript Number:	JoVE54099R3
Full Title:	Tissue engineering by intrinsic vascularization in an in vivo tissue engineering chamber
Article Type:	Invited Methods Article - JoVE Produced Video
Keywords:	tissue engineering, vascular pedicle, arteriovenous loop, vascularization, microsurgery, femoral vessel, angiogenesis, capillaries
Manuscript Classifications:	1.10: Tissues; 1.11: Cells; 95.51: Life Sciences (General)
Corresponding Author:	Shiang Lim St Vincent's Institute of Medical Research Fitzroy, VICTORIA AUSTRALIA
Corresponding Author Secondary Information:	
Corresponding Author E-Mail:	maxlim@unimelb.edu.au
Corresponding Author's Institution:	St Vincent's Institute of Medical Research
Corresponding Author's Secondary Institution:	
First Author:	Weiqing Zhan
First Author Secondary Information:	
Other Authors:	Weiqing Zhan
	Diego Marre
	Geraldine M Mitchell
	Wayne A Morrison
Order of Authors Secondary Information:	
Abstract:	In reconstructive surgery, there is a clinical need for an alternative to our current methods of autologous reconstruction which are complex, costly and trade one defect for another. Tissue engineering holds the promise to address this increasing demand. However, most tissue engineering strategies fail to generate stable and functional tissue substitutes because of poor vascularization. This paper focuses on an in vivo tissue engineering chamber model of intrinsic vascularization where a perfused artery and a vein either as an arteriovenous loop or a flow-through pedicle configuration is directed inside a protected hollow chamber. In this chamber-based system angiogenic sprouting occurs from the arteriovenous vessels and this system attracts ischaemic and inflammatory driven endogenous cell migration which gradually fills the chamber space with fibro-vascular tissue. Exogenous cell/matrix implantation at the time of chamber construction enhances cell survival and determines specificity of the engineered tissues which develop. Our studies have shown that this chamber model can successfully generate different tissues such as fat, cardiac muscle, liver and others. However, modifications and refinements are required to ensure target tissue formation is consistent and reproducible. This article describes a standardized protocol for the fabrication of two different vascularized tissue engineering chamber models in vivo.
Author Comments:	
Additional Information:	
Question	Response
If this article needs to be "in-press" by a certain date to satisfy grant requirements,	

please indicate the date below and explain in your cover letter.

Jaydev Upponi
Science Editor, *Journal of Visualized Experiments*

19th November 2015

Re: JoVE54099R2

Dear Jaydev,

Further to your correspondence on the 12th November 2015, regarding the above paper can I confirm that we have amended our paper in line with the editorial's and reviewers' comments. We hope that you feel that our paper is now in a suitable form for publication in *Journal of Visualized Experiments*.

Yours sincerely,
Shiang Y Lim, PhD
O'Brien Institute Department,
St Vincent's Institute of Medical Research,
42 Fitzroy Street,
Victoria 3065,
Australia.
Tel: + 61 3 9288 4020
Fax: + 61 3 9416 0926
Email: maxlim@unimelb.edu.au

TITLE:

Tissue engineering by intrinsic vascularization in an in vivo tissue engineering chamber

AUTHORS:

Zhan, Weiqing^{1*}; Marre, Diego^{1*}; Mitchell, Geraldine M.¹⁻³; Morrison, Wayne A.¹⁻³; Lim, Shiang Y.¹⁻²

AUTHOR AFFILIATION:

Zhan, Weiqing^{1*};

¹O'Brien Institute Department,
St Vincent's Institute of Medical Research,
Victoria, Australia.

wzhan@svi.edu.au

Marre, Diego^{1*};

¹O'Brien Institute Department,
St Vincent's Institute of Medical Research,
Victoria, Australia.

dmarre@svi.edu.au

Mitchell, Geraldine M.¹⁻³;

¹O'Brien Institute Department,
St Vincent's Institute of Medical Research,
Victoria, Australia.

²Department of Surgery,
University of Melbourne,
Victoria, Australia.

³Faculty of Health Sciences,
Australia Catholic University,
Victoria, Australia.

gmitchell@svi.edu.au

Morrison, Wayne A.¹⁻³;

¹O'Brien Institute Department,
St Vincent's Institute of Medical Research,
Victoria, Australia.

²Department of Surgery,
University of Melbourne,
Victoria, Australia.

³Faculty of Health Sciences,
Australia Catholic University,
Victoria, Australia.

wayne.morrison@unimelb.edu.au

Lim, Shiang Y.¹⁻²

¹O'Brien Institute Department,
St Vincent's Institute of Medical Research,
Victoria, Australia.

²Department of Surgery,
University of Melbourne,
Victoria, Australia.
mlim@svi.edu.au

*W.Z. and D.M. contributed equally to this work

#CORRESPONDING AUTHOR:

Shiang Y. Lim, Ph.D.
O'Brien Institute Department, St Vincent's Institute of Medical Research, Department of
Surgery, University of Melbourne,
42 Fitzroy Street, Fitzroy, Victoria 3065, Australia.
Tel : +61 3 9288 4020
Fax : +61 3 9416 0926
Email : mlim@svi.edu.au

KEY WORDS:

Tissue engineering, vascular pedicle, arteriovenous loop, vascularization, microsurgery,
femoral vessel, angiogenesis, capillaries

SHORT ABSTRACT:

This is a guideline for constructing *in vivo* vascularized tissue using a microsurgical arteriovenous loop or a flow-through pedicle configuration inside a tissue engineering chamber. The vascularized tissues generated can be employed for organ regeneration and replacement of tissue defects, as well as for drug testing and disease modeling.

LONG ABSTRACT:

In reconstructive surgery, there is a clinical need for an alternative to the current methods of autologous reconstruction which are complex, costly and trade one defect for another. Tissue engineering holds the promise to address this increasing demand. However, most tissue engineering strategies fail to generate stable and functional tissue substitutes because of poor vascularization. This paper focuses on an *in vivo* tissue engineering chamber model of intrinsic vascularization where a perfused artery and a vein either as an arteriovenous loop or a flow-through pedicle configuration is directed inside a protected hollow chamber. In this chamber-based system angiogenic sprouting occurs from the arteriovenous vessels and this system attracts ischemic and inflammatory driven endogenous cell migration which gradually fills the chamber space with fibro-vascular tissue. Exogenous cell/matrix implantation at the time of chamber construction enhances cell survival and determines specificity of the engineered tissues which develop. Our studies have shown that this chamber model can successfully generate different tissues such as fat, cardiac muscle, liver and others. However, modifications and refinements are required to ensure target tissue formation is consistent and reproducible. This article describes a standardized protocol for the fabrication of two different vascularized tissue engineering chamber models *in vivo*.

INTRODUCTION:

Fabricating functional vascularized tissue using a tissue engineering approach is an emerging paradigm in regenerative medicine.^{1,2} Many approaches to engineer new and healthy tissue for the replacement of injured tissue or defective organs have been developed,³⁻⁶ experimentally in small animal models with promising clinical potential.^{7,8} However, vascularization remains one of the great challenges for tissue engineering limiting its potential to grow tissues of clinically relevant size.⁹

Current approaches to vascularize tissue follow either an extrinsic pathway where new vessels grow from the recipient vascular bed and invade throughout the implanted tissue constructs¹⁰ or an intrinsic vascularization pathway where the vasculature grows and expands in unison with the newly developing tissue.¹¹ The extrinsic approach traditionally involves seeding cells onto a scaffold *in vitro* and implanting the complete construct into the living animal with the expectation that nutrients, previously supplied by culture media, will be sourced from the circulation.^{12,13} The concept is simplistic as vascular ingrowth is too slow and only very thin implants (>1-2 mm thick) will remain viable. Providing nutrients and oxygen by means of a sufficient and rapid vascularization is at the heart of any successful attempts to grow more complex and larger tissue-engineered substitutes such as bone, muscle, fat and solid organs.^{14,15} Intrinsic vascularization offers the potential for larger constructs to develop by progressive tissue growth commensurate with its expanding blood supply. One design is the *in vivo* implantation into a chamber of a vascular pedicle with or without a cell seeded scaffold.^{5,6} This has paved the way to new procedures for the generation of thicker intrinsically vascularized tissues.^{16,17}

More recently, strategies have been developed to pre-vascularize tissue grafts, prior to implantation. These incorporated blood vessel networks are aimed to inosculate with host vessels at implantation allowing for the rapid provision of a complete blood supply to improve the survival of all parts of a transplanted thick tissue graft.¹⁸

We pioneered an *in vivo* vascularized tissue engineering model in small animals that involves a subcutaneously implanted semi-rigid enclosed chamber containing a perfused vascular pedicle and cell-containing biomaterials. The chamber creates an ischemic environment that stimulates angiogenic sprouting from the implanted vessels.³ The vascular pedicle can either be a reconstructed arteriovenous loop or an intact flow-through artery and vein.^{3-6,19} This vascular pedicle sprouts a functioning and extensive arterio-capillary-venous network that links at both arteriole and venous ends with the vascular pedicle.^{3,20} Furthermore, the surrounding hollow support chamber protects the developing tissue from potentially deforming mechanical forces and prolongs the ischaemic drive to enhance vascularization.^{3,21,22} If the vessel pedicle is simply implanted into normal tissue and not inside the protected space of the chamber, angiogenic sprouting ceases along the same timeline as a normal wound and no new tissue will accumulate around the pedicle. Investigators have used this *in vivo* configuration to produce three-dimensional functional vascularized tissue constructs with supportive vasculature and of clinically relevant size.^{4,23} Furthermore, the engineered vascularized tissue constructs with its intact vascular pedicle can be harvested for subsequent transplantation at the injury site.^{24,25} A more clinically feasible scenario would be creating the chamber at the definitive site for reconstruction such as the breast. Thus, this *de novo* tissue engineering approach could have clinical potential to provide a new source of functional target tissue for reconstructive surgery.²⁶⁻²⁸

The following protocol will provide a general guide to construct an *in vivo* vascularized tissue engineering chamber in the rat, which could be adapted in different animal models and employed to examine the intricate processes of angiogenesis, matrix production, and cellular migration and differentiation.

PROTOCOL:

The protocols described here have been approved by the Animal Ethics Committee of St. Vincent's Hospital Melbourne, Australia, and were conducted under strict adherence to the Australian National Health and Medical Research Council Guidelines.

NOTE: Two chamber protocols are described below. The two different models and their specific chamber designs are illustrated in Figure 1. Chamber (1) is made of polycarbonate (for rat arteriovenous loop chamber model). It is cylindrical with an internal diameter 13 mm and height 4 mm. A window at one point in the wall allows unimpeded access for the pedicle. In the second model (for rat flow-through pedicle chamber model), the chamber is made of polyacrylic and is rectangular (10 X 8 X 4 mm internal dimensions). It has two 1.5 mm openings on opposite sides to accommodate the femoral artery and vein as they transgress the chamber.

1. Rat arteriovenous loop chamber model (one chamber per animal)

NOTE: Prior to starting surgery, make sure all the instruments have been properly sterilized. Likewise, ensure the instruments rest on sterile towels and are at a reasonable distance from the surgical field to avoid contamination during the procedure.

1.1. Preparation of the animal for surgery

1.1.1. Use rats weighing at least 250 g for their large size of vessels for creation of the arteriovenous loop.

1.1.2. Anaesthetize the animal with 4% isoflurane inhalation. Corroborate adequate depth of anesthesia by assessing unresponsiveness to toe-pinch. After anesthesia, keep the animal in continuous sedation throughout the procedure with 2% isoflurane.

1.1.3. Place the animal in a supine position and apply sterile lubricant to the eyes to prevent desiccation during surgery.

1.1.4. Using an electric razor, shave both groins and remove hair with a piece of moist gauze.

1.1.5. Prep the surgical sites with chlorhexidine/70% ethanol solution and drape the animal with sterile towels.

1.2. Harvest of femoral vein graft

1.2.1. Using a #15 blade, make a 4 cm long skin incision on the left groin parallel to the inguinal ligament. This exposes the inguinal fat pad.

1.2.2. Cut through the fat pad circumferentially with scissors leaving it attached to its vascular pedicle based on the epigastric vessels.

1.2.3. Using micro scissors, free the filmy connective tissue adhesions between the abdominal wall and underlying femoral vessels.

1.2.4. Place a retractor on the abdominal wall and pull medially. This exposes the inguinal ligament and the whole length of the femoral vessels.

1.2.5. Using micro forceps and curved scissors dissect the epigastric vein and isolate it from its surrounding fat by gently pulling and cutting. This vein acts as a tether when constructing the loop.

1.2.6. Using micro forceps and curved micro scissors open the perivascular sheath containing the femoral vessels and nerve all the way from the inguinal ligament to its bifurcation distal to the epigastric branch.

1.2.7. Using micro forceps, pick up the femoral vein by its adventitia and gently separate it from the surrounding tissues and accompanying artery. Do this with micro forceps and curved round-pointed micro scissors by pulling the tissue apart and cutting through it. NOTE: Never grab the whole thickness of the vein wall as this might cause trauma to the intima making it prone to thrombosis.

1.2.8. Ligate side branches found during the dissection with 10/0 nylon suture or coagulate them with a bipolar coagulator.

1.2.9. With the femoral vein completely free, ligate its proximal and distal ends with 10/0 nylon sutures. Make sure to obtain a vein graft of at least 15 mm length and include approximately 0.5 cm length of the epigastric branch to be used as a guy rope tether to hold the loop open in the chamber.

1.2.10. Using micro forceps and straight micro scissors, trim the adventitia from the graft's ends by gently pulling and cutting. This can also be done later, before microsurgical anastomoses.

1.2.11. Flush the vein graft with heparinized saline solution (10 U/mL of heparin) and leave it to rest in the solution. Close the wound using continuous running 4/0 silk suture plus two or three additional simple interrupted stitches.

1.3. Creation of arteriovenous loop and implantation of chamber

1.3.1. Repeat steps 1.2.1 to 1.2.4 in the exact same way on the contralateral limb.

1.3.2. Using micro forceps, dissect and isolate both the epigastric artery and vein from the surrounding fat pad. Do this by gently pulling the tissue away from the vessels

1.3.3. Using micro forceps, pick up the femoral artery by its adventitia and free it from the surrounding tissues. Do this with micro forceps and curved round-pointed micro scissors by pulling the tissue apart and cutting through it. Ligate or coagulate its side branches.

1.3.4. Ligate the femoral artery and vein distal to the emergence of the epigastric vessels using 10/0 nylon suture.

1.3.5. Place a single clamp proximally on the femoral artery and vein. Using a sharp straight micro scissor, make a clean transverse cut in each vessel distal to the emergence of the epigastric branches. Place a sterile plastic contrast background under the vessels.

1.3.6. Flush the vessels vigorously with generous amounts of heparinized saline until all the blood is removed from the lumen.

1.3.7. Bring the vein graft into the operative field. Make sure that it is reversed so that its distal end is anastomosed to the artery. Anastomose the proximal end of the vein graft to the femoral vein. This will allow the blood to flow from the arterial to the venous side without resistance from valves inside the vein graft. NOTE: Make sure the femoral vessels and the vein graft rest in their natural position without any twists.

1.3.8. Remove any redundant adventitia from the vessels' ends as per step 1.2.10, if needed and perform both microsurgical anastomoses with 10/0 nylon suture.

1.3.9. Check for leaks at both anastomotic sites. Resolve small leaks, which look like non-pulsating blood coming out of the anastomotic site, by placing a small piece of fat on top and gently compressing for 5 – 10 minutes. Larger pulsating leaks that rapidly flood the entire field will need additional stitches.

1.3.10. Check patency of the arteriovenous loop. Gentle occlusion of the femoral artery should make it shrink while the same in the femoral vein should engorge it.

1.3.11. Place the base of the tissue engineering chamber under the arteriovenous loop with the latter resting in its natural position without twists or kinks.

1.3.12. Secure the base of the chamber to the inguinal ligament and underlying muscle fascia with 6/0 nylon sutures.

1.3.13. Place the lid over the base so that the femoral vessels enter the chamber through a notch (window in the side of the chamber). When closing the lid, make sure it catches the epigastric branches, between the chamber base and lid, which act as tethers to hold the arteriovenous loop into position.

1.3.14. Close the wound using continuous running 4/0 silk suture plus two or three additional simple interrupted stitches.

1.3.15. Allow the animal to recover from anesthesia and administer a single dose of Carprofen (5 mg/kg, subcutaneously) as analgesic.

1.3.16. Do not leave the animal unattended until it has regained sufficient consciousness to maintain sternal recumbency. Likewise, do not return an animal that has undergone surgery to the company of other animals until fully recovered. Treat the wound with topical antibiotic ointment for 5 days.

2. Flow-through pedicle chamber (two chambers per animal)

2.1. Preparation of the animal for surgery

2.1.1. Repeat steps 1.1.1 through 1.1.4. Two chambers can be implanted into both groin regions of a single rat.

2.2. Isolation of femoral vessels and insertion of the chamber

2.2.1. Repeat steps 1.2.1 through 1.2.8.

2.2.2. With both artery and vein completely freed of surrounding tissues and their branches ligated, bring the chamber into the operative field.

2.2.3. Place each of the intact femoral vessels on the corresponding slit of the chamber base making sure there are no twists or kinks.

2.2.4. Close the chamber by attaching the lid to the base. Close the wound using continuous running 4/0 silk suture plus two or three additional simple interrupted stitches and allow the animal to recover as previously described.

3. Harvest of chambers and tissue processing

3.1. Once the experiment's time points (4-6 weeks post-implantation) are reached, anesthetize the animal as in step 1.1.2 and repeat steps 1.1.3 through 1.1.5.

3.2. Open the wound using a #15 blade and cut through the tissues with scissors until the chamber is completely exposed.

3.3. Expose the femoral vessels proximal to the construct and test for vascular patency: gently occlude the vessel with two microforceps, then milk the blood in a distal direction and finally release the proximal forceps. If the vessel fills with blood again, this confirms patency. Ligate the femoral vessels proximally in the case of the arteriovenous loop and both proximally and distally in the case of the flow-through configuration, and remove the chambers with the containing tissue *en-bloc*.

3.4. At the end of the experiment, euthanize the animal using a lethal dose of intraperitoneal lethobarb injection (163 mg/kg in 0.25 ml by 23 gauge needle).

3.5. Fix tissues in 4% paraformaldehyde at room temperature for 24 hours. Divide tissues into multiple transverse sections (1-2mm thick) and embed in paraffin wax or optimal cutting temperature compound for paraffin sections (5 μ m) or frozen sections (10 μ m), respectively.^{3,4,8,17,22,24}

3.6. Perform routine histological staining such as hematoxylin and eosin to examine the general morphology of tissues. Perform immunohistochemical staining with specific antibody to identify cell type of interest,^{3,4,8,17,22,24,29} for example cardiac troponin T immunostaining for cardiomyocytes.

REPRESENTATIVE RESULTS:

The microsurgical creation of tissue engineering chambers was performed as described in the protocol above. Tissues generated inside the chambers can be examined histologically as describe in protocol step 3. Various tissue types have been successfully engineered using the *in vivo* vascularized chamber (Figure 2). These include cardiac tissue with neonatal rat cardiomyocytes (Figure 2A), muscle tissue with rat skeletal myoblasts (Figure 2B), and

adipose tissue with a hydrogel derived from adipose tissue extracellular matrix (Figure 2C).

Morphometric evaluation of the tissues can be performed with either a stereo investigator system or Image J software.^{3,4,8,17,22,29} In addition to qualitative assessment of various tissue components, the stereology system also allows for unbiased quantification of specific tissue volume. For example, lectin (a marker for rodent endothelial cells) stained transverse sections (Figure 3) can be used to estimate the vascular volume of the harvested tissue constructs using video microscopy with stereology system. Similar quantification methods can be applied to assess the volume of other tissue types.

The tissue engineering chambers can also be employed to track cell fate following *in vivo* implantation. Cells can be pre-labelled with fluorescent dyes such as DiI, PKH26 or quantum dots before implantation. For example, neonatal rat cardiomyocytes pre-labelled with DiI can be detected in the tissue constructs harvested at 3 day post-implantation (Figure 4A). We have also successfully tracked implanted cells that have been pre-labelled with DiI for up to 4 weeks post-implantation. Alternatively, species-specific antibodies can be used to identify implanted cells in xenotransplantation studies. For example, human induced pluripotent stem cells implanted inside tissue engineering chambers in immunocompromized rats can be identified in the harvested tissue constructs by immunostaining with human-specific Ku80 antibody (Figure 4B).

FIGURE LEGENDS:

Figure 1. Cardiac tissue engineering with the *in vivo* vascularized chamber. Intrinsic vascularization approach with arteriovenous loop chamber model and flow-through pedicle chamber model. The chambers were made from either polycarbonate or polyacrylic, these materials were tested to be non-inflammatory and non-toxic *in vivo*. Scale bar = 5 mm. Reprinted with permission from³⁰.

Figure 2. Tissues engineered from the *in vivo* vascularized chambers. (A) Cardiac tissue with neonatal rat cardiomyocytes. Cardiomyocytes were immunostained with cardiac troponin T antibody (brown). (B) Muscle tissue with rat skeletal myoblasts. Muscle cells were immunostained with desmin antibody (brown). (C) Fat tissue with a hydrogel derived from adipose tissue extracellular matrix.³¹ Haematoxylin and eosin staining. Scale bar = 50 μ m.

Figure 3. Vascularity of a tissue constructs harvested at 4 weeks post-implantation. Representative images of lectin-stained sections. The blood vessels sprouting from the femoral artery (*) were labelled with lectin (brown). Scale bar = 200 μ m (left) and 100 μ m (right).

Figure 4. Identification of transplanted cells in the tissue constructs. (A) DiI-label neonatal rat cardiomyocytes (red and white arrows) in a rat tissue construct harvested at 3 days post-implantation. (B) A representative human-specific Ku80 stained histology image of a tissue construct harvested from a rat tissue engineering chamber implanted with human induced pluripotent stem cells at 28 days post-implantation. Human nuclei were immunolabelled brown and immunocompromized rat was used to prevent rejection of human cells. Scale bar = 50 μ m.

DISCUSSION:

Engineering of the microcirculation is currently being investigated essentially through two approaches. The first involves developing a highly interconnected vascular network within the construct *in vitro* so that when implanted, capillaries from the host vascular bed connect with those of the transplanted construct through a process called inosculation, thus ensuring the delivery of nutrients not only to the periphery but also to the core.^{21,32,33} This is called pre-vascularization. The second approach attempts to enhance the host's own vasculature directly *in vivo*, so that capillary sprouting occurs either before or concomitantly with implanted cell differentiation and tissue growth.^{17,34}

The *in vivo* tissue engineering chamber protocol presented here exploits the latter concept by placing an artery and a vein, either as an arteriovenous loop or a flow-through pedicle configuration, inside a protected empty space, allowing significant sprouting and formation of new capillaries over time.³ Advantages of the chamber include (1) the absence of *in vitro* manipulations; (2) the generation of a completely autologous vascular network which will not be rejected by the host; and (3) the fact that it does not need an inosculation period which can take between 1 to 7 days rendering the tissue construct prone to ischemia.^{35,36}

Nevertheless, it must be noted that it takes around 3-7 days for significant capillary sprouting to occur, a period during which the implanted tissue is also poorly supplied.³ Delayed cell implantation once the chamber is adequately vascularized has in fact shown improved survival.¹⁷ A further advantage includes the biocompatibility and non-immunogenicity of the chambers' material (i.e. polycarbonate and polyacrylic). In addition, the rigid non-collapsible chamber provides a protected space for the tissue and vasculature to grow without merging and integrating with the surrounding environment, which would otherwise hamper expansion and make harvest of the newly formed tissue difficult. Contrastingly, the fact that chambers are closed may limit tissue growth. This, however, has been addressed in the arteriovenous loop model, which now uses a perforated chamber that has been shown to grow tissue more effectively than the closed one.³⁷

The tissue-engineering chamber protocols presented here are highly reproducible but it should be stressed that the chambers rarely fill to completion, usually to about 70% capacity. Consistent results are achieved provided that some critical steps and technical issues are taken into consideration. Pedicle patency is the ultimate aim when working with blood vessels, particularly if microsurgical anastomoses are performed. We have consistently found no tissue grows if the vascular pedicle thromboses early post-surgery. Factors affecting patency can be broadly grouped into four categories, namely surgical technical, blood flow, thrombosis and spasm.

First, a delicate surgical technique is the key to success. In this sense, it should be noted that these procedures, especially the one involving the creation of an arteriovenous loop require a certain level of surgical skill which can be readily acquired by practicing first in non-living models and subsequently in the rat's femoral vessels following the principles and techniques described here and elsewhere.³⁸ Damage to the vessel wall, especially the intima, must be avoided at all times by proper handling of the vessels, which includes never grabbing the full thickness of the vessel wall, preventing excessive stretching, judicious use of the bipolar coagulator, and in the case of the arteriovenous loop, performance of meticulous and atraumatic microsurgical anastomoses. Although flushing with heparinized saline helps prevent clotting, it will never replace a fine surgical technique. Second, blood flow factors

relate mainly to turbulence and stasis. Turbulent flow secondary to twists, bends or kinks of vessels promotes thrombus formation. Therefore a streamline unrestricted flow must be ensured in both the arteriovenous loop and the flow-through models. In this sense, the tethering effect of the epigastric branches in the arteriovenous loop model is essential to prevent bending; if for any reason these branches cannot be used, simple 10/0 nylon stitches from the vessel wall to the surrounding tissues should be carefully placed instead. Static blood at the anastomotic site during the arteriovenous loop procedure is also highly thrombogenic and must be prevented by flushing the vessel vigorously with heparinized saline prior to and throughout the anastomosis. Thirdly, pro-thrombotic factors such as contaminants from the operative field and most importantly the presence of pieces of adventitia inside the anastomosis are to be avoided. Preparing the vessel ends correctly prior to microsurgical suturing and keeping the field and anastomosis clean by flushing regularly are important aspects to consider when constructing the arteriovenous loop. Last but not least, there is the issue of vessel spasm. Even though the pathophysiology of vessel spasm has not been completely elucidated, it is likely to be due to both local and systemic factors. Local factors include vessel trauma, presence of blood in the operative field and tissue desiccation. Systemic factors, on the other hand, comprise low core temperature, hypotension and sympathetic response to pain.³⁸

Thus, in both arteriovenous loop and flow-through models, proper handling and preparation of the animal together with a delicate surgical technique cannot be overemphasized. Strategies to resolve spasm include irrigation with warm saline or undiluted 1% xylocaine and having a rest period of 5 – 10 minutes. Vessel dilation and stripping of the adventitia can also help to relieve spasm due to its local sympathectomy effect.³⁸ To circumvent the need to perform microsurgical anastomoses and the technical challenge it implies, the cuff technique can be employed as described elsewhere.³⁹ This technique consists of inserting one of the vessel ends into a cuff, evert it and secure it with a circumferential 6/0 nylon suture. Next, the other vessel end is slid over the cuff and secured in a similar way.

The tissue-engineering chamber has opened a new window of possibilities in experimental research and is steadily advancing towards a potential clinical purpose. Until now, the models presented here have been used mainly for the generation of tissues of different lineages.^{4,7,8,17,22,,24,25,27-29,37,40} Nevertheless, they do have a number of other potential applications. For example, we have used the flow-through chamber as an effective and comparatively fast model for teratoma formation after implantation of human induced pluripotent stem cells.^{41,42} Thus, this approach may be used as a “quality control” tool to achieve tumor-free tissue engineering with pluripotent stem cells. Also, drug toxicology studies could be explored in human tissues grown inside the chamber. Likewise, generation of pathologic tissue could yield an interesting approach towards disease modeling and drug testing. Finally, the tissue-engineering chamber might also become a potential model to study growth of tissue and tracking of cell fate *in vivo*.

In conclusion, we have described a protocol involving the placement of a subcutaneous chamber in animals through two different approaches: using a microsurgical arteriovenous loop, or a flow-through pedicle configuration. The technique is highly reproducible and yields consistent results. Its use has been exploited mainly in the field of tissue engineering so far, however, there are other potential research fields for which these chambers might be of great application.

ACKNOWLEDGEMENTS:

This work was supported by grant funding from NHMRC and Stafford Fox Medical Foundation. The authors acknowledge the surgical assistance of Sue McKay, Liliana Pepe, Anna Deftereos and Amanda Rixon of the Experimental Medical and Surgical Unit, St. Vincent's Hospital, Melbourne. Support is also provided by the Victorian State Government's Department of Innovation, Industry and Regional Development's Operational Infrastructure Support Program.

DISCLOSURES:

The authors declare no competing interests.

REFERENCES:

1. Spiliopoulos, K., et al. Current status of mechanical circulatory support: A systematic review. *Cardiol Res Pract.* 2012 574198, doi:10.1155/2012/574198 (2012).
2. Hsu, P.L., Parker, J., Egger, C., Autschbach, R., Schmitz-Rode, T. & Steinseifer, U. Mechanical circulatory support for right heart failure: Current technology and future outlook. *Artif Organs.* **36** (4), 332-347, doi:10.1111/j.1525-1594.2011.01366.x (2012).
3. Lokmic, Z., Stillaert, F., Morrison, W.A., Thompson, E.W. & Mitchell GM. An arteriovenous loop in a protected space generates a permanent, highly vascular, tissue-engineered construct. *FASEB J.* **21** (2), 511-522, doi:10.1096/fj.06-6614com (2007).
4. Morritt, A.N., et al. Cardiac tissue engineering in an in vivo vascularized chamber. *Circulation.* **115** (3), 353-360, doi:10.1161/CIRCULATIONAHA.106.657379 (2007).
5. Tanaka, Y., Tsutsumi, A., Crowe, D. M., Tajima, S. & Morrison, W. A. Generation of an autologous tissue (matrix) flap by combining an arteriovenous shunt loop with artificial skin in rats: preliminary report. *B J Plast Surg.* **53** (1), 51-57, doi:10.1054/bjps.1999.3186 (2000).
6. Cronin, K. J. et al. New murine model of spontaneous autologous tissue engineering, combining an arteriovenous pedicle with matrix materials. *Plast Reconstr Surg.* **113** (1), 260-269, doi:10.1097/01.prs.0000095942.71618.9d (2004).
7. Forster, N.A., et al. A prevascularized tissue engineering chamber supports growth and function of islets and progenitor cells in diabetic mice. *Islets.* **3** (5), 271-283, doi:10.4161/isl.3.5. 15942 (2011).
8. Choi, Y.S., Matsuda, K., Disting, G.J., Morrison, W.A. & Dilley, R.J. Engineering cardiac tissue in vivo from human adipose-derived stem cells. *Biomaterials.* **31** (8), 2236-2242, doi:10.1016/j.biomaterials.2009.11.097 (2010).
9. Jeyaraj, R., G, N., Kirby, G., Rajadas, J., Mosahebi, A., Seifalian, A.M. & Tan, A. Vascularisation in regenerative therapeutics and surgery. *Mater Sci Eng C Mater Biol Appl.* **54**, 225-238, doi:10.1016/j.msec.2015.05.045 (2015).
10. Dew, L., Macneil, S. & Chong, C.K. Vascularization strategies for tissue engineers. *Regen Med.* **10** (2), 211-224, doi:10.2217/rme.14.83 (2015).
11. Weigand, A., et al. Acceleration of vascularized bone tissue-engineered constructs in a large animal model combining intrinsic and extrinsic vascularization. *Tissue Eng Part A.* **21** (9-10), 1680-1694, doi:10.1089/ten.TEA.2014.0568 (2015).
12. Vacanti, J. P., Langer, R., Upton, J. & Marler, J. J. Transplantation of cells in matrices for tissue regeneration. *Adv Drug Deliv Rev.* **33** (1-2), 165-182, doi:10.1016/S0169-409X(98)00025-8 (1998).
13. Beahm, E. K., Walton, R. L. & Patrick, C. W., Jr. Progress in adipose tissue construct development. *Clin Plast Surg.* **30** (4), 547-558, doi: http://dx.doi.org/10.1016/S0094-1298(03)00072-5 (2003).

14. Vunjak-Novakovic, G., et al. Challenges in cardiac tissue engineering. *Tissue Eng Part B Rev.* **16** (2), 169-187, doi:10.1089/ten.TEB.2009.0352 (2010).
15. Garcia, J. R. & Garcia, A. J. Biomaterial-mediated strategies targeting vascularization for bone repair. *Drug Deliv Transl Res*, doi:10.1007/s13346-015-0236-0 (2015).
16. Forster, N., et al. Expansion and hepatocytic differentiation of liver progenitor cells in vivo using a vascularized tissue engineering chamber in mice. *Tissue Eng Part C Methods.* **17** (3), 359-366, doi:10.1089/ten.TEC.2009.0519 (2011).
17. Tilkorn D.J., et al. Implanted myoblast survival is dependent on the degree of vascularization in a novel delayed implantation/prevascularization tissue engineering model. *Tissue Eng Part A.* **16** (1), 165-178, doi: 10.1089/ten.TEA.2009.0075 (2010).
18. Chang, Q. & Lu, F. A novel strategy for creating a large amount of engineered fat tissue with an axial vascular pedicle and a prefabricated scaffold. *Med hypotheses.* **79** (2), 267-270, doi:10.1016/j.mehy.2012.05.007 (2012).
19. Walton, R.L., Beahm, E.K. & Wu, L. De novo adipose formation in a vascularized engineered construct. *Microsurg.* **24** (5), 378-384, doi:10.1002/micr.20056 (2004).
20. Debels, H., Gerrand, Y. W., Poon, C. J., Abberton, K. M., Morrison, W. A. & Mitchell, G. M. An adipogenic gel for surgical reconstruction of the subcutaneous fat layer in a rat model. *J Tissue Eng Regen Med.*, doi:10.1002/term.2025 (2015).
21. Lokmic, Z. & Mitchell, G.M. Engineering the microcirculation. *Tissue Eng Part B Rev.* **14** (1), 87-103, doi:10.1089/teb.2007.0299 (2008).
22. Yap, K.K., et al. Enhanced liver progenitor cell survival and differentiation in vivo by spheroid implantation in a vascularized tissue engineering chamber. *Biomaterials.* **34** (16), 3992-4001, doi:10.1016/j.biomaterials.2013.02.011 (2013).
23. Findlay, M.W., et al. Tissue-engineered breast reconstruction: Bridging the gap toward large-volume tissue engineering in humans. *Plast Reconstr Surg.* **128** (6), 1206-1215, doi:10.1097/PRS.0b013e318230c5b2 (2011).
24. Tee, R., Morrison, W. A., Disting, G. J., Liu, G. S., Choi, Y. S., Hsiao, S. T. & Dilley, R. J. Transplantation of engineered cardiac muscle flaps in syngeneic rats. *Tissue Eng Part A.* **18** (19-20), 1992-1999, doi:10.1089/ten.TEA.2012.0151 (2012).
25. Dolderer, J.H., et al. Long-term stability of adipose tissue generated from a vascularized pedicled fat flap inside a chamber. *Plast Reconstr Surg.* **127** (6), 2283-2292, doi:10.1097/PRS.0b013e3182131c3e (2011).
26. Sekine, H., et al. Endothelial cell coculture within tissue-engineered cardiomyocyte sheets enhances neovascularization and improves cardiac function of ischemic hearts. *Circulation.* **118** (14 Suppl), S145-S152, doi:10.1161/CIRCULATIONAHA.107.757286 (2008).
27. Ting, A.C., et al. The adipogenic potential of various extracellular matrices under the influence of an angiogenic growth factor combination in a mouse tissue engineering chamber. *Acta Biomater.* **10** (5), 1907-1918, doi:10.1016/j.actbio.2013.11.019 (2014).
28. Zhan, W., et al. Self-synthesized extracellular matrix contributes to mature adipose tissue regeneration in a tissue engineering chamber. *Wound Repair Regen.* **23** (3), 443-452, doi:10.1111/wrr.12292 (2015).
29. Messina, A., Bortolotto, S.K., Cassell, O.C., Kelly, J., Abberton, K.M. & Morrison, W.A. Generation of a vascularized organoid using skeletal muscle as the inductive source. *FASEB J.* **19** (11), 1570-1572, doi:10.1096/fj.04-3241fje (2005).
30. Lim, S.Y., Hernández, D. & Disting, G.J. Growing vascularized heart tissue from stem cells. *J Cardiovasc Pharmacol.* **62** (2):122-129, doi: 10.1097/FJC.0b013e31829372fc (2013).
31. Poon, C.J., et al. Preparation of an adipogenic hydrogel from subcutaneous adipose tissue. *Acta Biomater.* **9** (3), 5609-5620, doi:10.1016/j.actbio.2012.11.003 (2013).

32. Dilley, R.J. & Morrison, W.A. Vascularisation to improve translational potential of tissue engineering systems for cardiac repair. *Int J Biochem Cell Biol.* **56** 38-46, doi:10.1016/j.biocel.2014.10.020 (2014).
33. Lesman, A., Koffler, J., Atlas, R., Blinder, Y.J., Kam, Z. & Levenberg, S. Engineering vessel-like networks within multicellular fibrin-based constructs. *Biomaterials.* **32** (31), 7856-7869, doi: 10.1016/j.biomaterials.2011.07.003 (2011).
34. Hussey A.J., et al. Seeding of pancreatic islets into prevascularized tissue engineering chambers. *Tissue Eng Part A.* **15** (12), 3823-3833, doi: 10.1089/ten.TEA.2008.0682 (2009).
35. Chen, X., Aledia, A.S., Popson, S.A., Him, L., Hughes, C.C. & George, S.C. Rapid anastomosis of endothelial progenitor cell-derived vessels with host vasculature is promoted by a high density of cotransplanted fibroblasts. *Tissue Eng Part A.* **16** (2), 585-594, doi: 10.1089/ten.TEA.2009.0491 (2010).
36. Lin, R.Z. & Melero-Martin, J.M. Fibroblast growth factor-2 facilitates rapid anastomosis formation between bioengineered human vascular networks and living vasculature. *Methods.* **56** (3), 440-451, doi: 10.1016/j.ymeth.2012.01.006 (2012).
37. Dolderer, J.H., et al. Spontaneous large volume adipose tissue generation from a vascularized pedicled fat flap inside a chamber space. *Tissue Eng.* **13** (4):673-681, doi:10.1089/ten.2006.0212 (2007).
38. Wei, F.C. & Lin Tay, S.K. Principles and techniques of microvascular surgery. In: *Plastic Surgery*. Volume 1, Chapter 26, Neligan, P.C., Gurtner, G.C., eds., Elsevier, 587-620 (2013).
39. Sekine, H., et al. In vitro fabrication of functional three-dimensional tissues with perfusable blood vessels. *Nat Comm.* **4** (1399):1-10, doi:10.1038/ncomms2406 (2013).
40. Lim, S.Y., Sivakumaran, P., Crombie, D.E., Disting, G.J., Pébay, A. & Dilley, R.J. Trichostatin A enhances differentiation of human induced pluripotent stem cells to cardiogenic cells for cardiac tissue engineering. *Stem Cells Transl Med.* **2** (9):715-725, doi: 10.5966/sctm.2012-0161 (2013).
41. Lim, S.Y., et al. In vivo tissue engineering chamber supports human induced pluripotent stem cell survival and rapid differentiation. *Biochem Biophys Res Commun.* **422** (1):75-79, doi: 10.1016/j.bbrc.2012.04.108 (2012).
42. Piao, Y., Hung, S.S., Lim, S.Y., Wong, R.C. & Ko, M.S. Efficient generation of integration-free human induced pluripotent stem cells from keratinocytes by simple transfection of episomal vectors. *Stem Cells Transl Med.* **3** (7):787-791, doi: 10.5966/sctm.2013-0036 (2014).


Figure 1

Figure 2




Figure 3





Figure 4



MATERIALS LIST		
Product/Instrument	Concentration	Company
1 15 Blade Scalpel		Braun
1 Toothed Adson Forceps		Braun
1 Needle Holder		Braun
1 Bipolar Coagulator		Braun
1 Micro Needle Holder B-15-8.3		S & T
1 Micro Dilator Forceps D-5a.2		S & T
1 Micro Jeweler's Forceps JF-5		S & T
1 Micro Scissors - Straight SAS-11		S & T
1 Micro Scissors - Curved SDC-11		S & T
2 Single Clamps B-3		S & T
2 10/0 nylon suture		S & T
1 6/0 nylon suture		Braun
2 4/0 Silk Sutures		Braun
Xilocaine 1%	10 mg/ml	Dealmed
Heparin Sodium	5000 UI / ml	Dealmed
Ringer Lactate	500 ml	Baxter
1 dome-shaped tissue engineering chamber		custom made
1 flow-through chamber		custom made
Lectin I, Griffonia Simplicifolia	1.67 µg/mL	Vector Laboratories
Troponin T antibody	4 µg/mL	Abcam
Human-specific Ku80 antibody	0.06 µg/mL	Abcam
Desmin antibody	2.55 µg/mL	Dako
Cell Tracker CM-Dil dye	3 mg/10 ⁶ cells	Thermo Fisher Scientific

Catalog Number	Web Address
BB515	www.bbraun.com
BD527R	www.bbraun.com
BM201R	www.bbraun.com
US335	www.bbraun.com
00763	www.s-and-t.net
00125	www.s-and-t.net
00108	www.s-and-t.net
00098	www.s-and-t.net
00090	www.s-and-t.net
00400	www.s-and-t.net
03199	www.s-and-t.net
G2095469	www.bbraun.com
C0760145	www.bbraun.com
150733	www.dealmed.com
272301	www.dealmed.com
JB2323	www.baxter.ca
B-1105	www.vectorlabs.com
Ab8295	www.abcam.com
Ab80592	www.abcam.com
M0760	www.dako.com
C-7000	www.thermofisher.com



1 Alewife Center #200
Cambridge, MA 02140
tel. 617.945.9051
www.jove.com

ARTICLE AND VIDEO LICENSE AGREEMENT

Title of Article: In vivo tissue engineering chamber for tissue construction with intrinsic vascularization
 Author(s): Wuqing Zhan, Diego Marre, Geraldine M. Mitchell, Wayne A. Morrison, Shiang Y. Lim

Item 1 (check one box): The Author elects to have the Materials be made available (as described at <http://www.jove.com/publish>) via: ☒ Standard Access ☐ Open Access

Item 2 (check one box):

- ☒ The Author is NOT a United States government employee.
☐ The Author is a United States government employee and the Materials were prepared in the course of his or her duties as a United States government employee.
☐ The Author is a United States government employee but the Materials were NOT prepared in the course of his or her duties as a United States government employee.

ARTICLE AND VIDEO LICENSE AGREEMENT

1. **Defined Terms.** As used in this Article and Video License Agreement, the following terms shall have the following meanings: "Agreement" means this Article and Video License Agreement; "Article" means the article specified on the last page of this Agreement, including any associated materials such as texts, figures, tables, artwork, abstracts, or summaries contained therein; "Author" means the author who is a signatory to this Agreement; "Collective Work" means a work, such as a periodical issue, anthology or encyclopedia, in which the Materials in their entirety in unmodified form, along with a number of other contributions, constituting separate and independent works in themselves, are assembled into a collective whole; "CRC License" means the Creative Commons Attribution-Non Commercial-No Derivs 3.0 Unported Agreement, the terms and conditions of which can be found at: <http://creativecommons.org/licenses/by-nc-nd/3.0/legalcode>; "Derivative Work" means a work based upon the Materials or upon the Materials and other pre-existing works, such as a translation, musical arrangement, dramatization, fictionalization, motion picture version, sound recording, art reproduction, abridgment, condensation, or any other form in which the Materials may be recast, transformed, or adapted; "Institution" means the institution, listed on the last page of this Agreement, by which the Author was employed at the time of the creation of the Materials; "JoVE" means MyJoVE Corporation, a Massachusetts corporation and the publisher of *The Journal of Visualized Experiments*; "Materials" means the Article and / or the Video; "Parties" means the Author and JoVE; "Video" means any video(s) made by the Author, alone or in conjunction with any other parties, or by JoVE or its affiliates or agents, individually or in collaboration with the Author or any other parties, incorporating all or any portion of the Article, and in which the Author may or may not appear.

2. **Background.** The Author, who is the author of the Article, in order to ensure the dissemination and protection of the Article, desires to have the JoVE publish the Article and create and transmit videos based on the Article. In furtherance of such goals, the Parties desire to memorialize in this Agreement the respective rights of each Party in and to the Article and the Video.

3. **Grant of Rights in Article.** In consideration of JoVE agreeing to publish the Article, the Author hereby grants to JoVE, subject to Sections 4 and 7 below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Article in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Article into other languages, create adaptations, summaries or extracts of the Article or other Derivative Works (including, without limitation, the Video) or Collective Works based on all or any portion of the Article and exercise all of the rights set forth in (a) above in such translations, adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. If the "Open Access" box has been checked in Item 1 above, JoVE and the Author hereby grant to the public all such rights in the Article as provided in, but subject to all limitations and requirements set forth in, the CRC License.

ARTICLE AND VIDEO LICENSE AGREEMENT

4. **Retention of Rights in Article.** Notwithstanding the exclusive license granted to JoVE in Section 3 above, the Author shall, with respect to the Article, retain the non-exclusive right to use all or part of the Article for the non-commercial purpose of giving lectures, presentations or teaching classes, and to post a copy of the Article on the Institution's website or the Author's personal website, in each case provided that a link to the Article on the JoVE website is provided and notice of JoVE's copyright in the Article is included. All non-copyright intellectual property rights in and to the Article, such as patent rights, shall remain with the Author.

5. **Grant of Rights in Video – Standard Access.** This Section 5 applies if the "Standard Access" box has been checked in Item 1 above or if no box has been checked in Item 1 above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby acknowledges and agrees that, Subject to Section 7 below, JoVE is and shall be the sole and exclusive owner of all rights of any nature, including, without limitation, all copyrights, in and to the Video. To the extent that, by law, the Author is deemed, now or at any time in the future, to have any rights of any nature in or to the Video, the Author hereby disclaims all such rights and transfers all such rights to JoVE.

6. **Grant of Rights in Video – Open Access.** This Section 6 applies only if the "Open Access" box has been checked in Item 1 above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby grants to JoVE, subject to Section 7 below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Video in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Video into other languages, create adaptations, summaries or extracts of the Video or other Derivative Works or Collective Works based on all or any portion of the Video and exercise all of the rights set forth in (a) above in such translations, adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. For any Video to which this Section 6 is applicable, JoVE and the Author hereby grant to the public all such rights in the Video as provided in, but subject to all limitations and requirements set forth in, the CRC License.

7. **Government Employees.** If the Author is a United States government employee and the Article was prepared in the course of his or her duties as a United States government employee, as indicated in Item 2 above, and any of the licenses or grants granted by the Author hereunder exceed the scope of the 17 U.S.C. 403, then the rights granted hereunder shall be limited to the maximum rights permitted under such

statute. In such case, all provisions contained herein that are not in conflict with such statute shall remain in full force and effect, and all provisions contained herein that do so conflict shall be deemed to be amended so as to provide to JoVE the maximum rights permissible within such statute.

8. **Likeness, Privacy, Personality.** The Author hereby grants JoVE the right to use the Author's name, voice, likeness, picture, photograph, image, biography and performance in any way, commercial or otherwise, in connection with the Materials and the sale, promotion and distribution thereof. The Author hereby waives any and all rights he or she may have, relating to his or her appearance in the Video or otherwise relating to the Materials, under all applicable privacy, likeness, personality or similar laws.

9. **Author Warranties.** The Author represents and warrants that the Article is original, that it has not been published, that the copyright interest is owned by the Author (or, if more than one author is listed at the beginning of this Agreement, by such authors collectively) and has not been assigned, licensed, or otherwise transferred to any other party. The Author represents and warrants that the author(s) listed at the top of this Agreement are the only authors of the Materials. If more than one author is listed at the top of this Agreement and if any such author has not entered into a separate Article and Video License Agreement with JoVE relating to the Materials, the Author represents and warrants that the Author has been authorized by each of the other such authors to execute this Agreement on his or her behalf and to bind him or her with respect to the terms of this Agreement as if each of them had been a party hereto as an Author. The Author warrants that the use, reproduction, distribution, public or private performance or display, and/or modification of all or any portion of the Materials does not and will not violate, infringe and/or misappropriate the patent, trademark, intellectual property or other rights of any third party. The Author represents and warrants that it has and will continue to comply with all government, institutional and other regulations, including, without limitation all institutional, laboratory, hospital, ethical, human and animal treatment, privacy, and all other rules, regulations, laws, procedures or guidelines, applicable to the Materials, and that all research involving human and animal subjects has been approved by the Author's relevant institutional review board.

10. **JoVE Discretion.** If the Author requests the assistance of JoVE in producing the Video in the Author's facility, the Author shall ensure that the presence of JoVE employees, agents or independent contractors is in accordance with the relevant regulations of the Author's institution. If more than one author is listed at the beginning of this Agreement, JoVE may, in its sole discretion, elect not take any action with respect to the Article until such time as it has received complete, executed Article and Video License Agreements from each such author. JoVE reserves the right, in its absolute and sole discretion and without giving any reason therefore, to accept or decline any work submitted to JoVE. JoVE and its employees, agents and independent contractors shall have

ARTICLE AND VIDEO LICENSE AGREEMENT

full, unfettered access to the facilities of the Author or of the Author's institution as necessary to make the Video, whether actually published or not. JoVE has sole discretion as to the method of making and publishing the Materials, including, without limitation, to all decisions regarding editing, lighting, filming, timing of publication, if any, length, quality, content and the like.

11. **Indemnification.** The Author agrees to indemnify JoVE and/or its successors and assigns from and against any and all claims, costs, and expenses, including attorney's fees, arising out of any breach of any warranty or other representations contained herein. The Author further agrees to indemnify and hold harmless JoVE from and against any and all claims, costs, and expenses, including attorney's fees, resulting from the breach by the Author of any representation or warranty contained herein or from allegations or instances of violation of intellectual property rights, damage to the Author's or the Author's institution's facilities, fraud, libel, defamation, research, equipment, experiments, property damage, personal injury, violations of institutional, laboratory, hospital, ethical, human and animal treatment, privacy or other rules, regulations, laws, procedures or guidelines, liabilities and other losses or damages related in any way to the submission of work to JoVE, making of videos by JoVE, or publication in JoVE or elsewhere by JoVE. The Author shall be responsible for, and shall hold JoVE harmless from, damages caused by lack of sterilization, lack of cleanliness or by contamination due to the making of a video by JoVE its employees, agents or independent contractors. All sterilization, cleanliness or decontamination procedures shall be solely the responsibility of the Author and shall be undertaken at the Author's


expense. All indemnifications provided herein shall include JoVE's attorney's fees and costs related to said losses or damages. Such indemnification and holding harmless shall include such losses or damages incurred by, or in connection with, acts or omissions of JoVE, its employees, agents or independent contractors.

12. **Fees.** To cover the cost incurred for publication, JoVE must receive payment before production and publication the Materials. Payment is due in 21 days of invoice. Should the Materials not be published due to an editorial or production decision, these funds will be returned to the Author. Withdrawal by the Author of any submitted Materials after final peer review approval will result in a US\$1,200 fee to cover pre-production expenses incurred by JoVE. If payment is not received by the completion of filming, production and publication of the Materials will be suspended until payment is received.

13. **Transfer, Governing Law.** This Agreement may be assigned by JoVE and shall inure to the benefits of any of JoVE's successors and assignees. This Agreement shall be governed and construed by the internal laws of the Commonwealth of Massachusetts without giving effect to any conflict of law provision thereunder. This Agreement may be executed in counterparts, each of which shall be deemed an original, but all of which together shall be deemed to me one and the same agreement. A signed copy of this Agreement delivered by facsimile, e-mail or other means of electronic transmission shall be deemed to have the same legal effect as delivery of an original signed copy of this Agreement.

A signed copy of this document must be sent with all new submissions. Only one Agreement required per submission.

CORRESPONDING AUTHOR:

Name: Shiang Y. Lim
Department: O'Brien Institute Department
Institution: St Vincent's Institute of Medical Research
Article Title: In vivo tissue engineering chamber for tissue construction with minimiz vascularization
Signature:  Date: 4/9/2015

Please submit a signed and dated copy of this license by one of the following three methods:

- 1) Upload a scanned copy of the document as a pdf on the JoVE submission site;
- 2) Fax the document to +1.866.381.2236;
- 3) Mail the document to JoVE / Attn: JoVE Editorial / 1 Alewife Center #200 / Cambridge, MA 02139

For questions, please email submissions@jove.com or call +1.617.945.9051

***In vivo* tissue engineering chamber for tissue construction with intrinsic vascularization (JoVE54099R2)**

We thank the editor and reviewers for his/her helpful and constructive comments. Please find our response below.

Editorial comments:

• Formatting

-Please check that all portions of protocol steps are in the imperative tense (e.g., 1.1.2-“Adequate depth of anesthesia...toe-pinch.”; 1.3.7-“The proximal end...vein graft.”). In certain instances, such statements can be included as Notes.

[This change has now been made.](#)

-Please include catalog numbers in the Materials/Equipment list. In addition, please check that all items have been included in this list (e.g., cardiac troponin T antibody).

[This change has now been made.](#)

•Additional detail is required:

-1.2.11-Please elaborate on how to “close the wound in two layers.”

[This has been clarified in Procedure.](#)

-3.1-What are the typical time points used?

[The typical harvesting time points are 4-6 weeks post-implantation. This has now been added to 3.1.](#)

-3.3-Please elaborate on, or provide a superscript reference, for the test for vascular patency. In addition, how is the chamber removed? Do any specific cuts need to be made?

[The test for patency has been described in step 3.3 of Procedure. The chamber is removed as explained after ligating the femoral vessels. No additional or specific cuts need to be made.](#)

-3.5-Is fixation performed at room temperature or 4°C? In addition, provide a reference for microtome/cryostat sectioning.

[Tissue fixation was performed at room temperature. This has been added to the manuscript \(Please see page 7\). Reference for microtome/cryostat sectioning has been added to the manuscript \(Please see page 7\).](#)

-3.6-Provide references for immunohistochemistry.

[References have been added to the manuscript \(Please see page 7\).](#)

•Branding should be removed:

-Results-MBF Bioscience, CAST system (Olympus), Invitrogen

[The branding has been removed.](#)

-Figure 2 legend-Adipogel

[The branding has been removed.](#)

•JoVE reference format requires that DOIs are included, when available, for all references listed in the article. This is helpful for readers to locate the included references and obtain more information. Please note that often DOIs are not listed with PubMed abstracts and as such, may not be properly included when citing directly from PubMed. In these cases, please manually include DOIs in reference information.

[DOIs have been included for all references.](#)

Reviewer #2:

1. The authors have shown vascularity of a tissue constructs at 4 weeks post-implantation in figure 3 and transplanted cells in figure 4. However, it needs to clarify if there is any significant difference in the vascular number or even more transplanted tissue regenerated within this chamber model when compared with none (no chamber or no vascular pedicle). I suggest more statements or control data would be helpful as a supplementary for the representative results.

The chamber creates an ischemic environment that stimulates angiogenic sprouting from the implanted vessels. Cells are attracted to the chamber and tissue spontaneously grows until the space fills or encapsulation occurs. From our experience, no tissue grows if no vessel is implanted or the vascular pedicle thromboses. Equally if the vessel pedicle is simply implanted into normal tissue and not inside the protected space of the chamber, angiogenic sprouting ceases along the same timeline as a normal wound and no new tissue will accumulate around the pedicle.

We have added this to the Introduction (page 3) and Discussion (page 9).

2. The authors declared that a human-specific Ku-80 antibody was used to identify human IPS cells in Figure 4 (B). How to avoid the rejections in a rat model as it is not an immunocompromised model? Authors should present the particular timepoint for harvesting and give the descriptions.

Human iPS cells were implanted inside the tissue engineering chambers in immunocompromized rats and the tissues were harvested at 28 days post-implantation. This has been added to the manuscript (Please see page 8 and Figure 4 legend).

Reviewer #3:

1. Have the authors proven definitively that "angiogenic sprouting occurs from the arteriovenous vessels"? The authors should be clear about whether this is true and how it was determined.

We have previously conducted a time course experiment and showed that angiogenic sprouting first occurred from the femoral vein at 3-7 days followed by sprouting from the artery at day 10.

Although blood vessel sprouting was not evident from the vein graft in the first 14 days, it occasionally occurred at slightly later time points. Capillary sprouts derived from the artery and vein were found to develop toward the vein graft and coursed along its abluminal surface and out into the chamber space.

[Lokmic Z, et al. An arteriovenous loop in a protected space generates a permanent, highly vascular, tissue-engineered construct. FASEB J. 2007. **21**:511-22.]

This reference has now been added to the Introduction section (page 3, paragraph 4).

2. The authors should be clear that these procedures take a reasonable level of surgical skill, particularly the AV loop. I am not sure all basic researchers could pull it off without training even with this protocol.

This has been clarified in the Discussion (Please see page 9).

Reviewer #4:

1) While the vascularization aspect of this project is obvious, what is lacking is commentary on the subsequent steps needed to make this a clinically relevant platform. It is not clear to me whether the tissue would have to be harvested and subsequently re-transplanted at the injury/disease site, or whether the in-vivo vascularization would take place at the desired site and then chamber subsequently removed (or both depending on the case) In the case of the former, is harvesting possible without tissue morbidity?

Experimentally, the chambers have been typically sited in the groin because of the availability of large vessels for anastomosis in small animals. Subsequent transplantation to a more desirable site has been performed to confirm proof of principle (Tee R, Morrison WA, et al. Tissue Eng Part A. 2012. 18:1992-9) (Dolderer JH, et al. Plast Reconstr Surg. 2011. 127:2283-92). However, in the human clinical scenario, it would be preferable and much more feasible to create the chamber at the definitive site for reconstruction such as the breast, etc. We have done this in the first human trial of

breast tissue engineering (Neopac) (presented at the International Breast Cancer Congress, Sydney 2012, and the manuscript is currently under reviewed by Annals of Surgery). We have added this to the Introduction (page 3).

2) While I can imagine this technique leading to better vascularization and tissue integration, no controls were used to compare to current approaches.

From our experience, no tissue grows if no vessel is implanted or the vascular pedicle thromboses. Equally if the vessel pedicle is simply implanted into normal tissue and not inside the protected space of the chamber, angiogenic sprouting ceases along the same timeline as a normal wound and no new tissue will accumulate around the pedicle.

We have added this to the Introduction (page 3) and Discussion (page 9).



[Click here to access/download](#)

Supplemental File (as requested by JoVE)
Wolters Kluwer, Figure reprint info.pdf

