# **Journal of Visualized Experiments**

# Strain sensing based on multiscale composite materials reinforced with graphene nanoplatelets --Manuscript Draft--

Manuscript Number:	JoVE54512R3
Full Title:	Strain sensing based on multiscale composite materials reinforced with graphene nanoplatelets
Article Type:	Invited Methods Article - JoVE Produced Video
Keywords:	Sensors; graphene nanoplatelets; composites; structural health monitoring; smart materials; biomechanic
Manuscript Classifications:	92.24.14: glass fiber reinforced plastics; 92.24.23: polymer matrix composites; 92.24.24: reinforcing fibers (composite materials); 92.24.29: testing of materials (composite materials); 92.24.6: epoxy matrix composites
Corresponding Author:	Rocio Moriche Universidad Rey Juan Carlos Móstoles, Madrid SPAIN
Corresponding Author Secondary Information:	
Corresponding Author E-Mail:	rocio.moriche@urjc.es
Corresponding Author's Institution:	Universidad Rey Juan Carlos
Corresponding Author's Secondary Institution:	
First Author:	Rocio Moriche
First Author Secondary Information:	
Other Authors:	Silvia G Prolongo
	María Sánchez
	Alberto Jiménez-Suárez
	Mónica Campo
	Alejandro Ureña
Order of Authors Secondary Information:	
Abstract:	The electrical response of NH2 functionalized graphene nanoplatelets composite materials under strain was studied. Two different manufacturing methods are proposed to create the electrical network in this work: (a) the incorporation of the nanoplatelets into the epoxy matrix and (b) the coating of the glass fabric with a sizing filled with the same nanoplatelets. Both types of multiscale composite materials, with an in-plane electrical conductivity of ~10 3 S/m, showed an exponential growth of the electrical resistance as the strain increases due to distancing between adjacent functionalized graphene nanoplatelets and contact loss between overlying ones. The sensitivity of the materials analyzed during this research, using the described procedures, has shown to be higher than commercially available strain gauges. The proposed procedures for self-sensing of the structural composite material would facilitate the structural health monitoring of components in difficult to access emplacements such as offshore wind power farms. Although the sensitivity of the multiscale composite materials was considerably higher than the sensitivity of metallic foils used as strain gauges, the value reached with NH2 functionalized graphene nanoplatelets coated fabrics was nearly an order of magnitude superior. This result elucidated their potential to be used as smart fabrics to monitor human movements such as bending of fingers or knees. By using the proposed method, the smart fabric could immediately detect the bending and

	recover instantly. This fact permits precisely monitoring of the time of bending as well as the bending degree.
Author Comments:	The patent process is delayed and for that reason we would need this article to be published after the mentioned process.
Additional Information:	
Question	Response
If this article needs to be "in-press" by a	

# TITLE:

Strain sensing based on multiscale composite materials reinforced with graphene nanoplatelets

### **AUTHORS:**

Moriche, Rocío Materials Science and Engineering Area University Rey Juan Carlos Móstoles, Spain rocio.moriche@urjc.es

Prolongo, Silvia G.
Materials Science and Engineering Area
University Rey Juan Carlos
Móstoles, Spain
silvia.gonzalez@urjc.es

Sánchez, María Materials Science and Engineering Area University Rey Juan Carlos Móstoles, Spain maria.sanchez@urjc.es

Jiménez-Suárez, Alberto
Materials Science and Engineering Area
University Rey Juan Carlos
Móstoles, Spain
alberto.jimenez.suarez@urjc.es

Campo, Mónica
Materials Science and Engineering Area
University Rey Juan Carlos
Móstoles, Spain
monica.campo@urjc.es

Ureña, Alejandro Materials Science and Engineering Area University Rey Juan Carlos Móstoles, Spain alejandro.urena@urjc.es

### **CORRESPONDING AUTHOR:**

Rocío Moriche

# **KEYWORDS:**

Sensors, graphene nanoplatelets, composites, structural health monitoring, smart materials, biomechanic

### **SHORT ABSTRACT:**

The integration of conductive nanoparticles, such as graphene nanoplatelets, into glass fiber composite materials creates an intrinsic electrical network susceptible to strain. In this work, different methods to obtain strain sensors based on the addition of graphene nanoplatelets into the epoxy matrix or as a coating on glass fabrics are proposed.

### LONG ABSTRACT:

The electrical response of NH<sub>2</sub>-functionalized graphene nanoplatelets composite materials under strain was studied. Two different manufacturing methods are proposed to create the electrical network in this work: (a) the incorporation of the nanoplatelets into the epoxy matrix and (b) the coating of the glass fabric with a sizing filled with the same nanoplatelets. Both types of multiscale composite materials, with an in-plane electrical conductivity of ~10<sup>-3</sup> S/m, showed an exponential growth of the electrical resistance as the strain increases due to distancing between adjacent functionalized graphene nanoplatelets and contact loss between overlying ones. The sensitivity of the materials analyzed during this research, using the described procedures, has been shown to be higher than commercially available strain gauges. The proposed procedures for self-sensing of the structural composite material would facilitate the structural health monitoring of components in difficult to access emplacements such as offshore wind power farms. Although the sensitivity of the multiscale composite materials was considerably higher than the sensitivity of metallic foils used as strain gauges, the value reached with NH<sub>2</sub>-functionalized graphene nanoplatelets coated fabrics was nearly an order of magnitude superior. This result elucidated their potential to be used as smart fabrics to monitor human movements such as bending of fingers or knees. By using the proposed method, the smart fabric could immediately detect the bending and recover instantly. This fact permits precise monitoring of the time of bending as well as the degree of bending.

### **INTRODUCTION:**

Structural health monitoring (SHM) has become increasingly important because of the need to know the remaining life of structures<sup>1-3</sup>. Nowadays, difficult to access locations, such as offshore wind plants, lead to higher risks in maintenance operations, as well as greater costs<sup>2-4</sup>. Self-sensing materials constitute one of the possibilities in the field of SHM due to their ability of self-monitoring strain and damage<sup>5</sup>.

In the case of wind turbines, blades are generally manufactured in glass fiber/epoxy composite materials, which are electrically insulators. In order to confer self-sensing properties to this composite material, an intrinsic electrical network susceptible to strain and damage needs to be created. During the last few years, the incorporation of conductive nanoparticles such as silver nanowires<sup>6,7</sup>, carbon nanotubes (CNTs)<sup>8-10</sup>, and graphene nanoplatelets (GNPs)<sup>11-13</sup> has been studied to create this electrical network. These nanoparticles can be incorporated into the system as filler into the polymer matrix or by coating the glass fiber fabric<sup>14</sup>. These materials can be also applied to other industrial fields, i.e. aerospace, automotive and civil engineering<sup>5</sup>,

and coated fabrics can be used as smart materials in biomechanical applications<sup>7,15</sup>.

Piezoresistivity of these sensors is achieved by three different contributions. The first contribution is the intrinsic piezoresistivity of the nanoparticles; a strain of the structure changes the electrical conductivity of the nanoparticles. However, the main contributions are changes in tunnel electrical resistance, due to modifications in distances between adjacent nanoparticles, and electrical contact resistance, because of variations in the contact area between overlying ones<sup>9</sup>. This piezoresistivity is higher when 2D nanoparticles are used as a nanofiller compared to 1D nanoparticles because the electrical network presents a higher susceptibility to geometrical changes and discontinuities, usually one order of magnitude superior<sup>16</sup>.

Due to the 2D atomic character<sup>17</sup> and the high electrical conductivity<sup>18,19</sup>, graphene nanoplatelets have been selected in this work as the nano-reinforcer of multiscale composite materials in order to obtain self-sensors with enhanced sensitivity. Two different ways to incorporate the GNPs into the composite material are studied in order to elucidate possible differences in sensing mechanisms and sensitivity.

#### PROTOCOL:

- 1. Preparation of the functionalized graphene nanoplatelet filled epoxy for multiscale composite materials.
- 1.1) Disperse functionalized graphene nanoplatelets (f-GNPs) into the epoxy resin.
- 1.1.1) Weigh 24.00 g of f-GNPs to achieve a 12 wt% of the final nanocomposite material inside a ductless fume hood.
- 1.1.2) Add 143.09 g of the bisphenol A diglycidyl ether (DGEBA) monomer and manually mix it to achieve homogeneity.
- 1.1.3) Disperse the f-GNPs into the monomer by a two-step method, which combines probe sonication and calendering processes<sup>20</sup>.
- 1.1.3.1) Sonicate the mixture at 50% of the amplitude and a cycle of 0.5 sec for 45 min.
- 1.1.3.2) Apply 3 cycles of calendering using a roller gap of 5 μm and increasing roller speed at each cycle: 250 rpm, 300 rpm and 350 rpm.
- 1.1.3.3) Weigh the mixture of f-GNP/monomer after completing dispersion.
- 1.1.4) Degas the f-GNP/monomer mixture under vacuum and magnetic stirring at 80 °C for 15 min.
- 1.1.5) Weigh and add the hardener in a weight ratio of 100:23 (monomer:hardener) and manually stir until achieving homogeneity.

- 2. Coating of the glass fabric with functionalized graphene nanoplatelet filled sizing (suspension) for multiscale composite materials.
- 2.1) Disperse functionalized graphene nanoplatelets into the sizing.
- 2.1.1) Weigh 7.5 g of f-GNPs, the quantity needed to achieve a 5 wt%, into 142.5 g of solvent (sizing/distilled water specified in 2.1.2) inside a ductless fume hood.
- 2.1.2) Prepare the mixture of the f-GNPs and the sizing diluted with distilled water (1:1 wt) inside the ductless fume hood. Once the distilled water has been added, perform the work outside the ductless fume hood.
- 2.1.3) Disperse the GNPs by probe sonication for 45 min at 50% amplitude and a cycle of 0.5 sec.
- 2.2) Coat the glass fabric with the f-GNP filled sizing.
- 2.2.1) With scissors suited for fabric cutting, cut 14 layers of glass fabric with dimensions of 120 x 120 mm<sup>2</sup> and then coat them with the mixture of f-GNPs and sizing (2.1.3) by dip coating (one immersion) using a dip coater in the f-GNP filled sizing.
- 2.2.2) Dry the f-GNP coated glass fabric in a vacuum oven at 150 °C for 24 hr as indicated in the technical sheets provided by the manufacturer.
- 3. Manufacturing of multiscale composite materials.
- 3.1) Manufacture f-GNP/epoxy composite materials.
- 3.1.1) After degassing the mixture, keep the f-GNP filled epoxy resin under magnetic stirring at 80 °C for all the manufacturing process.
- 3.1.2) Place the 14 layers of the glass fabric into an oven at 80 °C.
- 3.1.3) Alternatively, place a layer of the f-GNP filled epoxy and a layer of glass fiber fabric (14 layers) sequentially by hand on a metallic plate using a de-airing roller after placing each glass fabric layers.
- 3.1.3.1) Use scissors to cut and place the anti-adherent polymer film (120 x 120 mm²) on a steel plate.
- 3.1.3.2) Apply a layer of the f-GNP/epoxy mixture on the anti-adherent polymer film with a brush. Place a layer of glass fiber fabric. Note the importance of covering the area of the f-GNP/epoxy region and alignment of the different fabric layers. Remove the air and compact the plies by using a de-airing roller.
- 3.1.3.3) Repeat step 3.1.3.2 until completing all of the layers of the laminate.
- 3.1.3.4) Apply a final layer of the f-GNP/epoxy mixture with brush and cover the laminate with

another layer of anti-adherent polymer film.

- 3.1.4) Once all the fabric layers have been piled up, cure the laminate in a hot plate press at 140 °C for 8 hr with increasing pressure up to 6 bars.
- 3.1.5) Extract the cured laminate from the hot plate press.
- 3.2) Manufacture f-GNP/glass fiber composite materials by vacuum assisted resin infusion molding (VARIM).
- 3.2.1) Prepare the metallic plate where VARIM is going to be carried out.
- 3.2.1.1) Clean the steel plate surface with acetone.
- 3.2.1.2) Place anti-adherent polymer film onto the steel plate.
- 3.2.2) Place the sequence of f-GNP coated glass fabric (14 layers with dimensions 120 x 120 mm<sup>2</sup>) onto the plate. Ensure that the layers of fabric are aligned visually and by touch.
- 3.2.3) Seal the vacuum bag with sealant tape for the VARIM process and pre-heat the system at 80 °C in an oven.
- 3.2.4) Degas the DGEBA monomer under vacuum and magnetic stirring at 80 °C for 15 min. Add the hardener in a weight ratio of 100:23 (monomer:hardener) and stir until achieving homogeneity.
- 3.2.5) Add the epoxy resin at 80 °C with a vacuum pump connected to the vacuum bag with a polymeric tube until the glass fabric pile is totally filled by the epoxy resin and cure the laminate in an oven at 140 °C for 8 hr.
- 3.2.6) Extract the cured laminate from the oven and remove the vacuum bag and auxiliary material.

# 4. Preparation of the samples for strain sensors tests.

4.1) Machine samples (Computer Numerical Control - CNC milling machine) of multiscale laminates to the required dimension for flexural tests following the ASTM D790-02<sup>21</sup> and cut glass fabric bands 10 mm in width in order to study the strain sensitivity of the f-GNP coated fabric.

Note: Samples are fixed onto the machining table with adhesive tape and machined using the following parameters: feed speed of 500 mm/min, idle speed of 5000 min<sup>-1</sup> and depth steps of 0.1 mm.

4.2) Carefully clean the surface of the machined samples with acetone to eliminate dust.

4.3) Paint lines of silver (acrylic conductive paint) on the surface of the materials distanced 20 mm apart to minimize the electrical contact resistance and adhere copper wires to the wet silver lines as electrodes to facilitate the measurement of the electrical resistance during the tests.

Note: Electrical contacts are located on both surfaces: compression surfaces and tensile subjected surfaces.

- 4.4) Once the silver paint is dry, fix the electrical contacts with hot melt adhesive to avoid electrical contact detachment.
- 5. Testing the strain sensor.
- 5.1) Analyze the electrical behavior of sensors under flexural loads (three-point bending test).
- 5.1.1) Measure the specimen's width and thickness with a caliper.
- 5.1.2) Set the specimen in the mechanical test machine with the flexural test configuration.
- 5.1.3) Set the test speed (controlled by strain) to 1 mm/min and the start position that defines the initial length of the specimen.
- 5.1.4) Connect the electrical contacts to the multimeter. Measure the electrical resistance between each two adjacent electrical contacts as it is specified in Figure 1.

[Place Figure 1 here]

- 5.1.5) Run flexural test and monitor the electrical resistance simultaneously in order to study variations due to the induced strain in the specimen.
- 5.1.6) Repeat all steps for at least 3 specimens of f-GNP/epoxy and f-GNP/glass fiber composite materials to confirm the electrical behavior of the composite materials.
- 5.2) Analyze f-GNP/glass fabric as strain sensors of human movements.
- 5.2.1) Monitor finger bending.
- 5.2.1.1) Attach glass fabric bands to each of the fingers of a nitrile glove with hot melt adhesive on the internal surface as indicated in Figure 2.

[Place Figure 2 here]

- 5.2.1.2) Repeat step 5.1.4 but measure the electrical resistance of contacts placed on a same finger.
- 5.2.1.3) Start the sequence of finger bending to monitor and measure the electrical resistance while fingers are bending. The sequence of finger bending in this particular case is: (1) thumb,

(2) index, (3) middle finger, (4) ring finger, (5) all the fingers simultaneously and (6) sequence of bending (higher speed): (1), (2), (3), (4), (4), (3), (2) and (1).

### **REPRESENTATIVE RESULTS:**

The protocol to obtain two different materials has been described in the procedure. The difference is in the way the nanoreinforcement is incorporated in the composite material to achieve an electrical network that could be used to strain monitoring. The first method consists of the coating of a glass fiber fabric with f-GNP sizing that can be used as a smart fabric (named f-GNP/glass fiber) or as reinforcement of polymer matrix multiscale composite materials (named f-GNP/glass fiber composite material). The other method is the nanoreinforcement of the epoxy matrix of composite materials with f-GNPs (named f-GNP/epoxy composite material) using glass fiber as a continuous reinforcement. The infusion of the resin was carried out by using VARIM because it is one of the most common methods used in the industry, but other methods could be used. An alternative manufacturing method could be resin transfer molding (RTM).

Due to the insulating character of the glass fiber, the incorporation of the f-GNPs following the protocol described above creates an electrical network inside the material that causes an increase of the electrical conductivity up to  $\sim 10^{-3}$  S/m and can be modified by inducing strain. Figure 3 shows representative results of the variation of normalized electrical resistance caused by strain induced during flexural test (three-point bending) in an f-GNP/glass fiber band. The normalized electrical resistance exponentially grows with the increasing strain due to the mechanism of tunnel resistance. When failure occurs, jumps in the normalized electrical resistance can be observed, which are correlated to a drop of load.

# [Place Figure 3 here]

The electrical behavior of the multiscale composite materials, f-GNP/epoxy (Figure 4.a) and f-GNP/glass fiber (Figure 4.b) composite materials, shows some differences with the described above for coated fabrics. When the compression subjected surface is monitored, two regions can be discriminated. At low strain values, the normalized electrical resistance diminishes up to  $\sim 0.010$  and  $\sim 0.015$  mm/mm for f-GNP/epoxy and f-GNP/glass fiber composite materials, respectively. In contrast, at strains higher than the mentioned threshold, the normalized electrical resistance increases with an exponential tendency. In the case of monitoring the tensile subjected surfaces, the normalized electrical resistance augments in both of the systems. The sensitivity shown in all the configurations is in the order of 10 to 40 (per unit). At high strain values, the gauge factor was -1.4 and 7.8 (per unit) for the compression subjected surface of f-GNP/epoxy and f-GNP/glass fiber composite materials and on the order of 17 and 41 (per unit) for the tensile subjected surface of f-GNP/epoxy and f-GNP/glass fiber composite materials, respectively.

# [Place Figure 4 here]

As an example of the application of f-GNP coated glass fiber fabrics, Figure 5.a shows the

monitoring of finger bending. Each finger and the electrical response of the coupled glass fiber band are distinguished by a different color to make it understandable. The first sequence corresponds to bending of the thumb (Figure 5.b), the index (Figure 5.c), the middle finger (Figure 5.d) and the ring finger (Figure 5.e). The normalized electrical resistance diminishes when the related finger bends and recovers the initial value when the finger recuperates the initial position. The second sequence of movements includes simultaneous bending of the four fingers and the third, a sequence of faster movements showing the instantaneous response and recovery of the normalized electrical resistance. This could be used to remotely monitor the evolution of bone diseases or count footsteps during running and in physical therapy to evaluate the recuperation.

[Place Figure 5 here]

# Figure 1: Electrical contacts set up in flexural tests of multiscale composite materials. Copper electrodes are attached on the surface of composite materials by using lines of silver paint (in gray) in order to minimize the electrical contact resistance.

# Figure 2: Location of f-GNP/glass fiber bands on the internal surface of the fingers of a nitrile glove to monitor fingers bending.

Once the glass fiber fabric has been coated and dried, bands 10 mm in width are cut and attached on the different fingers of a glove with the aim of monitoring the finger bending and corroborate the viability of the protocol described above.

# Figure 3: Example of strain monitoring of f-GNP/glass fiber bands under flexural test.

The figure represents the variation of the normalized electrical resistance ( $\Delta R/R_o$ , R: instantaneous electrical resistance and  $R_o$ : initial electrical resistance) and force (F) versus beam depth during flexural test. The normalized electrical resistance increases with the strain. This phenomenon occurs because tensile forces cause distancing between the nanoparticles and loss of contact of overlying GNPs. The exponential tendency observed during loading of sample is due to a major contribution of changes induced in tunnel resistance. Tunnel resistance varies exponentially with the distance between nanoparticles when they are at a distance in the order of  $10 \text{ nm}^{12,21}$ . For that reason when distances between adjacent GNPs increase, the electrical resistance also increases with an exponential tendency. This effect is dominant when the GNP content is close to the percolation threshold<sup>23</sup> but its contribution diminishes at higher GNP content<sup>24,25</sup>. During failure, the electrical behavior changes and jumps are observed in the electrical response. These jumps can be correlated to drops in load provoked by the fiber breakage, which constitutes discontinuities in the electrical network. These discontinuities act as obstacles causing the increment of the electrical resistance of the GNP/glass fiber bands.

# Figure 4: Example of strain monitoring of (a) f-GNP/epoxy and (b) f-GNP/glass fiber composite materials under flexural test.

The figure represents the variation of the normalized electrical resistance ( $\Delta R/R_o$ , R: instantaneous electrical resistance and  $R_o$ : initial electrical resistance) and stress ( $\sigma$ ) versus strain ( $\varepsilon$ ) during flexural test. In this case, the electrical contacts are place on the compression

subjected (blue line) and the tensile subjected (red line) obtaining different electrical behavior. Two different graphs are included, which correspond to the two routes proposed in the protocol: (a) f-GNP/epoxy and (b) f-GNP/glass fiber composite materials showing their viability.

# Figure 5: Example of strain monitoring of fingers bending by coupling of f-GNP/glass fiber bands on a nitrile glove.

(a) Electrical response of the sensor during 3 sequences of fingers bending and (b-e) first sequence of fingers bending. Following the protocol explained in the present work, monitoring of fingers bending capability was possible.  $\Delta R/R_o$ , R: instantaneous electrical resistance and  $R_o$ : initial electrical resistance

### **DISCUSSION:**

Self-sensor properties of nanoreinforced composite materials are due to the electrical network created by the f-GNPs through the epoxy matrix and along the glass fibers, which is modified when strain is induced. Dispersion of the f-GNPs is then crucial because the electrical behavior of the sensors strongly depends on the microstructure of the material. Here, we present an optimized procedure to achieve a good dispersion of the GNPs into the epoxy matrix and to avoid wrinkling of the nanoparticles, which causes the detriment of the electrical conductivity. The critical steps are the sonication (operating parameters) and calendering processes (roller gap and speed). These steps strongly influence the mechanical<sup>26</sup>, thermal<sup>27</sup> and electrical<sup>28</sup> properties of the multiscale composite materials. Usually, dispersion of nanoreinforcement is carried out into solvent that need to be evaporated before curing of nanocomposites<sup>29,30</sup>. In the process proposed in this work, the use of solvents is avoided making it more environmentally friendly. Another step of the protocol, which also strongly influences the microstructure of composite materials and, therefore, the electrical behavior of the sensors, is the manufacturing procedure for multiscale composite materials. During manufacturing of these materials, even if good dispersion of the nanoparticles into the epoxy matrix is initially achieved, f-GNP distribution can be strongly affected by filtering phenomena. Additionally, degassing of the epoxy matrix is essential in order to maintain mechanical properties of the multiscale composite materials, which becomes more difficult when the matrix is filled with the GNPs because of a major viscosity.

Electrical contact placement needs to be carried out carefully in order to assure that the electrical contact resistance is as low as possible. For this, it is important to ensure that surfaces are completely cleaned before applying the silver paint to fix copper electrodes. Furthermore, before applying the hot melt adhesive, the silver paint needs to dry. If not, the solvent evaporates and provokes the appearance of bubbles, increasing the electrical contact resistance. One of the advantages of positioning electrical contacts on the surface of the material, in contrast to the electrodes located inside the sample<sup>31</sup>, is that it is non-intrusive and is not a detriment to any mechanical properties. During monitoring tests, the electrical contacts can detach from the surface of samples. Consequently, proper fixing is essential to ensure that the electrical signal that is going to be registered corresponds only to the intrinsic electrical response of the material.

The protocol described above can be applied or modified with different nanofillers such as carbon nanotubes or other conductive nanoparticles that also lead to electrically conductive composites with self-sensing properties<sup>32,33</sup>. The monitoring protocol can be extrapolated to other test configurations for damage detection and quantification. One limitation of the system used for the electrical contacts is that their location on samples surfaces restricts the volume of material where the electrical resistance is analyzed. By designing another system involving volumetric measurements, internal damage could be detected and quantified but in this case, mechanical properties could be compromised. The protocol could be useful in biomechanical applications to remotely monitor the evolution of bone diseases or count footsteps during running or in physical therapy to evaluate the recuperation process.

### **ACKNOWLEDGMENTS:**

The authors would like to acknowledge the Ministerio de Economía y Competitividad of Spain Government (Project MAT2013-46695-C3-1-R) and Comunidad de Madrid Government (P2013/MIT-2862).

### **DISCLOSURES:**

The authors have nothing to disclose.

# **REFERENCES**


- 1. Farrar, C.R., Worden, K. An introduction to structural health monitoring. *Philos Trans Math Phys Eng Sci.* **365**, 303–15, DOI: 10.1098/rsta.2006.1928 (2007).
- 2. Lorenzo, E.D., *et al.* Structural Health Monitoring challenges on the 10-MW offshore wind turbine model. *J Phys Conf Ser*, **628**, 012081, DOI:10.1088/1742-6596/628/1/012081 (2015).
- 3. Braga, D.F.O.O., *et al.* Advanced design for lightweight structures: Review and prospects. *Prog Aerosp Sci*, **69**, 29–39, DOI:10.1016/j.paerosci.2014.03.003 (2014).
- 4. García Márquez, F.P., Tobias, A.M., Pinar Pérez, J.M., Papaelias, M. Condition monitoring of wind turbines: Techniques and methods. *Renew Energy*, **46**, 169–78, DOI:10.1016/j.renene.2012.03.003 (2012).
- 5. Chung, D.D.L. Self-monitoring structural materials. *Mater Sci Eng R Reports*, **22**, 57–78, DOI:10.1016/S0927-796X(97)00021-1 (1998).
- 6. Kandare, E., et al. Improving the through-thickness thermal and electrical conductivity of carbon fibre/epoxy laminates by exploiting synergy between graphene and silver nanoinclusions. *Compos Part A Appl Sci Manuf*, **69**, 72–82, DOI:10.1016/j.compositesa.2014.10.024 (2015).
- 7. Amjadi, M., Pichitpajongkit, A., Lee, S., Ryu, S., Park, I. Highly stretchable and sensitive strain sensor based on silver nanowire–elastomer nanocomposite. *ACS Nano*, **8**, 5154–63, DOI: 10.1021/nn501204t (2014).
- 8. Alamusi, H.N., Fukunaga, H., Atobe, S., Liu, Y., Li, J. Piezoresistive strain sensors made from carbon nanotubes based polymer nanocomposites. *Sensors*, **11**, 10691–723, DOI:10.3390/s111110691 (2014).
- 9. Njuguna, M.K.K., Yan, C., Hu, N., Bell, J.M.M., Yarlagadda, P.K.D.V. Sandwiched carbon nanotube film as strain sensor. *Compos Part B Eng*, **43**, 2711–7,


- DOI:10.1016/j.compositesb.2012.04.022 (2012).
- 10. Liu, Y., Rajadas, A., Chattopadhyay, A. A biomimetic structural health monitoring approach using carbon nanotubes. *JOM*, **64**, 802–7, DOI: 10.1007/s11837-012-0357-6 (2012).
- 11. Eswaraiah, V., Balasubramaniam, K., Ramaprabhu, S. Functionalized graphene reinforced thermoplastic nanocomposites as strain sensors in structural health monitoring. *J Mater Chem*, **21**, 12626–8, DOI: 10.1039/C1JM12302E (2011).
- 12. Chiacchiarelli, L.M., *et al.* The role of irreversible and reversible phenomena in the piezoresistive behavior of graphene epoxy nanocomposites applied to structural health monitoring. *Compos Sci Technol*, **80**, 73–9, DOI:10.1016/j.compscitech.2013.03.009 (2013).
- 13. Le, J., Du, H., Dai, S. Use of 2D Graphene Nanoplatelets (GNP) in cement composites for structural health evaluation. *Compos Part B*, **67**, 555–63, DOI:10.1016/j.compositesb.2014.08.005 (2014).
- 14. Ren, X., Burton, J., Seidel, G.D., Lafdi, K. Computational multiscale modeling and characterization of piezoresistivity in fuzzy fiber reinforced polymer composites. *Int J Solids Struct*, **54**, 121–34, DOI:10.1016/j.ijsolstr.2014.10.034 (2015).
- 15. Park, M., Park, J., Jeong, U. Design of conductive composite elastomers for stretchable electronics. *Nano Today*, **9**, 244–60, DOI:10.1016/j.nantod.2014.04.009 (2014).
- 16. Kim, Y-J., *et al.* Preparation of piezoresistive nano smart hybrid material based on graphene. *Curr Appl Phys*, **11**, S350–2, DOI:10.1016/j.cap.2010.11.022 (2011).
- 17. Sadeghi, M.M., Pettes, M.T., Shi, L. Thermal transport in graphene. *Solid State Commun*, **152**, 1321–30, DOI:10.1016/j.ssc.2012.04.022 (2012).
- 18. Potts, J.R., Dreyer, D.R., Bielawski, C.W., Ruoff, R.S. Graphene-based polymer nanocomposites. *Polymer*, **52**, 5–25, DOI:10.1016/j.polymer.2010.11.042 (2011).
- 19. Zaman, I., et al. A facile approach to chemically modified graphene and its polymer nanocomposites. *Adv Funct Mater*, **22**, 2735–43, DOI: 10.1002/adfm.201103041 (2012).
- 20. Moriche, R., *et al.* Morphological changes on graphene nanoplatelets induced during dispersion into an epoxy resin by different methods. *Compos Part B Eng*, **72**, 199–205, DOI:10.1016/j.compositesb.2014.12.012 (2015).
- 21. ASTM D790-02. Standard Test Methods for Flexural Properties of Unreinforced and Reinforced Plastics and Electrical Insulating Materials.
- 22. Gong, S., Zhu, Z.H., Meguid, S.A. Carbon nanotube agglomeration effect on piezoresistivity of polymer nanocomposites. *Polymer*, **55**, 5488–99, DOI:10.1016/j.polymer.2014.08.054 (2014).
- 23. Zhao, J., et al. Ultra-sensitive strain sensors based on piezoresistive nanographene films. *Appl Phys Lett,* **101**, 063112, DOI:10.1063/1.4742331 (2012).
- 24. Galpaya, D., *et al.* Recent advances in fabrication and characterization of graphene-polymer nanocomposites. *Graphene*, **1**, 30–49, DOI:10.4236/graphene.2012.12005 (2012).
- 25. Kanoun, O., et al. Flexible Carbon Nanotube Films for High Performance Strain Sensors. Sensors, 14, 10042–71, DOI:10.3390/s140610042 (2014).
- 26. Zaman, I., et al. Epoxy/graphene platelets nanocomposites with two leves of interface strength. *Polymer*, 52, 1603-1611, DOI: 10.1016/j.polymer.2011.02.003 (2011).


- 27. Chu, K., Li, W.S., Dong, H. Role of graphene waviness on the thermal conductivity of graphene composites. *Appl Phys A*, 111, 221-225, DOI: 10.1007/s00339-012-7497-y (2013).
- 28. Monti, M., et al. Morphology and electrical properties of graphene-epoxy nanocomposites obtained by different solvent assisted processing methods. *Compos Part A*, **46**, 166-172, DOI: 10.1016/j.compositesa.2012.11.005 (2013).
- 29. Moazzami Gudarzi, M., Sharif, F. Enhancement of dispersion and bonding of graphene-polymer through wet transfer of functionalized graphene oxide. *Express Polym Lett*, **6**, 1017-1031, DOI: 10.3144/expresspolymlett.2012.107 (2013).
- 30. Fan, H., *et al.* Fabrication, mechanical properties and biocompatibility of graphene-reinforced chitosan composites. Biomacromolecules, **11**, 2345-2351, DOI: 10.1021/bm100470q (2010).
- 31. Teomete, E. Transverse strain sensitivity of steel fiber reinforced cement composites tested by compression and split tensile tests. *Constr Build Mater*, 55, 136-145, DOI: 10.1016/j.conbuildmat.2014.01.016 (2014).
- 32. Nauman, S., Cristian, I., Koncar, V. Simultaneous Application of Fibrous Piezoresistive Sensors. *Sensors*, **11**, 9478–98, DOI:10.3390/s111009478 (2011).
- 33. Han, B., Ding, S., Yu, X. Intrinsic self-sensing concrete and structures: A review. *Measurement*, **59**, 110–28, DOI:10.1016/j.measurement.2014.09.048 (2015).

















Name of Reagent/ Equipment	Company	Catalog Number	Comments/Description	
Graphene Nanoplatelets	XGScience	M25	NA	
Enovy rocin	Huntsman	Araldite LY556	NA	
Epoxy resin	HulltSillali	XB3473	NA	
Probe sonication	Hielscher	UP400S	NA	
Three roll mill	Exakt	Exakt 80E (Exakt GmbH)	NA	
Glass fiber fabric	Hexcel	HexForce ® 01031 1000 TF970 E UD 4H	NA	
Hot plate press	Fontijne	Fontijne LabEcon300	NA	
Sizing	Nanocyl	$Sizicyl^{TM}$	NA	
Multimeter	Alava Ingenieros	Agilent 34410A	NA	
Strain Gauges	Vishay	Micro-Measurement (MM®) CEA-06-187UW-120	NA	
Mechanical tests machine	Zwick	Zwick/Roell 100 kN	NA	
Conductive silver paint	Monocomp	16062 – PELCO® Conductive Silver Paint	NA	



1 Alewife Center #200 Cambridge, MA 02140 tel. 617.945.9051 www.jove.com

# ARTICLE AND VIDEO LICENSE AGREEMENT

Title of Article: Author(s):					MATERIAS FOR STRAIN SE AREZ, M. LAMPO, A LIKER	<u>-</u>
	box): The Autho	parameters and a second		processor and a second	available (as described	at
Item 2 (check one box	<b>()</b> :					
The Auth	or her duties as a	States governr United States ates governme	ment employee government en ent employee bu	and the Mat nployee. It the Materia	erials were prepared in a	

# **ARTICLE AND VIDEO LICENSE AGREEMENT**

- 1. Defined Terms. As used in this Article and Video License Agreement, the following terms shall have the following meanings: "Agreement" means this Article and Video License Agreement; "Article" means the article specified on the last page of this Agreement, including any associated materials such as texts, figures, tables, artwork, abstracts, or summaries contained therein; "Author" means the author who is a signatory to this Agreement; "Collective Work" means a work, such as a periodical issue, anthology or encyclopedia, in which the Materials in their entirety in unmodified form, along with a number of other contributions, constituting separate and independent works in themselves, are assembled into a collective whole; "CRC License" means the Creative Commons Attribution-Non Commercial-No Derivs 3.0 Unported Agreement, the terms and conditions of which can be found http://creativecommons.org/licenses/by-ncnd/3.0/legalcode; "Derivative Work" means a work based upon the Materials or upon the Materials and other preexisting works, such as a translation, musical arrangement, dramatization, fictionalization, motion picture version, sound recording, art reproduction, abridgment, condensation, or any other form in which the Materials may be recast, transformed, or adapted; "Institution" means the institution, listed on the last page of this Agreement, by which the Author was employed at the time of the creation of the Materials; "JoVE" means MyJove Corporation, a Massachusetts corporation and the publisher of The Journal of Visualized Experiments; "Materials" means the Article and / or the Video; "Parties" means the Author and JoVE; "Video" means any video(s) made by the Author, alone or in conjunction with any other parties, or by JoVE or its affiliates or agents, individually or in collaboration with the Author or any other parties, incorporating all or any portion of the Article, and in which the Author may or may not appear.
- 2. <u>Background</u>. The Author, who is the author of the Article, in order to ensure the dissemination and protection of the Article, desires to have the JoVE publish the Article and create and transmit videos based on the Article. In furtherance of such goals, the Parties desire to memorialize in this Agreement the respective rights of each Party in and to the Article and the Video.
- 3. Grant of Rights in Article. In consideration of JoVE agreeing to publish the Article, the Author hereby grants to JoVE, subject to Sections 4 and 7 below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Article in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Article into other languages, create adaptations, summaries or extracts of the Article or other Derivative Works (including, without limitation, the Video) or Collective Works based on all or any portion of the Article and exercise all of the rights set forth in (a) above in such translations, adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. If the "Open Access" box has been checked in Item 1 above, JoVE and the Author hereby grant to the public all such rights in the Article as provided in, but subject to all limitations and requirements set forth in, the CRC License.



1 Alewife Center #200 Cambridge, MA 02140 tel. 617.945.9051 www.iove.com

# ARTICLE AND VIDEO LICENSE AGREEMENT

- 4. Retention of Rights in Article. Notwithstanding the exclusive license granted to JoVE in Section 3 above, the Author shall, with respect to the Article, retain the non-exclusive right to use all or part of the Article for the non-commercial purpose of giving lectures, presentations or teaching classes, and to post a copy of the Article on the Institution's website or the Author's personal website, in each case provided that a link to the Article on the JoVE website is provided and notice of JoVE's copyright in the Article is included. All non-copyright intellectual property rights in and to the Article, such as patent rights, shall remain with the Author.
- 5. <u>Grant of Rights in Video Standard Access</u>. This **Section 5** applies if the "Standard Access" box has been checked in **Item 1** above or if no box has been checked in **Item 1** above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby acknowledges and agrees that, Subject to **Section 7** below, JoVE is and shall be the sole and exclusive owner of all rights of any nature, including, without limitation, all copyrights, in and to the Video. To the extent that, by law, the Author is deemed, now or at any time in the future, to have any rights of any nature in or to the Video, the Author hereby disclaims all such rights and transfers all such rights to JoVE.
- 6. Grant of Rights in Video Open Access. This Section 6 applies only if the "Open Access" box has been checked in Item 1 above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby grants to JoVE, subject to Section 7 below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Video in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Video into other languages, create adaptations, summaries or extracts of the Video or other Derivative Works or Collective Works based on all or any portion of the Video and exercise all of the rights set forth in (a) above in such translations. adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. For any Video to which this Section 6 is applicable, JoVE and the Author hereby grant to the public all such rights in the Video as provided in, but subject to all limitations and requirements set forth in, the CRC License.
- 7. <u>Government Employees</u>. If the Author is a United States government employee and the Article was prepared in the course of his or her duties as a United States government employee, as indicated in **Item 2** above, and any of the licenses or grants granted by the Author hereunder exceed the scope of the 17 U.S.C. 403, then the rights granted hereunder shall be limited to the maximum rights permitted under such

- statute. In such case, all provisions contained herein that are not in conflict with such statute shall remain in full force and effect, and all provisions contained herein that do so conflict shall be deemed to be amended so as to provide to JoVE the maximum rights permissible within such statute.
- 8. <u>Likeness</u>, <u>Privacy</u>, <u>Personality</u>. The Author hereby grants JoVE the right to use the Author's name, voice, likeness, picture, photograph, image, biography and performance in any way, commercial or otherwise, in connection with the Materials and the sale, promotion and distribution thereof. The Author hereby waives any and all rights he or she may have, relating to his or her appearance in the Video or otherwise relating to the Materials, under all applicable privacy, likeness, personality or similar laws.
- 9. Author Warranties. The Author represents and warrants that the Article is original, that it has not been published, that the copyright interest is owned by the Author (or, if more than one author is listed at the beginning of this Agreement, by such authors collectively) and has not been assigned, licensed, or otherwise transferred to any other party. The Author represents and warrants that the author(s) listed at the top of this Agreement are the only authors of the Materials. If more than one author is listed at the top of this Agreement and if any such author has not entered into a separate Article and Video License Agreement with JoVE relating to the Materials, the Author represents and warrants that the Author has been authorized by each of the other such authors to execute this Agreement on his or her behalf and to bind him or her with respect to the terms of this Agreement as if each of them had been a party hereto as an Author. The Author warrants that the use, reproduction, distribution, public or private performance or display, and/or modification of all or any portion of the Materials does not and will not violate, infringe and/or misappropriate the patent, trademark, intellectual property or other rights of any third party. The Author represents and warrants that it has and will continue to comply with all government, institutional and other regulations, including, without limitation all institutional, laboratory, hospital, ethical, human and animal treatment, privacy, and all other rules, regulations, laws, procedures or guidelines, applicable to the Materials, and that all research involving human and animal subjects has been approved by the Author's relevant institutional review board.
- 10. JoVE Discretion. If the Author requests the assistance of JoVE in producing the Video in the Author's facility, the Author shall ensure that the presence of JoVE employees, agents or independent contractors is in accordance with the relevant regulations of the Author's institution. If more than one author is listed at the beginning of this Agreement, JoVE may, in its sole discretion, elect not take any action with respect to the Article until such time as it has received complete, executed Article and Video License Agreements from each such author. JoVE reserves the right, in its absolute and sole discretion and without giving any reason therefore, to accept or decline any work submitted to JoVE. JoVE and its employees, agents and independent contractors shall have



1 Alewife Center #200 Cambridge, MA 02140 tel. 617.945.9051 www.jove.com

# ARTICLE AND VIDEO LICENSE AGREEMENT

full, unfettered access to the facilities of the Author or of the Author's institution as necessary to make the Video, whether actually published or not. JoVE has sole discretion as to the method of making and publishing the Materials, including, without limitation, to all decisions regarding editing, lighting, filming, timing of publication, if any, length, quality, content and the like.

11. Indemnification. The Author agrees to indemnify JoVE and/or its successors and assigns from and against any and all claims, costs, and expenses, including attorney's fees, arising out of any breach of any warranty or other representations contained herein. The Author further agrees to indemnify and hold harmless JoVE from and against any and all claims, costs, and expenses, including attorney's fees, resulting from the breach by the Author of any representation or warranty contained herein or from allegations or instances of violation of intellectual property rights, damage to the Author's or the Author's institution's facilities, fraud, libel, defamation, research, equipment, experiments, property damage, personal injury, violations of institutional, laboratory, hospital, ethical, human and animal treatment, privacy or other rules, regulations, laws, procedures or guidelines, liabilities and other losses or damages related in any way to the submission of work to JoVE, making of videos by JoVE, or publication in JoVE or elsewhere by JoVE. The Author shall be responsible for, and shall hold JoVE harmless from, damages caused by lack of sterilization, lack of cleanliness or by contamination due to the making of a video by JoVE its employees, agents or independent contractors. All sterilization, cleanliness or decontamination procedures shall be solely the responsibility of the Author and shall be undertaken at the Author's expense. All indemnifications provided herein shall include JoVE's attorney's fees and costs related to said losses or damages. Such indemnification and holding harmless shall include such losses or damages incurred by, or in connection with, acts or omissions of JoVE, its employees, agents or independent contractors.

- 12. Fees. To cover the cost incurred for publication, JoVE must receive payment before production and publication the Materials. Payment is due in 21 days of invoice. Should the Materials not be published due to an editorial or production decision, these funds will be returned to the Author. Withdrawal by the Author of any submitted Materials after final peer review approval will result in a US\$1,200 fee to cover pre-production expenses incurred by JoVE. If payment is not received by the completion of filming, production and publication of the Materials will be suspended until payment is received.
- 13. <u>Transfer, Governing Law.</u> This Agreement may be assigned by JoVE and shall inure to the benefits of any of JoVE's successors and assignees. This Agreement shall be governed and construed by the internal laws of the Commonwealth of Massachusetts without giving effect to any conflict of law provision thereunder. This Agreement may be executed in counterparts, each of which shall be deemed an original, but all of which together shall be deemed to me one and the same agreement. A signed copy of this Agreement delivered by facsimile, e-mail or other means of electronic transmission shall be deemed to have the same legal effect as delivery of an original signed copy of this Agreement.

A signed copy of this document must be sent with all new submissions. Only one Agreement required per submission.

# **CORRESPONDING AUTHOR:**

Name:	ROUD MORICHE	
Department:	MATERIALS SCIENCE AND ENGINTERING AREA	
Institution:	UNIVERSITY REY JUAN (ARLOS	
Article Title:	CRAPHENE NANCALATELETS MULTISCALE COMPOSITE MATERIALS FOR STRAIN SENS	inc
Signature:	Date:	

Please submit a signed and dated copy of this license by one of the following three methods:

- 1) Upload a scanned copy of the document as a pfd on the JoVE submission site;
- 2) Fax the document to +1.866.381.2236;
- 3) Mail the document to JoVE / Attn: JoVE Editorial / 1 Alewife Center #200 / Cambridge, MA 02139

For questions, please email submissions@jove.com or call +1.617.945.9051

٠			

### **Editorial comments:**

# 1. Some additional details are required:

### 1.1.1: What are the f-GNPs dissolved in?

The f-GNPs are not dissolved in any solvent, they are dispersed (1.1.2) into the monomer.

### 2.1.1: What is the solvent used here?

A comment has been included to clarify it: "2.1.1) Weigh 7.5 g of f GNPs, the quantity needed to achieve a 5 wt% into 142.5 g of solvent (sizing/distilled water specified in 2.1.2) inside a ductless fume hood."

## 2.2.1: Dip in which sizing, the one from 1.1.5 or 2.1.3?

A clarifying note has been included: ", prepared in 2.1.3,". The point 1.1.5 is related to the reinforcement of the epoxy matrix where sizing is not used.

# 4.1: We need more details on the CNC if this is to be filmed. What parameters are used, etc.

A clarifying note has been included: "Note: samples are fixed onto the machining table with adhesive tape and machined using the following parameters: feed speed of 500 mm/min, idle speed of 5000 min-1 and depth steps of 0.1 mm."

## Please provide a reference for ASTM D790-02.

The reference has been added.

# 4.3: What type of silver is used? Please include in the Materials Table as well.

The type of paint has been added into brackets: "(acrylic conductive paint)". Additionally, the silver paint has been included in the Materials Table as indicated.

# 5.2.1.3: What sequence of finger bending?

A note has been included:

"Note: The sequence of finger bending in this particular case is: (1) thumb, (2) index, (3) middle finger, (4) ring finger, (5) all the fingers simultaneously and (6) sequence of bending (higher speed): (1), (2), (3), (4), (4), (3), (2) and (1)."

## 2. Please revise the X axis label in Figure 5 to say "Time (sec)".

The X axis label has been corrected.

# 3. Please include comparisons of the method presented with other protocols and provide citations in the Discussion.

Some additional discussion has been included:

- "Usually, dispersion of nanoreinforcement is carried out into solvent that need to be evaporated before curing of nanocomposites<sup>29,30</sup>. In the process proposed in this work, the use of solvents is avoided making it more environmentally friendly."
- "One of the advantages of positioning electrical contacts on the surface of the material, in contrast to the electrodes located inside the sample<sup>31</sup>, is that it is not intrusive and do not cause detriment of mechanical properties."

# 4. Please revise the highlighting of the protocol to represent 2.75 pages of protocol text. You currently exceed this hard limit for the videography.

The protocol has been revised. Two descriptions have been removed of the highlighted text (in red).

# 5. Some grammatical issues are still in the manuscript. I have done some light copyediting. Please use the attached file for all revisions.

The text has been revised carefully. If any other issues are in the manuscript, please do not hesitate to contact.

The electrical behavior of the multiscale composite materials, f-GNPs/epoxy (Figure 4.a) and f GNPs/glass fiber (Figure 4.b) composite materials, shows some differences with the described above. What is the "described above" referring to?

A brief comment has been included: "for coated fabrics".

# 0.015 mm/mm??

This is the value of the strain induced in materials during the test. Units can be mm/mm or per unit. It is the same but usually mm/mm is used in order to differentiate from percentages.

# The sensitivity shown in all the configurations is on the order of 10 to 40 - What are the units here?

These values are per unit, for sensitivity there is no necessity of including it. Nevertheless, units have been added into brackets.