

# Journal of Visualized Experiments

## In-situ monitoring of the accelerated performance degradation of solar cells and modules: a case study for Cu(In,Ga)Se<sub>2</sub> solar cells --Manuscript Draft--

<b>Manuscript Number:</b>	JoVE55897R4
<b>Full Title:</b>	In-situ monitoring of the accelerated performance degradation of solar cells and modules: a case study for Cu(In,Ga)Se <sub>2</sub> solar cells
<b>Article Type:</b>	Invited Methods Article - JoVE Produced Video
<b>Keywords:</b>	CIGS; CZTS; damp heat; degradation; electrical loads; illumination; in-situ analysis; monitoring; Solar cells; testing
<b>Manuscript Classifications:</b>	93.33.75: solar cells (electrical design); 93.38.17: reliability (procedures and theory); 94.44.18: solar cells (energy conversion); 94.44.21: solar panels (energy conversion)
<b>Corresponding Author:</b>	Mirjam Theelen, PhD TNO/Solliance Eindhoven, Noord-Brabant NETHERLANDS
<b>Corresponding Author Secondary Information:</b>	
<b>Corresponding Author E-Mail:</b>	mirjam.theelen@tno.nl; mirjam.theelen@solliance.eu
<b>Corresponding Author's Institution:</b>	TNO/Solliance
<b>Corresponding Author's Secondary Institution:</b>	
<b>First Author:</b>	Mirjam Theelen, PhD
<b>First Author Secondary Information:</b>	
<b>Other Authors:</b>	Klaas Bakker
	Henk Steijvers
	Stefan Roest
	Peter Hielkema
	Nicolas Barreau
	Erik Haverkamp
<b>Order of Authors Secondary Information:</b>	
<b>Abstract:</b>	<p>The levelized cost of electricity (LCOE) of photovoltaic (PV) systems is determined by among others the PV module reliability. Better prediction of degradation mechanisms and prevention of module field failure can therefore decrease investment risks as well as increase the electricity yield. An improved knowledge level can therefore significantly decrease the total costs of PV electricity.</p> <p>In order to better understand and minimize the degradation of PV modules, the occurring degradation mechanisms and conditions should be identified. This should preferably happen under combined stresses, since modules in the field are also simultaneously exposed to multiple stress factors. Therefore, two 'Combined Stress test with In-situ measurement' setups have been designed and constructed. These setups allow the simultaneous use of humidity, temperature, illumination and electrical biases as independently controlled stress factors on solar cells and minimodules. The setups also allow real-time monitoring of the electrical properties of these samples. This protocol presents these setups and describes the experimental possibilities. Moreover, results obtained with these setups are also presented: various examples about the influence of both deposition and degradation conditions on the stability of thin film Cu(In,Ga)Se<sub>2</sub> as well as Cu<sub>2</sub>ZnSnSe<sub>4</sub> solar cells are described. Results on</p>

	the temperature dependency of Cu(In,Ga)Se <sub>2</sub> solar cells are also presented.
<b>Author Comments:</b>	As discussed with Benjamin Werth, we have funding on a project that will be closed on February 28th. We would like to have the invoice (a long time?) before this date, and it would be nice if we would already have gone through the peer-review process before this time.
<b>Additional Information:</b>	
<b>Question</b>	<b>Response</b>
If this article needs to be "in-press" by a certain date, please indicate the date below and explain in your cover letter.	02-24-2017

**TITLE:**

*In Situ* Monitoring of the Accelerated Performance Degradation of Solar Cells and Modules: A Case Study for Cu(In,Ga)Se<sub>2</sub> Solar Cells

**AUTHORS & AFFILIATIONS:**

Mirjam Theelen<sup>1</sup>, Klaas Bakker<sup>1</sup>, Henk Steijvers<sup>1</sup>, Stefan Roest<sup>2</sup>, Peter Hielkema<sup>3</sup>, Nicolas Barreau<sup>4</sup>, Erik Haverkamp<sup>5,6</sup>

<sup>1</sup>TNO Solliance, Thin Film Technology, High Tech Campus 21, 5656 AE Eindhoven, The Netherlands

<sup>2</sup>Eternal Sun, Wolga 11, 2491 BK Den Haag, the Netherlands

<sup>3</sup>Hielkema Testequipment, Vluchtoord 23, 5406 XP Uden, The Netherlands

<sup>4</sup>Institut des Matériaux Jean Rouxel (IMN)-UMR 6502, Université de Nantes, CNRS, 2 rue de la Houssinière, BP 32229, 44322 Nantes Cedex 3, France

<sup>5</sup>ReRa Solutions BV, Bijsterhuizen 1158, 6546 AS Nijmegen, The Netherlands

<sup>6</sup>Radboud University, Institute of Molecules and Materials, Heyendaalseweg 135, 6525 AJ Nijmegen, The Netherlands

**E-MAIL ADDRESSES:**

Mirjam Theelen (mirjam.theelen@tno.nl)

Klaas Bakker (n.j.bakker@ecn.nl)

Henk Steijvers (henk.steijvers@tno.nl)

Stefan Roest (sroest@eternalsun.com)

Peter Hielkema (peter@hielkematest.nl)

Nicolas Barreau (nicolas.barreau@univ-nantes.fr)

Erik Haverkamp (erik.haverkamp@rerasolutions.com)

**CORRESPONDING AUTHOR:**

Mirjam Theelen (Mirjam.theelen@tno.nl)

**KEYWORDS:**

CIGS, CZTS, damp heat, degradation, electrical loads, illumination, *in situ* analysis, monitoring, solar cells, testing

**SHORT ABSTRACT:**

Two 'Combined Stress test with *in situ* measurement' setups, which allow real-time monitoring of accelerated degradation of solar cells and modules, were designed and constructed. These setups allow the simultaneous use of humidity, temperature, electrical biases, and illumination as independently controlled stress factors. The setups and various experiments executed are presented.

**LONG ABSTRACT:**

The levelized cost of electricity (LCOE) of photovoltaic (PV) systems is determined by, among other factors, the PV module reliability. Better prediction of degradation mechanisms and

prevention of module field failure can consequently decrease investment risks as well as increase the electricity yield. An improved knowledge level can for these reasons significantly decrease the total costs of PV electricity.

In order to better understand and minimize the degradation of PV modules, the occurring degradation mechanisms and conditions should be identified. This should preferably happen under combined stresses, since modules in the field are also simultaneously exposed to multiple stress factors. Therefore, two 'Combined Stress test with *in situ* measurement' setups have been designed and constructed. These setups allow the simultaneous use of humidity, temperature, illumination, and electrical biases as independently controlled stress factors on solar cells and minimodules. The setups also allow real-time monitoring of the electrical properties of these samples. This protocol presents these setups and describes the experimental possibilities. Moreover, results obtained with these setups are also presented: various examples about the influence of both deposition and degradation conditions on the stability of thin film Cu(In,Ga)Se<sub>2</sub> (CIGS) as well as Cu<sub>2</sub>ZnSnSe<sub>4</sub> (CZTS) solar cells are described. Results on the temperature dependency of CIGS solar cells are also presented.

## INTRODUCTION:

PV systems are considered to be a cost-effective form of renewable energy. PV modules represent the core of these PV systems and are generally sold with a performance guarantee of over 25 years (*e.g.*, max. 20% efficiency loss after this period)<sup>1</sup>. It is crucial for the trust of consumers and investors that these guarantees are met. The electricity yield should therefore be as stable and high as possible over at least the desired module lifetime. This should be managed by reduction of both slow but steady degradation<sup>2</sup> and unexpected premature module failures, which, for example can occur due to production errors. Examples of observed module failures in the field are Potential Induced Degradation (PID)<sup>3</sup> and Light Induced Degradation (LID)<sup>4</sup> for crystalline silicon modules or water induced corrosion in CIGS modules<sup>5,6,7,8</sup>. In order to prevent a reduced field lifetime of PV modules, degradation mechanisms should therefore be identified and minimized.

Improved understanding of degradation mechanisms occurring in PV cells or modules would also help to lower PV module production costs: in many cases, protective materials against environmental stresses are introduced in modules to offer the guaranteed lifetime. This is for example true for flexible thin film modules, like CIGS, that contain an expensive barrier to prevent water ingress. All package materials in such modules can make up to 70% of the module costs. These protective materials are often over-dimensioned in order to be certain to obtain the required lifetime: more knowledge about the degradation mechanisms can therefore make solar cells more intrinsically stable and more accurately predictable. Better understanding about the long-term stability of the module and its constituents would therefore likely prevent over-dimensioning and allow reduced costs for these protective materials.

To give a general estimation of module reliability, solar cells and modules are nowadays tested and qualified by Accelerated Lifetime Tests (ALT)<sup>9</sup>. The most profound qualification tests are defined by the International Electrotechnical Commission (IEC) 61215 tests<sup>10</sup>, which give "go/no

go” decisions on the stability of PV modules. However, Osterwald *et al.*<sup>11</sup> revealed that a positive outcome of the IEC tests does not always indicate that the PV module can stand outdoor conditions for 25 or more years. This limited correlation between field and laboratory testing was demonstrated to be especially true for the relatively new thin film modules<sup>12</sup>.

These tests do not yield insight into the degradation mechanisms (‘Which processes and/or which stresses lead to observed slow module degradation or to rapid module failure?’). Moreover, these tests, which are currently based on single or dual stress factors (for example mechanical stress, or combined temperature and humidity) can certainly not simulate field behavior in a reliable way, since PV modules in the field are subject to numerous combined stresses (for example: temperature, humidity, wind, snow, illumination, dust, sand, water). These stresses can also vary per climate zone: while in the desert, temperature and illumination are likely important stress factors; in moderate climates, the influence of for example humidity can also be very important. To simulate the degradation and consequent failures in various climates, various combinations of multiple stresses are thus required. Consequently, simultaneous exposure to multiple stresses is very important to obtain a good estimation of the module reliability in a certain climate, and combined stress tests should thus be part of laboratory tests.

It is thus proposed that qualitative and quantitative understanding of the degradation mechanisms occurring under combined stress conditions should be improved. Ideally, information about the solar cell or module should also be gathered during these tests, to allow identification of device changes during exposure. Therefore, we have designed and constructed two setups that allow simultaneous exposure to humidity, (elevated) temperatures, electrical biases, and illumination. In these setups, the severity of these stresses can also be tuned, depending on the goal of an experiment. Additionally, the illumination allows *in situ* monitoring of the PV devices (**Figure 1**)<sup>13-20</sup>. These types of tests will be named ‘Combined Stress tests with *in situ* measurements’ (CSI). In this protocol, two hybrid degradation setups, named ‘CSI 1’ and ‘CSI 2’, will be presented. Many studies, aiming at the improvement of understanding of the performance and degradation of especially thin film CIGS solar cells, were executed with these setups. A selection of stability and temperature dependency results obtained on unpackaged CIGS and CZTS solar cells are presented. More information can also be found in<sup>21,22</sup>.

[Insert Figure 1]

## PROTOCOL:

Note: Sections 1 and 3 are specific for degradation testing of CIGS and CZTS solar cells via this procedure, but all other types of solar cells (*e.g.*, perovskites, organic PV, and crystalline silicon) are or will be tested with these setups. It should be noted that for every device type and geometry, a sample holder should be designed. These holders should have non-corroding contacts to prevent contact degradation, since this would obscure the effects of device degradation. Moreover, it is advised to contact samples in a four-point probe configuration, to prevent the measurement of the results of corroded contacts or wires in the measurement system.

## 1. Preparation of CIGS Solar Cells

1.1. Use gloves in all steps of the protocol when handling solar cells: protect against the toxic elements, but also prevent the deposition of unwanted materials, like kitchen salt (NaCl), on the samples.

1.2. Cut a 1 mm x 100 mm x 100 mm soda lime (SLG) glass sample into four 100 mm x 25 mm rectangular strips with a glass cutter or diamond pen in order to prepare appropriate substrates.

1.3. Place the SLG sample in a sputter coater. Deposit the 0.5  $\mu\text{m}$  thick molybdenum back contact by Direct Current (DC) sputtering at room temperature on the glass substrates<sup>23</sup>.

1.3.1. Choose from various stack sequences, including a single layer, a bilayer, and a multiplayer stack. For example, deposit a bilayer with a high initial sputtering pressure (e.g., 0.03 mbar) followed by a lower sputtering pressure (e.g., 0.003 mbar) at power densities of 1–5 W/cm<sup>2</sup>.

1.4. Prepare an etch solution of 1 M NaOH and 0.3 M K<sub>3</sub>Fe(CN)<sub>6</sub><sup>24</sup>. Electrochemically etch a 6 mm stripe of the molybdenum away to deposit a patterned back contact.

Note: In this way, the solar cell has a well-defined area, without solar cell areas covered by the gold contacts, which might still partly contribute to the electrical parameters.

1.5. Place the sample in a vacuum chamber and deposit a 2  $\mu\text{m}$  thick CIGS absorber layer by a coevaporation process under a copper, indium, gallium, and selenium atmosphere<sup>25</sup>.

1.5.1. For example, use typical substrate temperatures of 550 to 600 °C and follow the three-stage deposition process, first forming (In,Ga)<sub>2</sub>Se<sub>3</sub> by evaporation of indium, gallium and selenium, followed by the formation of a copper rich CIGS due to the addition of large quantities of copper. Turn off the copper evaporator to form the required copper-poor CIGS absorber in the third stage.

1.5.2. Alternatively, use a two-stage deposition at atmospheric pressure for a low-cost process. Perform CuInGa deposition, either by vacuum sputtering or by atmospheric pressure electrochemical deposition. Follow this by selenization under an elemental selenium atmosphere<sup>26</sup> in a moving belt selenization oven.

1.6. Place the sample in a chemical bath and deposit the CdS buffer by a “chemical bath deposition” (CBD) process with a thickness of 50 nm<sup>27</sup>. Typically use a water based solution of NH<sub>4</sub>OH, CdSO<sub>4</sub>, and thiourea (NH<sub>2</sub>CSNH<sub>2</sub>) at a temperature of ~ 70 °C.

1.7. Place the sample in a sputtering tool and deposit the i-ZnO/ZnO:Al front contact by Radio Frequency (RF) sputtering from i-ZnO and ZnO:Al targets with thicknesses of respectively 50 nm and 800–1,000 nm<sup>28</sup>.

177  
178 1.7.1. For i-ZnO use a layer of a pure ZnO target and use a ZnO ceramic target with 2% Al<sub>2</sub>O<sub>3</sub> for  
179 the ZnO:Al layer. Use deposition temperatures between room temperature and 200 °C. Avoid the  
180 use of a conductive metal grid in the top electrode, as this is not used in commercial modules.  
181 Therefore, use this relatively thick ZnO:Al layer to allow enough conductivity in these cells that  
182 mimic a module design.

183  
184 1.8. Carefully scratch away a stripe of 14 mm (at the opposite side of the etching in step 1.4) of  
185 the solar cell with a knife.

186  
187 1.8.1. By making use of the difference in hardness of the layers, remove only the top layers  
188 (ZnO:Al/i-ZnO/CdS/CIGS) and leave the molybdenum back contact intact. Form solar cells with a  
189 width of 5 mm, similar to the width of a cell in a module.

190  
191 1.9. Place the sample in a gold sputtering tool and cover it with a stripe in the middle as a mask,  
192 so that no gold is deposited on the solar cell. Deposit gold contacts of ~ 60 nm thickness by  
193 sputtering at room temperature on both the back contact (molybdenum) and the front contact  
194 (ZnO:Al) in order to allow contacting of the cells.

195  
196 Note: The use of a contact of a noble metal allows long term exposure of the samples to harsh  
197 conditions without degradation of the contacts, so that the cell degradation can be studied.

198  
199 1.10. Cut the strips with a glass cutter or a diamond pen into 7 mm wide samples, that now have  
200 a cell surface of ~ 7 mm x 5 mm and a total size of 7 mm x 25 mm (**Figure 2**).

201  
202 Note: A schematic representation of the cross-section as well as a microscopy picture of a cell is  
203 shown in **Figure 2**. For the experiments with CZTS solar cells, a different deposition procedure of  
204 the active absorber layer (CZTS) has been followed (similar to reference<sup>29</sup>), while all other layers  
205 were deposited following an analog procedure.

206  
207 [Insert Figure 2 here]

## 208 209 2. Analysis of the Solar Cells Before Degradation

210  
211 2.1. Measure the *ex situ* current voltage (IV) performance of the solar cells under standard test  
212 conditions (STC, illumination: 1000 W/m<sup>2</sup> and AM 1.5, temperature: 25°C) in a four point probe  
213 configuration to determine the electrical parameters with an IV tester.

214  
215 2.1.1. Measure the external quantum efficiency (EQE) for the exact current density and  
216 wavelength dependent absorption<sup>30,31</sup> with a spectral response (SR) setup and calculate the exact  
217 current density.

218  
219 2.2. Record the illuminated lock-in thermography (ILIT) mapping<sup>31</sup> and the photoluminescence  
220 (PL) mapping<sup>31</sup> with a large magnification and take (microscopy) images to identify any visual and

lateral defects.

2.2.1. Place the sample under an ILIT device with heat detector with a 15  $\mu\text{m}$  lens for high magnification and an IR illumination source. Illuminate the sample and record the spatial difference in temperature to identify the heated locations.

2.2.2. Place the sample under a mapping PL setup to obtain a spatial photoluminescence image. Use a high power LED light source for illumination and a CCD camera for data detection.

Note: Examples can be found in references<sup>15,16,20,30</sup>.

2.3. Select a number of solar cells for the degradation experiment, while placing the rest of the samples in an argon glovebox as reference. Select a mixed set of solar cells as reference and as experimental samples, so any difference within the full slides (e.g. gradients in composition) are in the same severity present in the experiment and reference samples.

Note: This could for example mean that cells with positions 1, 3, 4, 5, 7 and 8 on the slides are experimental cells, while positions 2 and 6 are reference cells.

### 3. Placement of the Solar Cells into Sample Holders

3.1. Place the solar cells in sample holders that do not cast any shadow on the cells and make contact between the gold front and back contacts and measurement pins.

Note: The sample holders are specifically designed to withstand the harsh conditions during the climate tests. Moreover, they are constructed of materials that have only limited outgassing.

3.2. Place the sample holders on the sample rack inside the CSI setup, which allow electrical contact between the solar cells and the measurement tools outside the setup. Place the sample rack on the dedicated position, where it will be illuminated by an AM 1.5 light source.

Note: Light source specifications are as follows. CSI1: 40 cm x 40 cm area, 1,000 W/m<sup>2</sup>, BAA calibrated illumination; CSI2: 100 x 100 cm<sup>2</sup> area, 1,000 W/m<sup>2</sup>, AAA calibrated illumination, calibrations according to IEC60904-9:2007<sup>32</sup>.

### 4. Execution of the Degradation Experiment

4.1. Switch on the solar simulator, the measurement equipment, the climate chamber, and the computer.

4.2. Program the measurement computer, which controls the solar simulator, electrical biases, and climate chamber settings. Define the voltage range, voltage steps, measurement sequence, and time between the measurements in the IV measurement software, and define temperature, humidity, bias voltage, and illumination profiles in the software.



Note: Let this software steer the measurements during the full experiment.

4.2.1. For typical settings for the IV measurements, use voltage in the range -0.2 V to +1.0 V in 120 steps (0.01 V/step). Note that in most cases, the system alternates between the IV measurements of all samples and pauses of around 5 min.

4.3. Stabilize the temperature of the climate chamber and the solar cells in the setup. Observe the sample temperature in the software.

Note: A typical temperature for the solar cells is 25 °C, which is the STC temperature. Since the illumination heats up the samples, the sample temperature is always higher than the surrounding chamber. Typical starting temperatures of the climate chamber are -10 °C to +5 °C (+5 °C chamber temperature can for example lead to CIGS sample temperatures of 25 °C). If other sample designs or compositions are selected, other chamber temperatures can be required to obtain 25 °C sample temperature.

4.4. Heat the climate chamber slowly until it reaches 85 °C, for example at 0.1–0.3 °C/min. Read the chamber temperature from the climate chamber computer and read the sample temperature from the software.

Note: Typical samples temperatures are then between 100 °C and 110 °C when the chamber is 85 °C. These values vary between samples, and are especially influenced by the substrate type, the sample holder design and material, and the solar cell itself. During this stage, the cells are in open circuit conditions when they are not measured, unless mentioned differently. If the influence of any internal voltage bias during the heating stage has to be excluded, the illumination can also be off during this stage.

4.4.1. For CSI1, attach an individual thermocouple to all individual cells to measure their temperature, while in CSI2 use 15 thermocouples for 32 samples. Record and log the individual temperatures.

4.5. Automatically measure the current voltage curves of the solar cells one by one during the heating, which means that they are determined every 0.5 to several min, depending on the number of samples. Observe the electrical parameters in the software.

4.5.1. Calculate the electrical parameters from the current voltage curves. Always determine the efficiency, open circuit voltage, short circuit current density, fill factor, series resistance, and shunt resistance. Determine the resistances from the slopes on the end of the current voltage curves.

4.5.2. If required, also determine the ideality factor, saturation current density, and photo current density by fitting with the one-diode model<sup>14</sup>.

Note: However, note that these fitting procedures are relatively unreliable for degraded solar cells that do not behave like ideal diodes. The efficiency as measured by these elevated temperatures will be lower than under STC, which is mostly visible in a decrease in the open circuit voltage<sup>13</sup>.

4.6. Turn on the humidity in the climate chamber, a standard setting is a relative humidity (RH) of 85%. This is generally the starting point of the experiment ( $t = 0$  h). Observe the RH from the climate chamber computer.

Note: The actual sample relative humidity is lower than the set value. This is caused by the fact that the sample temperature is higher than 85 °C, while the absolute humidity is the same: since the relative humidity is a function of the temperature, this value is lower than 85% RH<sup>33</sup>.

4.7. Leave the samples in the CSI setups for 100s to 1,000s of hours, while measuring the current voltage curves. Measure the curves every 5 to 10 min, but vary this on demand. Observe the electrical parameters in the software.

4.7.1. In the remaining time, keep the samples either under open circuit conditions (standard conditions) or place them under various electrical biases with the use of electrical loads, varying from -20 V to +20 V. In case a modification of the electrical bias is required during the experiment, change the set value in the tracer software.

Note: 'Standard' settings are the maximum power point (MPP) conditions (the operation voltage and current of a solar cell), short circuit conditions, and conditions with a limited negative voltage. Use the latter to simulate partial module shading.

4.8. To learn more about samples after various exposure times, remove a limited number of samples in the sample holders from the setup before the others. Execute this under illumination and in a very rapid manner in order to minimize the influence on the remaining samples. This is naturally only possible for small samples.

4.9. At the end of the experiment, cool the chamber down to room temperature slowly in a few hours and remove the samples together with their sample holders. Observe the temperature from the climate chamber computer.

Note: It is also possible to use other light intensities (*e.g.*, 800 W/m<sup>2</sup> or ultraviolet light), while the humidity and temperature can naturally also be varied. In that case, the obtained electrical parameters should be corrected for the different light intensity. It was observed that unexpected changes in electrical parameters occurred when CIGS solar cells were shortly (*e.g.*, 15 min) not illuminated (and heated by the illumination source). If this effect is not the aim of the study, it is recommended to leave on the illumination continuously<sup>14</sup>.

## 5. Analysis of Degraded and Reference Cells

5.1. Plot the development of the electrical parameters as a function of exposure time in the degradation setups.

5.2. Repeat the *ex situ* IV measurements of the degraded solar cells directly after the samples are removed from the setups to obtain the electrical parameters at STC. Repeat the external quantum efficiency measurements for the exact current density and wavelength-dependent absorption.

5.3. Record again the illuminated lock-in thermography mapping and photoluminescence mapping, and take (microscopy) pictures to identify any change in visual and lateral defects. Use the same settings as before degradation.

5.4. Use other analysis techniques, like (cross-section) Scanning Electron Microscope-Energy Dispersive X-ray spectroscopy (SEM-EDX)<sup>31</sup>, X-Ray Diffraction (XRD)<sup>31</sup>, Secondary Ion Mass Spectroscopy (SIMS)<sup>31</sup>, and temperature dependent current voltage (IV(T))<sup>31</sup> to further identify the failure mechanisms.

5.4.1. Execute these destructive analyses on both degraded and reference samples to observe the changes due to exposure in the CSI setups.

## 6. Definition of the Degradation Mechanisms and Modes

6.1. Combine all the data to define degradation mechanisms and their impact on long term stability of the solar cells or modules.

### REPRESENTATIVE RESULTS:

The CSI setups have been used for a wide range of experiments. Experiments have both focused on the influence on the cell or module composition and design, as well as on the influence of the degradation conditions. Some examples of the development of electrical parameters are displayed in the following figures. Measurements in **Figure 3**, **Figure 5**, **Figure 6**, and **Figure 7** were taken in CSI1, while **Figure 4** was obtained in CSI2. In these figures, it is chosen to depict either the device efficiency, the open circuit voltage, or the shunt resistance, but other parameters can naturally also be plotted.

**Figure 3** and **Figure 4** display the influence of the degradation conditions on stability of alkali-rich CIGS solar cells without a humidity barrier or any other package material. **Figure 3** shows that these cells degrade when they are exposed to illumination, heat, and humidity, while they are almost stable in the absence of humidity. This indicates that these solar cells or analog modules might be completely stable when well packaged against humidity<sup>15</sup>. Potential package materials naturally include glass, but also flexible barriers, which are often based on organic-inorganic multi-stacks<sup>15</sup>. In future experiments, these possibilities will also be tested. These results also indicate that this package material might not be necessary in a hot and dry climate. **Figure 4** shows the influence of a bias voltage when exposed to damp heat plus illumination: these preliminary results indicate that a low negative voltage (-0.5 V, grey curves) likely has a more

negative effect on stability than short circuit, open circuit, and MPP conditions<sup>18</sup>.

[Insert Figure 3 and Figure 4 here]

Due to the slow heating (0.1–0.3 °C/min) during the heating phase and the real-time measurements, these setups also automatically allow the determination of the temperature dependency of solar cells. **Figure 5** displays the dependency of the open circuit voltages as obtained from the heating curves before degradation experiments. This graph shows that differences exist between the open circuit voltage ( $V_{oc}$ ) temperature dependency of various CIGS solar cells, while other parameters like the series resistance and the short circuit current (not depicted) display even larger differences between cells. The development of other parameters can be found in reference<sup>34</sup>.

[Insert Figure 5 here]

**Figure 6** shows that small differences in the composition of solar cells can have a large influence on the device stability. This experiment demonstrated that alkali-rich samples containing large quantities of sodium and potassium had a higher initial efficiency, but they also degraded more rapidly. On the other hand, almost stable unpackaged solar cells that only contained small quantities of alkali-elements (“alkali-poor” samples) were also produced. These solar cells were thus almost intrinsically stable and did not need any protective material. Based on this information combined with *ex situ* analysis results, the main degradation mechanisms for these samples could be identified: it was observed that the main driver behind the efficiency-loss of the alkali-rich samples was a sharp decrease in shunt resistance<sup>16</sup>. In-depth analysis of the properties of these cells displayed that the migration of alkali-elements, more specifically sodium, seemed to cause this decrease. More information is presented in references<sup>16,20</sup>. Later stages of this study aim to develop solar cells with the stability of the alkali-poor samples, and the high initial efficiency of the alkali-rich samples.

[Insert Figure 6 here]

A last example focuses on various CZTS samples<sup>19</sup>. **Figure 7** shows that different types of unpackaged solar cells demonstrate a different IV behavior under damp heat plus illumination. It should be noted that these cells are not ideal solar cells, so the increase in efficiency and voltage as displayed in this figure is likely not representative for CZTS solar cells in general and no explanation could be provided for this behavior. More studies need to be executed to give reliable statements about the stability of these cells.

[Insert Figure 7 here]

#### FIGURE LEGENDS:

**Figure 1: ‘Combined Stress tests with *in situ* measurements’ setup.** Left: Schematic overview of a CSI setup including the measurement system. Middle and right: Photograph of the CSI setups

(climate chambers plus solar simulators, measurement systems not depicted, setups have different sizes). Middle is CSI1, right is CSI2. This figure has been modified from<sup>19,30</sup>.

**Figure 2: CIGS sample design.** (top) Schematic representation of the cross-section of a CIGS sample and (bottom) a microscope picture of a CIGS sample taken from the top. This figure has been partly modified from references<sup>14,30</sup>.

**Figure 3: Influence of humidity on CIGS solar cell stability.** The development of the efficiency of unpackaged CIGS solar cells as a function of exposure time to illumination plus dry heat (red) and damp heat (blue) taken at elevated temperatures. Every line represents one solar cell. This figure has been modified from reference<sup>15</sup>.

**Figure 4: Influence of electrical loads on CIGS solar cell stability.** Evolution of the efficiency of unpackaged cells as a function of time at various voltages plus damp heat and illumination. Grey, blue, green, and red curves indicate exposure to -0.5 V, 0 V,  $\sim V_{MPP}$ , and open circuit conditions, respectively. These parameters are obtained at elevated temperatures, while the room temperature efficiencies are around 50% higher. Every line represents one solar cell. This figure has been modified from reference<sup>18</sup>.

**Figure 5: Temperature dependency of CIGS solar cells.** Temperature dependency of the open circuit voltage ( $V_{oc}$ ) of two unpackaged CIGS solar cells. The colors indicate different solar cell designs: the blue squares represent samples with the cell design and deposition procedure as described above. The red circles indicate a non-packaged CIGS solar cell on polyimide foil with absorbers deposited with ion-beam assisted coevaporation. Every line represents one solar cell. This figure has been modified from reference<sup>34</sup>.

**Figure 6: Influence of the alkali-content on CIGS solar cell stability.** Evolution of the efficiency (left) and shunt resistance (right) of two types of unpackaged CIGS solar cells exposed to damp heat plus illumination. The pink and purple lines represent the alkali-poor samples, while the blue lines represent the alkali-rich samples. The values were obtained at elevated temperatures, while room temperature efficiencies are 30–80% higher. Every line represents one solar cell. This figure has been modified from reference<sup>16</sup>.

**Figure 7: CZTS solar cells exposed to damp heat plus illumination.** Evolution of normalized open circuit voltage and efficiency of four types of non-optimized unpackaged CZTS solar cells as a function of time, exposed to damp heat plus illumination taken at elevated temperatures. Every color depicts a different type of CZTS solar cell. Every line represents one solar cell. This figure has been modified from reference<sup>19</sup>.

## DISCUSSION:

Two CSI setups for real-time monitoring of the electrical parameters of solar cells and modules have been designed and constructed. These setups allow simultaneous exposure to damp heat, illumination, and electrical biases, while also *in situ* determining the IV parameters of PV devices. These setups have been used to study the influence of environmental stresses (humidity,

illumination, electrical biases, and temperature) as well as cell or module composition on the long-term stability of unpackaged solar cells. **Figure 3, Figure 4, Figure 5, Figure 6, and Figure 7** display a selection of results obtained with these setups.

Stability results (**Figure 3, Figure 4, Figure 6, and Figure 7**) from the presented studies should always be treated with care: in order to make the translation from these studies to module stability, the constraints of all accelerated lifetime tests on the stability of PV devices (including this study) should be taken into account. These constraints are caused by the fact that the conditions in the laboratory are meant to rapidly identify degradation mechanisms, while some degradation mechanisms might not be found due to the selection of the wrong (severity of) stresses. Moreover, the chosen conditions might also lead to degradation mechanisms and consequent failures that do not occur in the field or occur in the field before or after the predicted time frame. While for example for damp heat conditions (85 °C/85% RH), an acceleration factor of 219 is assumed, reference<sup>25</sup> showed that this rate is often non-linear and can vary in CIGS modules between 10 and 1,000, and for different degradation mechanisms.

To estimate the validity of the presented results, the most important differences between the field module exposure and the presented experiments should be taken into account:

a. Used laboratory conditions are more severe than field conditions, which is an intrinsic requirement for accelerated testing. Moreover, the conditions in these experiments are mostly constant, while modules in the field will be exposed to continuously changing conditions.

b. In the presented experiments, non-packaged solar cells were used. Naturally, barrier materials and edge sealants will play an important role in the device stability (especially under humid conditions). Additionally, the influence of interconnection and encapsulation materials is also very important and should not be neglected. Certainly, experiments with packaged and interconnected mini-modules are also possible in these setups.

c. Due to the illumination, the experiments presented in **Figure 3, Figure 5, Figure 6, and Figure 7** were executed under open circuit conditions when the IV curves were not recorded. However, modules should function under MPP conditions, while the cells could also be exposed to reversed bias conditions in the case of partial module shadowing. **Figure 4** shows that only limited differences between MPP and open circuit conditions were observed in that specific experiment, but that might be different for other cells or conditions.

d. The composition of the CIGS solar cells has a large influence on the long-term stability. Examples of studies on the influence of the composition on the stability can for example be found in references<sup>16,20</sup>. Since the exact nature of the influence of many small modifications in the solar cell stack is not yet identified, degradation might occur faster or slower than expected.

The above factors indicate that a large number of accelerated lifetime studies with variation in degradation conditions and sample composition is required to truly predict module field performance. Moreover, these results should therefore be combined with field studies to obtain

a complete picture about the long-term stability of PV modules.

However, we propose that the setups presented in this study are substantial improvements compared to the standard IEC tests, due to the combined stress exposure as well as *in situ* monitoring. These properties greatly improve the predictive value of accelerated lifetime experiments and increase our understanding of degradation mechanisms. The four main advantages compared to ‘standard’ (*e.g.*, IEC 61215) tests are the following capabilities:

a. Testing under exposure to combined stresses (*i.e.*, temperature, humidity, illumination, and electrical biases).

b. Tuning of combined stresses in order to simulate local climates (*e.g.*, desert or polar conditions).

c. Tuning of electrical biases, *e.g.*, to simulate effects of partial shading.

d. Real-time monitoring of the device performance, allowing simpler and faster testing as well as better prediction or limitation of the degradation mechanisms due to an increased knowledge level.

e. Reduced testing time, since a test can be stopped directly after a failure has occurred, instead of after the defined test period (*e.g.*, 1,000 h).

It is therefore proposed that lifetime studies with the presented setups can greatly improve the qualitative and quantitative understanding and prediction of long-term stability of solar cells and modules. In the future, a setup offering ‘Combined Stress tests with *in situ* measurements’ (CSI) for full scale modules will be developed: the setups with illuminated areas of 40 cm x 40 cm and 100 cm x 100 cm are too small for full-size PV modules, so plans to increase the scale of this combined stress measurement concept are underway.

#### **ACKNOWLEDGMENTS:**

The authors would like to thank Miro Zeman (Delft University of Technology) and Zeger Vroon (TNO) for the fruitful discussions. Kyo Beyeler, Vincent Hans, Ekaterina Liakopoulou, Soheyl Mortazavi, Gabriela de Amorim Soares (all TNO), Felix Daume (Solarion), and Marie Buffière (IMEC) are acknowledged for the sample deposition and analysis and the long discussions. Furthermore, we would like to thank all employees from Eternal Sun, Hielkema Testequipment, and ReRa Solutions, and more specifically Robert Jan van Vugt, Alexander Mulder and Jeroen Vink for their contribution.

These studies were carried out under project number M71.9.10401 in the framework of the Research Program of the Materials innovation institute M2i, TKI IDEEGO project TRUST, the project PV OpMaat, financed by the cross border collaboration program Interreg V Flanders-Netherlands with financial support of the European Funds for Regional Development and the TNO ‘Technologie zoekt Ondernemer’ program.

## DISCLOSURES:

The authors Erik Haverkamp (ReRa Solutions), Stefan Roest (Eternal Sun), and Peter Hielkema (Hielkema Testequipment) are employed by the consortium commercializing these setups. The employer of the inventors of these setups (authors Mirjam Theelen and Henk Steijvers (TNO)) holds a license agreement with this consortium.

## REFERENCES:


1. Jordan, D., Kurtz, S., VanSant, K., Newmiller, J., Compendium of Photovoltaic degradation rates, *Prog. Photovolt.* **24** (7) (2016) 978-989, DOI: 10.1002/pip.2744
2. Pingel, S. et al., Potential induced degradation of solar cells and panels, *Proc. 35<sup>th</sup> IEEE PVSC* (2010) 2817-2822, DOI: 10.1109/PVSC.2010.5616823
3. Lindroos, J., Savin, H., Review of light-induced degradation in crystalline silicon solar cells, *Sol. Energ. Mat. Sol. Cells* **147** (2016) 115–126, DOI 10.1016/j.solmat.2015.11.047
4. Theelen, M., Daume, F., Stability of Cu(In,Ga)Se<sub>2</sub> solar cells: A literature review, *Solar Energy* **133** (2016) 586–627, DOI 10.1016/j.solener.2016.04.010
5. Malmström, J., Wennerberg, J., Stolt, L., A study of the influence of the Ga content on the long-term stability of Cu(In,Ga)Se<sub>2</sub> thin film solar cells, *Thin Solid Films* **431–432** (2003) 436–442 DOI: 10.1016/S0040-6090(03)00185-8
6. Wennerberg, J., Kessler, J., Stolt, L., Degradation mechanisms of Cu(In,Ga)Se<sub>2</sub>-based thin film PV modules, *Proc. 16<sup>th</sup> EUPVSEC* (2000) 309–312
7. Feist, R., Rozeveld, S., Kern, B., D'Archangel, J., Yeung, S., Bernius, M., Further investigation of the lifetime-limiting failure mechanisms of CIGSS-based minimodules under environmental stress, *Proc. 34<sup>th</sup> IEEE PVSC* (2009) 2359–2363, DOI: 10.1109/PVSC.2009.5411323
8. Sharma, V., Chandel, S., Performance and degradation analysis for long term reliability of solar photovoltaic systems: A review, *Renew. Sustainable Energy Rev.* **27** (2013) 753–767, DOI: 10.1016/j.rser.2013.07.046
9. Fraunhofer ISE, PV Module Certification for new Standards and new Technologies, [https://www.ise.fraunhofer.de/content/dam/ise/de/documents/infomaterial/brochures/photo voltaik/flyer-pv-module-certification-for-new-standards-and-new-technologies.pdf](https://www.ise.fraunhofer.de/content/dam/ise/de/documents/infomaterial/brochures/photo%20voltaik/flyer-pv-module-certification-for-new-standards-and-new-technologies.pdf) accessed 19-3-2017
10. Osterwald, C., McMahon, T., History of Accelerated and Qualification Testing of Terrestrial Photovoltaic Modules: A Literature Review, *Prog. Photovolt.* **17**, 11–33 (2009) DOI: 10.1002/pip.861
11. Carlsson, T., Brinkman, A., Identification of degradation mechanisms in field-tested CdTe modules, *Prog. Photovolt.* **14**, 213 – 224 (2006), DOI: 10.1002/pip.663
12. Jordan, D., Kurtz, S., VanSant, K., Newmiller, J., Compendium of photovoltaic degradation rates, *Prog. Photovolt.* **24**, 978-989 (2016), DOI: 10.1002/pip.2744
13. Theelen, M., Tomassini, M., Steijvers, H., Vroon, Z., Barreau, N., Zeman, M., In situ Analysis of the Degradation of Cu(In,Ga)Se<sub>2</sub> Solar Cells, *Proc. 39<sup>th</sup> IEEE PVSC* (2013) 2047-2051
14. Theelen, M. et al., Accelerated performance degradation of CIGS solar cell determined by in situ monitoring, *Proc. SPIE 9179*, 91790I (2014), DOI: 10.1117/12.2059951



15. Theelen, M., Beyeler, K., Steijvers, H., Barreau, N., Stability of CIGS Solar Cells under Illumination with Damp Heat and Dry Heat: A Comparison, accepted in *Sol. Energ. Mat. Sol. Cells*, DOI 10.1016/j.solmat.2016.12.039
16. Theelen, M., Hans, V., Barreau, N., Steijvers, H., Vroon, Z., Zeman, M., The impact of sodium and potassium on the degradation of CIGS solar cells, *Prog. Photovolt.* **23**, 537-545 (2015), DOI: 10.1002/pip.2610
17. Theelen, M., Hendrikx, R., Barreau, N., Steijvers, H., Böttger, A., The effect of damp heat – illumination exposure on CIGS solar cells: a combined XRD and electrical characterization study, *Sol. Energ. Mat. Sol. Cells* **157**, 943–952 (2016) DOI: 10.1016/j.solmat.2016.07.051
18. Theelen, M. et al., The Exposure of CIGS Solar Cells to Different Electrical Biases in a Damp-heat Illumination Environment, *Proc 43<sup>rd</sup> IEEE PVSC* (2016) 0929-0934, DOI: 10.1109/PVSC.2016.7749746
19. Theelen, M. et al., In situ monitoring of the accelerated performance degradation of thin film solar cells, *Proc. 42<sup>th</sup> IEEE PVSC* (2015) 1-6, DOI: 10.1109/PVSC.2015.7355639
20. Theelen, M., Barreau, N., Steijvers, H., Hans, V., Vroon, Z., Zeman, M., Degradation of CIGS solar cells due to the migration of alkali elements, *Proc. 42<sup>th</sup> IEEE PVSC* (2015) 1-6 DOI: 10.1109/PVSC.2015.7355776
21. In situ monitoring of the degradation of CIGS solar cells, <https://www.youtube.com/watch?v=Zmy5tb-2NK8>, accessed on March 15<sup>th</sup> 2017
22. Hybrid degradation testing of solar cells and modules, <https://www.youtube.com/watch?v=tEsvkTco-To>, accessed on March 15<sup>th</sup> 2017
23. Theelen, M. et al, Influence of Mo/MoSe<sub>2</sub> microstructure on the damp heat stability of the Cu(In,Ga)Se<sub>2</sub> back contact molybdenum, *Thin Solid Films* **612** (2016) 381–392, DOI: 10.1016/j.tsf.2016.06.028
24. Hovestad, A, Bressers, P., Meertens, R., Frijters, C., Voorthuijzen, W., Electrochemical etching of molybdenum for shunt removal in thin film solar cells, *J. Appl. Electrochem.* **45** (7) (2015), 745-753, DOI: 10.1007/s10800-015-0829-9
25. Couzinie-Devy, F., Barreau, N., Kessler, J., Re-investigation of preferential orientation of Cu(In,Ga)Se<sub>2</sub> thin films grown by the three-stage process, *Prog. Photovolt.* **19** (2011) 527–536, DOI: 10.1002/pip.1079
26. Schmidt, S. et al., Adjusting the Ga grading during fast atmospheric processing of Cu(In,Ga)Se<sub>2</sub> solar cell absorber layers using elemental selenium vapor, accepted in *Prog. Photovolt.* (2017), DOI: 10.1002/pip.2865
27. Contreras, M. et al., Optimization of CBD CdS process in high-efficiency Cu(In,Ga)Se<sub>2</sub>-based solar cells, *Thin Solid Films* **403-404** (2002) 204–211, DOI: 10.1016/S0040-6090(01)01538-3
28. Theelen, M., et al., Physical and chemical degradation behavior of sputtered aluminum doped zinc oxide layers for Cu(In,Ga)Se<sub>2</sub> solar cells, *Thin Solid Films* **550** (2014) 530–540, DOI: 10.1016/j.tsf.2013.10.149
29. Brammertz, G. et al., Characterization of defects in 9.7% efficient Cu<sub>2</sub>ZnSnSe<sub>4</sub>-CdS-ZnO solar cells, *Appl. Phys. Lett.* **103** (16) (2013) 163904 DOI: 10.1063/1.4826448
30. Theelen, M., Degradation of CIGS solar cells, Ipskamp Drukkers (2015) DOI: 10.4233/uuid:2ce88658-a4c3-459f-afdc-00a5ac2c4ac4

- 658 31. Abou-Ras, D., Kirchartz, T., Rau, U., Advanced Characterization Techniques for Thin Film  
659 Solar Cells, Wiley-VCH (2011) DOI 10.1002/9783527699025
- 660 32. Wolgemuth, J., Standards for PV Modules and Components – Recent Developments and  
661 Challenges, *Proc. 27<sup>th</sup> EUPVSEC* (2012) 2976 - 2980 DOI: 10.4229/27<sup>th</sup>EUPVSEC2012-4DP.2.3
- 662 33. Hyperphysics Relative Humidity, [http://hyperphysics.phy-](http://hyperphysics.phy-astr.gsu.edu/hbase/kinetic/relhum.html)  
663 [astr.gsu.edu/hbase/kinetic/relhum.html](http://hyperphysics.phy-astr.gsu.edu/hbase/kinetic/relhum.html), accessed 19-3-2017
- 664 34. Theelen, M. et al., Temperature Dependency of CIGS solar cells on soda lime glass and  
665 polyimide: a comparison, accepted to JRSE (2016)
- 666 35. Coyle, D., Life prediction for CIGS solar modules part 1: modelling moisture ingress and  
667 degradation, *Prog. Photovolt.* **21** (2) (2013) 156-172, DOI 10.1002/pip.1172
- 668

Figure 1






Figure 3




Figure 4




Figure 5









Figure 6







Material/equipment	Company	Catalogue number	Comments
Hybrid degradation setup	Eternal Sun	Climate Chamber Solar Simulator	More infor
Sample holders	ReRa Solutions		More infor
Sample rack	Demo Delft		More infor
Gold deposition tool	Polaron Equipment LTD	SEM coating unit E5100	Tool for Au
Tracer IV software	ReRa Solutions		More infor
Solar cells	Solliance		More infor
Solar cells and modules can also be obtained from many other universities, research institutes and companies			
PL mapping setup	GreatEyes	LumiSolarCell	
ILIT mapping setup	Infratec	ImageIR camera and Sunfilm IR lens	
Optical microscopy	Leica	Wild M400	coupled wit
IV tester	OAI	OAI TriSol Solar Simulator	coupled wit
EQE tester	Homemade		

mation can be found here: <http://www.eternalsun.com/products/climate-chamber/>

mation can be found here: <https://www.rerasolutions.com/>

mation can be found here: <http://www.demo.tudelft.nl/>

deposition for SEM measurements

mation can be found here: <https://www.rerasolutions.com/product/tracer-iv-software/>

mation can be found here: <http://www.solliance.eu>

th a Leica DFC 320 camera and Leica Application Suite software, version 4.3.0

th a Keithley SourceMeter 2400 and controlled using IV runner software, version 1.4.0.6.





1 Alewife Center #200  
Cambridge, MA 02140  
tel. 617.945.9051  
www.jove.com

## ARTICLE AND VIDEO LICENSE AGREEMENT

Title of Article:

*In-situ monitoring of the accelerated performance degradation of solar cells and modules: a case study for C16J solar cells*

Author(s):

*Bakker, Steyvers, Roest, Havelkamp, Hielkeña, Barreau, Theelen*

Item 1 (check one box): The Author elects to have the Materials be made available (as described at

http://www.jove.com/author) via: ☐ Standard Access ☒ Open Access

Item 2 (check one box):



The Author is NOT a United States government employee.



The Author is a United States government employee and the Materials were prepared in the course of his or her duties as a United States government employee.



The Author is a United States government employee but the Materials were NOT prepared in the course of his or her duties as a United States government employee.

### ARTICLE AND VIDEO LICENSE AGREEMENT

1. **Defined Terms.** As used in this Article and Video License Agreement, the following terms shall have the following meanings: "**Agreement**" means this Article and Video License Agreement; "**Article**" means the article specified on the last page of this Agreement, including any associated materials such as texts, figures, tables, artwork, abstracts, or summaries contained therein; "**Author**" means the author who is a signatory to this Agreement; "**Collective Work**" means a work, such as a periodical issue, anthology or encyclopedia, in which the Materials in their entirety in unmodified form, along with a number of other contributions, constituting separate and independent works in themselves, are assembled into a collective whole; "**CRC License**" means the Creative Commons Attribution-Non Commercial-No Derivs 3.0 Unported Agreement, the terms and conditions of which can be found at: <http://creativecommons.org/licenses/by-nc-nd/3.0/legalcode>; "**Derivative Work**" means a work based upon the Materials or upon the Materials and other pre-existing works, such as a translation, musical arrangement, dramatization, fictionalization, motion picture version, sound recording, art reproduction, abridgment, condensation, or any other form in which the Materials may be recast, transformed, or adapted; "**Institution**" means the institution, listed on the last page of this Agreement, by which the Author was employed at the time of the creation of the Materials; "**JoVE**" means MyJoVE Corporation, a Massachusetts corporation and the publisher of *The Journal of Visualized Experiments*; "**Materials**" means the Article and / or the Video; "**Parties**" means the Author and JoVE; "**Video**" means any video(s) made by the Author, alone or in conjunction with any other parties, or by JoVE or its affiliates or agents, individually or in collaboration with the Author or any other parties, incorporating all or any portion of the Article, and in which the Author may or may not appear.

2. **Background.** The Author, who is the author of the Article, in order to ensure the dissemination and protection of the Article, desires to have the JoVE publish the Article and create and transmit videos based on the Article. In furtherance of such goals, the Parties desire to memorialize in this Agreement the respective rights of each Party in and to the Article and the Video.

3. **Grant of Rights in Article.** In consideration of JoVE agreeing to publish the Article, the Author hereby grants to JoVE, subject to **Sections 4 and 7** below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Article in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Article into other languages, create adaptations, summaries or extracts of the Article or other Derivative Works (including, without limitation, the Video) or Collective Works based on all or any portion of the Article and exercise all of the rights set forth in (a) above in such translations, adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. If the "Open Access" box has been checked in **Item 1** above, JoVE and the Author hereby grant to the public all such rights in the Article as provided in, but subject to all limitations and requirements set forth in, the CRC License.



## ARTICLE AND VIDEO LICENSE AGREEMENT

**4. Retention of Rights in Article.** Notwithstanding the exclusive license granted to JoVE in **Section 3** above, the Author shall, with respect to the Article, retain the non-exclusive right to use all or part of the Article for the non-commercial purpose of giving lectures, presentations or teaching classes, and to post a copy of the Article on the Institution's website or the Author's personal website, in each case provided that a link to the Article on the JoVE website is provided and notice of JoVE's copyright in the Article is included. All non-copyright intellectual property rights in and to the Article, such as patent rights, shall remain with the Author.

**5. Grant of Rights in Video – Standard Access.** This **Section 5** applies if the "Standard Access" box has been checked in **Item 1** above or if no box has been checked in **Item 1** above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby acknowledges and agrees that, Subject to **Section 7** below, JoVE is and shall be the sole and exclusive owner of all rights of any nature, including, without limitation, all copyrights, in and to the Video. To the extent that, by law, the Author is deemed, now or at any time in the future, to have any rights of any nature in or to the Video, the Author hereby disclaims all such rights and transfers all such rights to JoVE.

**6. Grant of Rights in Video – Open Access.** This **Section 6** applies only if the "Open Access" box has been checked in **Item 1** above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby grants to JoVE, subject to **Section 7** below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Video in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Video into other languages, create adaptations, summaries or extracts of the Video or other Derivative Works or Collective Works based on all or any portion of the Video and exercise all of the rights set forth in (a) above in such translations, adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. For any Video to which this **Section 6** is applicable, JoVE and the Author hereby grant to the public all such rights in the Video as provided in, but subject to all limitations and requirements set forth in, the CRC License.

**7. Government Employees.** If the Author is a United States government employee and the Article was prepared in the course of his or her duties as a United States government employee, as indicated in **Item 2** above, and any of the licenses or grants granted by the Author hereunder exceed the scope of the 17 U.S.C. 403, then the rights granted hereunder shall be limited to the maximum rights permitted under such

statute. In such case, all provisions contained herein that are not in conflict with such statute shall remain in full force and effect, and all provisions contained herein that do so conflict shall be deemed to be amended so as to provide to JoVE the maximum rights permissible within such statute.

**8. Likeness, Privacy, Personality.** The Author hereby grants JoVE the right to use the Author's name, voice, likeness, picture, photograph, image, biography and performance in any way, commercial or otherwise, in connection with the Materials and the sale, promotion and distribution thereof. The Author hereby waives any and all rights he or she may have, relating to his or her appearance in the Video or otherwise relating to the Materials, under all applicable privacy, likeness, personality or similar laws.

**9. Author Warranties.** The Author represents and warrants that the Article is original, that it has not been published, that the copyright interest is owned by the Author (or, if more than one author is listed at the beginning of this Agreement, by such authors collectively) and has not been assigned, licensed, or otherwise transferred to any other party. The Author represents and warrants that the author(s) listed at the top of this Agreement are the only authors of the Materials. If more than one author is listed at the top of this Agreement and if any such author has not entered into a separate Article and Video License Agreement with JoVE relating to the Materials, the Author represents and warrants that the Author has been authorized by each of the other such authors to execute this Agreement on his or her behalf and to bind him or her with respect to the terms of this Agreement as if each of them had been a party hereto as an Author. The Author warrants that the use, reproduction, distribution, public or private performance or display, and/or modification of all or any portion of the Materials does not and will not violate, infringe and/or misappropriate the patent, trademark, intellectual property or other rights of any third party. The Author represents and warrants that it has and will continue to comply with all government, institutional and other regulations, including, without limitation all institutional, laboratory, hospital, ethical, human and animal treatment, privacy, and all other rules, regulations, laws, procedures or guidelines, applicable to the Materials, and that all research involving human and animal subjects has been approved by the Author's relevant institutional review board.

**10. JoVE Discretion.** If the Author requests the assistance of JoVE in producing the Video in the Author's facility, the Author shall ensure that the presence of JoVE employees, agents or independent contractors is in accordance with the relevant regulations of the Author's institution. If more than one author is listed at the beginning of this Agreement, JoVE may, in its sole discretion, elect not take any action with respect to the Article until such time as it has received complete, executed Article and Video License Agreements from each such author. JoVE reserves the right, in its absolute and sole discretion and without giving any reason therefore, to accept or decline any work submitted to JoVE. JoVE and its employees, agents and independent contractors shall have



## ARTICLE AND VIDEO LICENSE AGREEMENT

full, unfettered access to the facilities of the Author or of the Author's institution as necessary to make the Video, whether actually published or not. JoVE has sole discretion as to the method of making and publishing the Materials, including, without limitation, to all decisions regarding editing, lighting, filming, timing of publication, if any, length, quality, content and the like.

11. **Indemnification.** The Author agrees to indemnify JoVE and/or its successors and assigns from and against any and all claims, costs, and expenses, including attorney's fees, arising out of any breach of any warranty or other representations contained herein. The Author further agrees to indemnify and hold harmless JoVE from and against any and all claims, costs, and expenses, including attorney's fees, resulting from the breach by the Author of any representation or warranty contained herein or from allegations or instances of violation of intellectual property rights, damage to the Author's or the Author's institution's facilities, fraud, libel, defamation, research, equipment, experiments, property damage, personal injury, violations of institutional, laboratory, hospital, ethical, human and animal treatment, privacy or other rules, regulations, laws, procedures or guidelines, liabilities and other losses or damages related in any way to the submission of work to JoVE, making of videos by JoVE, or publication in JoVE or elsewhere by JoVE. The Author shall be responsible for, and shall hold JoVE harmless from, damages caused by lack of sterilization, lack of cleanliness or by contamination due to the making of a video by JoVE its employees, agents or independent contractors. All sterilization, cleanliness or decontamination procedures shall be solely the responsibility of the Author and shall be undertaken at the Author's

expense. All indemnifications provided herein shall include JoVE's attorney's fees and costs related to said losses or damages. Such indemnification and holding harmless shall include such losses or damages incurred by, or in connection with, acts or omissions of JoVE, its employees, agents or independent contractors.

12. **Fees.** To cover the cost incurred for publication, JoVE must receive payment before production and publication the Materials. Payment is due in 21 days of invoice. Should the Materials not be published due to an editorial or production decision, these funds will be returned to the Author. Withdrawal by the Author of any submitted Materials after final peer review approval will result in a US\$1,200 fee to cover pre-production expenses incurred by JoVE. If payment is not received by the completion of filming, production and publication of the Materials will be suspended until payment is received.

13. **Transfer, Governing Law.** This Agreement may be assigned by JoVE and shall inure to the benefits of any of JoVE's successors and assignees. This Agreement shall be governed and construed by the internal laws of the Commonwealth of Massachusetts without giving effect to any conflict of law provision thereunder. This Agreement may be executed in counterparts, each of which shall be deemed an original, but all of which together shall be deemed to be one and the same agreement. A signed copy of this Agreement delivered by facsimile, e-mail or other means of electronic transmission shall be deemed to have the same legal effect as delivery of an original signed copy of this Agreement.

A signed copy of this document must be sent with all new submissions. Only one Agreement required per submission.

### CORRESPONDING AUTHOR:

Name: Miriam Theeler  
Department: Thin Film Technology  
Institution: TNO  
Article Title: In-situ monitoring of the CIGS solar cells  
Signature: [Signature] Date: 29/12/16

Please submit a signed and dated copy of this license by one of the following three methods:

- 1) Upload a scanned copy of the document as a pdf on the JoVE submission site;
- 2) Fax the document to +1.866.381.2236;
- 3) Mail the document to JoVE / Attn: JoVE Editorial / 1 Alewife Center #200 / Cambridge, MA 02139

For questions, please email [submissions@jove.com](mailto:submissions@jove.com) or call +1.617.945.9051





Eindhoven, October 16<sup>th</sup> 2017

Dear Alisha,

As discussed, hereby the movie instructions. I also modified the manuscript, although I don't think the added information is relevant for the reader

With kind regards,

Mirjam





## Thank you for your order!

Dear Mrs. Mirjam Theelen,

Thank you for placing your order through Copyright Clearance Center's RightsLink® service.

### Order Summary

Licensee: Mirjam Theelen  
Order Date: Jun 14, 2017  
Order Number: 4127570084389  
Publication: IEEE Proceedings  
Title: The exposure of CIGS solar cells to different electrical biases in a damp-heat illumination environment  
Type of Use: Journal/Magazine  
Order Total: 0.00 USD

View or print complete [details](#) of your order and the publisher's terms and conditions.

Sincerely,

Copyright Clearance Center

How was your experience? Fill out this [survey](#) to let us know.

Tel: +1-855-239-3415 / +1-978-646-2777  
[customercare@copyright.com](mailto:customercare@copyright.com)  
<https://myaccount.copyright.com>



RightsLink®



## Thank you for your order!

Dear Mrs. Mirjam Theelen,

Thank you for placing your order through Copyright Clearance Center's RightsLink® service.

### Order Summary

Licensee: Mirjam Theelen  
Order Date: Jun 14, 2017  
Order Number: 4127671286786  
Publication: IEEE Proceedings  
Title: In-situ monitoring of the accelerated performance degradation of thin film solar cells  
Type of Use: Journal/Magazine  
Order Total: 0.00 USD

View or print complete [details](#) of your order and the publisher's terms and conditions.

Sincerely,

Copyright Clearance Center

How was your experience? Fill out this [survey](#) to let us know.

Tel: +1-855-239-3415 / +1-978-646-2777  
[customercare@copyright.com](mailto:customercare@copyright.com)  
<https://myaccount.copyright.com>



RightsLink®



## Thank you for your order!

Dear Mrs. Mirjam Theelen,

Thank you for placing your order through Copyright Clearance Center's RightsLink® service.

### Order Summary

Licensee:	Mirjam Theelen
Order Date:	Jun 14, 2017
Order Number:	4127690016449
Publication:	Progress in Photovoltaics
Title:	The impact of alkali elements on the degradation of CIGS solar cells
Type of Use:	Journal/Magazine
Order Total:	0.00 USD

View or print complete [details](#) of your order and the publisher's terms and conditions.

Sincerely,

Copyright Clearance Center

How was your experience? Fill out this [survey](#) to let us know.

Tel: +1-855-239-3415 / +1-978-646-2777  
[customercare@copyright.com](mailto:customercare@copyright.com)  
<https://myaccount.copyright.com>



RightsLink®



## Thank you for your order!

Dear Mrs. Mirjam Theelen,

Thank you for placing your order through Copyright Clearance Center's RightsLink® service.

### Order Summary

Licensee: Mirjam Theelen  
Order Date: Jun 14, 2017  
Order Number: 4127570084389  
Publication: IEEE Proceedings  
Title: The exposure of CIGS solar cells to different electrical biases in a damp-heat illumination environment  
Type of Use: Journal/Magazine  
Order Total: 0.00 USD

View or print complete [details](#) of your order and the publisher's terms and conditions.

Sincerely,


Copyright Clearance Center

How was your experience? Fill out this [survey](#) to let us know.

Tel: +1-855-239-3415 / +1-978-646-2777  
[customercare@copyright.com](mailto:customercare@copyright.com)  
<https://myaccount.copyright.com>



RightsLink®



## Thank you for your order!

Dear Mrs. Mirjam Theelen,

Thank you for placing your order through Copyright Clearance Center's RightsLink® service.

### Order Summary

Licensee: Mirjam Theelen  
Order Date: Jun 14, 2017  
Order Number: 4127690198017  
Publication: Solar Energy Materials and Solar Cells  
Title: Stability of CIGS solar cells under illumination with damp heat and dry heat: A comparison  
Type of Use: reuse in a journal/magazine  
Order Total: 0.00 USD

View or print complete [details](#) of your order and the publisher's terms and conditions.

Sincerely,

Copyright Clearance Center

How was your experience? Fill out this [survey](#) to let us know.

Tel: +1-855-239-3415 / +1-978-646-2777  
[customercare@copyright.com](mailto:customercare@copyright.com)  
<https://myaccount.copyright.com>



RightsLink®

Dear Ms. Theelen,

Thank you for seeking permission from SPIE to reprint material from our publications. As author, SPIE shares the copyright with you, so you retain the right to reproduce your paper in part or in whole.

Publisher's permission is hereby granted under the following conditions:

(1) the material to be used has appeared in our publication without credit or acknowledgment to another source; and

(2) you credit the original SPIE publication. Include the authors' names, title of paper, volume title, SPIE volume number, and year of publication in your credit statement.

Sincerely,

Nicole Harris  
Administrative Editor, SPIE Publications  
1000 20th St.  
Bellingham, WA 98225  
+1 360 685 5586 (office)  
[nicoleh@spie.org](mailto:nicoleh@spie.org)

SPIE is the international society for optics and photonics. <http://SPIE.org>

**SPIE.**



## Thank you for your order!

Dear Mrs. Mirjam Theelen,

Thank you for placing your order through Copyright Clearance Center's RightsLink® service.

### Order Summary

Licensee: Mirjam Theelen  
Order Date: Aug 10, 2017  
Order Number: 4165260964470  
Publication: Journal of Renewable and Sustainable Energy  
Title: Determination of the temperature dependency of the electrical parameters of CIGS solar cells  
Type of Use: Journal/Magazine  
Order Total: 0.00 USD

View or print complete [details](#) of your order and the publisher's terms and conditions.

Sincerely,

Copyright Clearance Center

How was your experience? Fill out this [survey](#) to let us know.

Tel: +1-855-239-3415 / +1-978-646-2777  
[customer@copyright.com](mailto:customer@copyright.com)  
<https://myaccount.copyright.com>



RightsLink®





## Step 4.1

### Initializing the software

On the computer there is installed the monitoring software for logging the data from the measurements and keep record of all the conditions applied to the solar devices. The software is called Tracer 3 (Figure 1).




Figure 1: Desktop icon for the software

## Step 4.2 (Climate chamber)

### Input of the climate chamber

Let's now move on the programming of the climate chamber controls (Figure 2), the setting can be input through the touch screen on the left hand side of the machine.

There are two main type of condition that can be applied:

1. Constant mode, where the values of temperature and relative humidity will be fixed to a constant value and kept until the CC is turned off;
2. Programmable mode, where it is possible to input the values of temperature and relative humidity as function of time.




Figure 2: Home screen for climate chamber control

We chose the third quadrant option 'Program setup'

#### Third quadrant

With this selection it is possible to schedule the temperature and relative humidity as function of time creating a program that handle the environmental conditions.

After pressing the selection in the 3<sup>rd</sup> quadrant we are in front of all the programs in the Katrien CC memory, as visible in Figure 3, pressing on the single program we will see the detailed conditions scheduled for this program, Figure 4 .




Figure 3: Programs list




Figure 4: Detail of first 3 steps of DH + illumination experiment

From the Figure 4 it is possible to retrieve the environmental conditions applied for each step and the duration of it. When the environmental value has got an arrow nearby (as for temperature in step 1 Figure 4) it means that there is a speed control to reach that value at the end of the step, when there is a dot nearby the value means that this is kept constant at the stated condition.

For example in Figure 4 there is a controlled cooling in 30 minutes to reach -10°C and kept constant for other 30 minutes during step 2.

When we press on “Input” button we enter the editing mode, as in Figure 5, where it is necessary to select one step in order to modify the specific environmental condition applied.






Figure 5: Editing MODE selection of the step

We then make a stabilisation period at room temperature, followed by a slow temperature ramp until 85°C. Then we turn on the relative humidity to 85% and we leave it like this for e.g. 1000 hours.

We can use the start button to start the requested program (Figure 6).




Figure 6: Editing MODE selection of the step

#### Program the computer (step 4.2, computer)

##### Specimens parameters

Furthermore when the specimens will be in place with the correct electrical connection and the thermocouple attached to them, it is necessary to input some solar cells characteristics in the Tracer

3 software (Figure 7) in order to perform a correct analysis of the solar device, the values necessary are:

- Sample connection position code (1-32)
- Sample Name
- Thermocouple corresponding to the sample
- Correct surface of the active area




Figure 7: Homepage of Tracer 3 software

In order to input in the software the above mentioned parameters it is necessary to go to Hardware settings → Multiplexer → MultiplexerPresents as in Figure 8. In this window it is necessary to define a name (Label) for the selected port (example Cell 1), as well as the active area and the temperature input (corresponding to the thermocouple attached to the device).




Figure 8: Input of surface active area and thermocouple linked to the solar cell

Press apply to confirm the changes and record the data.

### Defining the measurement settings

## Programming of the Tracer 3 (Rera) for continues monitoring

It is now necessary to define the parameters for the IV measurements (Figure 9) that will be performed, in particular the value to input are :

- Start voltage [V]
- Stop Voltage [V]
- Step [mV] or number of points




Figure 9: Input measurement settings

In order to record the data from the IV measurements the PC is connected to a local server that log those data, this PC is not connected directly from internet due to safety reasons.

Pressing on the start button on the top left hand corner and selecting Options (Figure 10) we will see the window as in Figure 11. In that picture there are expressed the location in which the local file will be stored, those are 2 types: local IV raw data and project files.




Figure 10: Start menu




Figure 11: Auto save location (local IV(T) files and project files)

## Program the electrical loads (step 4.2, electrical loads)

### Electric loads

In order to edit the electric loads parameters it is necessary to go Hardware settings → Electrical Bias → ReRa CAN Loads as in Figure 12. There are 32 electric loads available one each device that can be fit in the climate chamber for the experiment.

When double clicking on a specific load the window as in Figure 13 will be visible and it is possible to edit the voltage applied to the solar device. In case of changing the Voltage setpoint it is necessary to send the updated to the load.

Loads with the tick are connected, without disconnected.

The screenshot shows the Tracer3 software interface. The top menu bar includes Home, Measurement, Analysis, and Data. The left sidebar shows a tree view of hardware settings, with 'ReRa CAN Loads' selected under 'Electrical Bias'. The main window displays the 'CAN loads' configuration table.

Id	Connected	Setpoint [V]	Max fix current	allow 1A	Voltage [V]	Current [mA]
1	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
2	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
3	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
4	<input checked="" type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
5	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
6	<input checked="" type="checkbox"/>	0.3	0.05	<input type="checkbox"/>	0	0
7	<input checked="" type="checkbox"/>	0.16	0.05	<input type="checkbox"/>	0	0
8	<input checked="" type="checkbox"/>	0.133	0.05	<input type="checkbox"/>	0	0
9	<input checked="" type="checkbox"/>	0.26	0.05	<input type="checkbox"/>	0	0
10	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
11	<input checked="" type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
12	<input checked="" type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
13	<input checked="" type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
14	<input checked="" type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
15	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
16	<input checked="" type="checkbox"/>	0.13	0.05	<input type="checkbox"/>	0	0
17	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
18	<input checked="" type="checkbox"/>	-0.5	0.05	<input type="checkbox"/>	0	0
19	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
20	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
21	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
22	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
23	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
24	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
25	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
26	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
27	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
28	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0
29	<input type="checkbox"/>	0	0.05	<input type="checkbox"/>	0	0

Figure 12: Electric loads overview






Figure 13: Edit load window

### Sequence measurement

Finally it is possible to define a sequence of solar devices to be measured. Pressing the arrow under “Check contact” in the top right hand corner we will see a window where we can insert the number and code of the devices to be measured and their order, as in Figure 14.





Figure 14: Edit of sequence for continues measurement.

Press “New sequence ” and input the name of the sequence of solar devices. From the commands window we can now select the location of the solar device we are interested into and add them to the list of the monitored specimens. Pressing “Ok” we confirm and save the sequence.

Pressing on “Automatic Sequence” (Figure 15) it is possible to start the continues IV measurements and edit the waiting time between a sequence and the next one.




Figure 15: Automatic sequence start-up.

### Monitoring the climate chamber (step 4.3 and 4.4)

With the second quadrant option, we can monitor the climate chamber. Figure 16 represents the monitoring interface of the CC, as saying the screen where there a reported the set point value of temperature and relative humidity, as well as the current value registered inside the machine.

In these steps, the temperature will go up to 85°C, while the RH will stay close to zero.

Second quadrant option

Current program state




Figure 16: Monitoring interface for CC

Measure the IV curves (step 4.5)

Show a few curves occurring during measurements




Figure 17: Page showing the IV measurements

Monitoring the climate chamber (step 4.6)

With the second quadrant option, we can monitor the climate chamber. The Figure 16 represents the monitoring interface of the CC, as saying the screen where there a reported the set point value of temperature and relative humidity, as well as the current value registered inside the machine.

In these steps, the temperature will remain 85°C, while the RH will rapidly increase to 85% RH.

Second quadrant option

Current program state




Figure 18: Monitoring interface for CC

#### Measure the IV curves (step 4.7)

Similar screen as step 4.5

#### Cooling down the climate chamber (step 4.9)

With the second quadrant option, we can monitor the climate chamber. The Figure 16 represents the monitoring interface of the CC, as saying the screen where there a reported the set point value of temperature and relative humidity, as well as the current value registered inside the machine.

In these steps, the relative humidity will first rapidly go to a low value, after which the temperature will slowly go back to room temperature.

Second quadrant option

Current program state




Figure 19: Monitoring interface for CC