Journal of Visualized Experiments

Functional and Physiological Methods of Evaluating Median Nerve Regeneration in the Rat --Manuscript Draft--

Methods Article - Author Produced Video
JoVE59767R3
Functional and Physiological Methods of Evaluating Median Nerve Regeneration in the Rat
JoVE Medicine
Median nerve; nerve regeneration; peripheral nervous system; repair; rat; experimental model; surgery; functional tests.
Diogo Casal, M.D. NOVA Medical School, Universidade NOVA de Lisboa Lisbon, Lisbon PORTUGAL
NOVA Medical School, Universidade NOVA de Lisboa
diogo_bogalhao@yahoo.co.uk
Diogo Casal, M.D.
Eduarda Mota-Silva
Ines Iria
Diogo Pais
Ana Farinho
Sara Alves
Claudia Pen
Luis Mascarenhas-Lemos
José Ferreira-Silva
Mário Ferraz-Oliveira
Valentina Vassilenko
Paula Videira
João Goyri-O'Neill
Response
Open Access (US\$3000)

Cover Letter

Dear Editor of the Journal of Visualized Experiments (JoVE),

We take the liberty of submitting the manuscript of a paper entitled "Functional and physiological methods of evaluating median nerve regeneration in the rat" for publication in the Journal of Visualized Experiments (JoVE).

Arguably, using the median nerve (MN) of the rat, it is possible to adequately replicate peripheral nerve lesions in humans. ¹⁻³ In this paper we present a model of peripheral nerve lesion and repair in the rat. In particular, we demonstrate in a detailed fashion the steps required to produce and repair different types of MN lesions in the rat. Moreover, we illustrate the use of different settings adequate to simulate postoperative physiotherapy. Finally, we show how to evaluate functional recovery of this nerve using several tests.

We strongly believe that this model is particularly indicated to replicate the clinical scenario, facilitating extrapolation of results to the human species.

We base this description in our groups' 15-year experience with the use of this model for both teaching and research purposes.^{1,4} To make this subject more perceptible to a wider audience, we have included an original professional-drawn diagram illustrating the relevant anatomy of the MN in the rat.

We believe this paper will undoubtedly be of great interest to the readers of **JoVE**, as the MN model has multiple advantages relatively to the most commonly used sciatic nerve model.

We very much hope you decide to publish it!
If you have any doubts or queries, please do not hesitate to contact us.
Thank you so much for your kind time and attention.
Yours sincerely.

The authors

References

- Casal, D. *et al.* Reconstruction of a 10-mm-long median nerve gap in an ischemic environment using autologous conduits with different patterns of blood supply: A comparative study in the rat. *PLoS One.* **13** (4), e0195692, doi:10.1371/journal.pone.0195692, (2018).
- Stößel, M., Rehra, L. & Haastert-Talini, K. Reflex-based grasping, skilled forelimb reaching, and electrodiagnostic evaluation for comprehensive analysis of functional recovery—The 7-mm rat median nerve gap repair model revisited. *Brain and Behavior.* **7** (10), e00813, doi:10.1002/brb3.813, (2017).
- Manoli, T. *et al.* Correlation analysis of histomorphometry and motor neurography in the median nerve rat model. *Eplasty.* **14** e17 (2014).
- 4 Angelica-Almeida, M. *et al.* Brachial plexus morphology and vascular supply in the wistar rat. *Acta Med Port.* **26** (3), 243-250 (2013).

1	TITLE:		
2	Functional and Physiological Methods of Evaluating Median Nerve Regeneration in the Rat		
3			
4	AUTHORS AND AFFILIATIONS:		
5 6	Diogo Casal ^{1,2*} , Eduarda Mota-Silva ^{3*} , Inês Iria ^{4,5} , Diogo Pais ¹ , Ana Farinho ⁶ , Sara Alves ⁷ , Cláud Pen ⁷ , Luís Mascarenhas-Lemos ⁷ , José Ferreira-Silva ⁷ , Mário Ferraz-Oliveira ⁷ , Valentii		
7 8	Vassilenko ³ , Paula A. Videira	a ^{4,5} , João Goyri-O'Neill ¹	
9	¹ Anatomy Department, NO	VA Medical School, Lisbon, Portugal	
10	² Plastic and Reconstructive	Surgery Department and Burn Unit, Centro Hospitalar de Lisboa	
11	Central, Lisbon, Portugal		
12	³ LIBPhys, Physics Departme	nt, Faculty of Sciences and Technology, Lisbon, Portugal	
13	⁴ Glycoimmunology, CEDOC,	NOVA Medical School, Lisbon, Portugal	
14	⁵ UCIBIO, Life Sciences Depa	artment, Faculty of Sciences and Technology, Universidade NOVA de	
15	Lisboa, Lisbon, Portugal		
16	⁶ Tissue Repair Unit, CEDOC,	NOVA Medical School, Lisbon, Portugal	
17	⁷ Pathology Department, Centro Hospitalar de Lisboa Central, Lisbon, Portugal		
18			
19	*These authors contributed	l equally	
20			
21	Email Address of the Corres	ponding Author:	
22	Diogo Casal	(diogo_bogalhao@yahoo.co.uk)	
23			
24	Email Addresses of Co-auth	nors:	
25	Eduarda Mota-Silva	(emd.silva@campus.fct.unl.pt)	
26	Inês Iria	(inesraqueliria@gmail.com)	
27	Diogo Pais	(diogo.pais@nms.unl.pt)	
28	Ana Farinho	(ana.farinho@nms.unl.pt)	
29	Sara Alves	(<u>saraalves79@hotmail.com</u>)	
30	Cláudia Pen	(penfreitas@gmail.com)	
31	Luís Mascarenhas-Lemos	(<u>luisalbuquerquemascarenhas@gmail.com</u>)	
32	José Ferreira-Silva	(jose.ferreira.silva@chlc.min-saude.pt)	
33	Mário Ferraz-Oliveira	(malexferraz@sapo.pt)	
34	Valentina Vassilenko	(<u>vv@fct.unl.pt</u>)	
35	Paula A. Videira	(videirapaula@gmail.com)	
36	João Goyri-O'Neill	(goyrioneill@gmail.com)	
37			
38	KEYWORDS:		
39	median nerve, nerve regeneration, peripheral nervous system, repair, rat, experimental model,		
40	surgery, functional tests		
41			
42	SUMMARY:		

Presented is a protocol to produce different types of median nerve (MN) lesions and repair in the rat. Additionally, the protocol shows how to evaluate the functional recovery of the nerve using several noninvasive behavioral tests and physiological measurements.

ABSTRACT:

The main goal of this investigation is to show how to create and repair different types of median nerve (MN) lesions in the rat. Moreover, different methods of simulating postoperative physiotherapy are presented. Multiple standardized strategies are used to assess motor and sensory recovery using an MN model of peripheral nerve lesion and repair, thus permitting easy comparison of the results. Several options are included for providing a postoperative physiotherapy-like environment to rats that have undergone MN injuries. Finally, the paper provides a method to evaluate the recovery of the MN using several noninvasive tests (i.e., grasping test, pin prick test, ladder rung walking test, rope climbing test, and walking track analysis), and physiological measurements (infrared thermography, electroneuromyography, flexion strength evaluation, and flexor carpi radialis muscle weight determination). Hence, this model seems particularly appropriate to replicate a clinical scenario, facilitating extrapolation of results to the human species.

Although the sciatic nerve is the most studied nerve in peripheral nerve research, analysis of the rat MN presents various advantages. For example, there is a reduced incidence of joint contractures and automutilation of the affected limb in MN lesion studies. Furthermore, the MN is not covered by muscle masses, making its dissection easier than that of the sciatic nerve. In addition, MN recovery is observed sooner, because the MN is shorter than the sciatic nerve. Also, the MN has a parallel path to the ulnar nerve in the arm. Hence, the ulnar nerve can be easily used as the nerve graft for repairing MN injuries. Finally, the MN in rats is located in the forelimb, akin to the human upper limb; in humans, the upper limb is the site of most peripheral nerve lesions.

INTRODUCTION:

Peripheral nerve lesions occur regularly as a result of trauma, infection, vasculitis, autoimmunity, malignancy, and/or radiotherapy^{1,2}. Unfortunately, peripheral nerve repair continues to present clinically unpredictable and frequently disappointing results^{3,4}. There is widespread consensus that considerable basic and translational research is still needed to improve the prospect of those affected⁴⁻⁷.

The rat MN shows great similarities to that of humans^{8,9} (**Figure 1**). Originating from the brachial plexus in the axillary region, this nerve descends into the medial aspect of the arm, reaching the elbow, and branching off to the majority of the muscles in the ventral compartment of the forearm. The MN reaches the hand, where it innervates the thenar muscles and the first two lumbrical muscles as well as to part of the rat's hand skin⁹ (**Figure 1**).

Using the rat MN, it is possible to adequately replicate peripheral nerve lesions in humans¹⁰⁻¹². This nerve has several potential research advantages relative to the customarily used sciatic nerve. Because the MN is located in the forelimb of rats (akin to the human upper limbs), it can

Page 1 of 19 revised May 2019

be damaged experimentally with a much smaller impact on the rat's wellbeing, compared to the sciatic nerve, which innervates a substantial portion of the pelvic limb¹³. Additionally, in humans most clinical lesions occur in the upper limb, which corresponds to the rat's forelimb^{10-12,14-16}.

This paper shows how to produce different types of MN lesions in the rat. Moreover, different ways to simulate postoperative physiotherapy are presented. Finally, tests to evaluate functional recovery of the MN are described. There are multiple standardized strategies available to assess motor and sensory recovery using an MN model of peripheral nerve lesion and repair, thus permitting an easy comparison of results. The MN model is particularly suitable to replicate the clinical scenario, facilitating extrapolation of results to the human species.

PROTOCOL:

All procedures involving animal subjects were approved by the Institutional Animal Care and Use Committee and Ethical Committee at Nova University Medical School, Lisbon, Portugal (08/2012/CEFCM).

1. Median nerve surgery

NOTE: Follow aseptic technique during the surgery. Use personal protective instruments (PPE) and wear a sterile surgical gown¹⁷. Autoclave all the required surgical instruments prior to the surgery (see the **Table of Materials**).

1.1. Use 12-week-old Wistar rats. Provide them with ad libitum food and water with 12 h light-dark cycles 7 days prior to surgery. Prior to anesthesia, weigh the rat to determine the amount of anesthetic required.

1.2. Anesthetize the rat with an intraperitoneal injection of a mixture of ketamine (40–80 mg/kg body weight) and xylazine (5–10 mg/kg of body weight). Check for the depth of anesthesia by the lack of response to a toe pinch and by observing of respiration rate throughout the entire procedure ^{18,19}. Provide additional analgesia if a respiratory rate over 110 cycles/min or motor response to toe pinching is observed ^{18,20}.

1.3. Inject 1 mg/kg of meloxicam subcutaneously to provide preemptive analgesia^{20,21}.

1.4. To avoid corneal abrasion during the surgery, apply ophthalmic gel to both the eyes.

1.5. Use a depilatory cream to remove the hair over the medial aspect on the right. Once done,
 wash with warm saline to remove the cream¹⁷.

- 1.6. Lay the rat in supine position on a heating pad. Apply an iodine or chlorhexidine-based surgical scrub over the operative site. Leave it for at least 15 s and then wipe with ethanol. Repeat the application 3x. Ensure that the scrub is in contact with the skin for at least 2 min prior to
- 130 proceeding with the surgery.

NOTE: Contact the infection control authority at your research unit for alternative protocols to prevent surgical site infection¹⁹.

134

135 1.7. Drape the surgical area¹⁷.

136

137 NOTE: Perform all procedures under strict aseptic conditions¹⁹.

138

1.8. Incise the skin in the medial aspect of the right arm and pectoral region to the deep fascial plane, using a number 15 scalpel blade. Carefully cauterize any bleeding vessels using an electric cautery.

142

1.9. Carefully divide the brachial fascia, which presents as a whitish sheath covering the muscles,
 using a thermocautery or a pair of blunt scissors, taking care not to damage the vascular and
 nerve structures in the medial aspect of the arm.

146

1.10. Open a pair of scissors bluntly beneath the terminal insertion of the pectoralis major muscle, in order to tease this muscle away from the underlying axillary artery and vein, as well as from the terminal branches of the brachial plexus.

150

1.11. Divide the insertion of the pectoralis major muscle with an electric cautery. Expose and section the pectoralis minor muscle.

153

1.12. Bluntly dissect the MN from the brachial vessels and from the ulnar nerve starting from the axillary region up to the elbow. This allows exposure of the different terminal branches of the brachial plexus, namely the median, the ulnar, the radial, the axillary and the musculocutaneous nerves (**Figure 2**).

158

1.13. Separate different experimental groups as described below.

160

161 1.13.1. Create the *Sham* group by only dissecting the MN.

162

1.13.2. Create the *Crush* group by compressing the MN in the middle portion of the arm for 15 s using a number 5 microsurgery forceps, or a similar instrument^{22,23}.

165

1.13.3. Create the *Excision* group using a pair of microsurgery scissors to excise a 10 mm-long segment from the central part of the MN in the arm. Ligate the proximal stump of the nerve with an 8/0 Nylon suture to prevent axonal growth.

169

1.13.4. Create the *Graft* group using the 10 mm-long-segment of the MN described in the latter step and rotating it 180°. Suture the proximal and distal stumps of the sectioned MN to the nerve graft using interrupted 10/0 Nylon stitches.

173

1.74 1.14. Close the skin wound using interrupted 5/0 Nylon stitches^{10,24}.

Page 3 of 19

175176

1.15. Provide postoperative analgesia with 7 mL of cherry-flavored acetaminophen mixed with
 43 mL of tap water²⁵ to obtain a concentration of 4.48 mg/mL in 50 mL plastic water bottles made
 available to the rats ad libitum for 3 days²⁵.

179 180

2. Housing and physiotherapy

181

2.1. Allow rats to have contact with the physiotherapy apparatuses 2–4 weeks before surgery, in order to ensure an easier and faster adaptation to the exercise settings. Perform the exercises by following the procedures detailed below.

185

2.2. Once a day, place each rat inside an individual physiotherapy sphere, and subsequently place
 the sphere in a room with few obstacles. Let the rat ambulate and explore the room freely for
 half an hour.

189

2.3. House the rats individually in solitary cages with incorporated running wheels to help themexercise.

192

2.4. Form groups of 4–5 animals and house these groups in personalized cages. Personalize the cages by including ladders, ropes, running wheels, and other environmental enriching elements.

195

196 2.5. Return individual rats to personalized cages the day after surgery.

197

2.6. Resume physiotherapy exercises 3 days after surgery.

198199200

3. Functional tests

201202

203

204

3.1. One week before starting to perform the functional tests, familiarize the rats with the food treats to be used as positive reinforcement. Provide this reinforcement after the successful completion of each test, before and after surgery. After the initial training period of 3 weeks, resume all tests 1 week after surgery.

205206207

3.2. Conduct the tests in the evening, when the rats are naturally more active. Resume tests 1week after surgery.

209

3.3. Perform the Grasping Test by placing the rat on a grid and lift it by its tail, letting it grab the grid with its forepaws^{11,26}. Assign a "Positive" score if the rat can grab the grid with both forepaws. Assign a "Negative" score if the rat cannot grab the grid with the injured paw.

213

NOTE: A positive Grasping Test indicates that the motor component of the MN is functioning^{16,27}.

215

3.4. Perform a Pin Prick Test^{28,29}.

217

3.4.1. Make a plastic platform with a 4 mm x 4 mm square grid pattern. Provide support to this

Page 4 of 19

219 grid with a 21 cm long metallic frame.

220

3.4.2. Place the rat on the platform and cover the grid with a 15.5 cm x 15.5 cm x 11 cm transparent plastic box. Wait for few minutes until normal activities (e.g., exploratory and major grooming) subside.

224

3.4.3. Start the test when the rat is stationary and standing on its four paws.

226

3.4.4. With the help of a mirror, insert an aesthesiometer (e.g., number 4 Von Frey hair with a bending force of 25 g) through the mesh and poke the palmar aspect of the forepaw in the skin territory of the MN (**Figure 1**). Repeat the assessment 5x on each forepaw alternatively, waiting a few seconds after each evaluation.

231

3.4.5. Check for the bending of the Von Frey filament³⁰ for the correct evaluation. Score the withdrawal responses as follows: "0" for no withdrawal response, "1" if the rat slowly removes the paw from the filament, "2" if the rat quickly responds to the stimulus and removes the paw or licks the paw.

236

NOTE: If ambulation and biting of the filament are observed repeat the stimulus, because these are considered ambiguous responses.

239

3.5. Training sessions

241242

243

244

245

NOTE: Train the rats daily for 3 weeks before performing the surgery in the evening in a low-light environment. The training sessions are recommended specially for the rope climbing, ladder rung, and walking tracks tests. These can be done in the order presented before, starting with the rope climbing test, ladder rung, and finally walking tracks test. Allow the same animal a few minutes of rest before a new test.

246247248

249

250

3.5.1. During the first week, place the rat on the last third of the ladder/rope/corridor, close to the box's entrance. Condition the animal to move towards the box opening by gently touching and/or pulling the tip of its tail. Provide the rat a food treat once it enters the box, allowing it some seconds of rest before repeating the test. Repeat it 5x each day for 5 days.

251252

3.5.2. During the second week, place the animal on the second third of the ladder/rope/corridor Repeat the steps in 3.5.1.

255

3.5.2. During the third week, place the rat on the bottom of the ladder/rope/corridor, on the opposite side of box's entrance. Repeat the steps in 3.5.1, but only reward the animal when it completes the test correctly.

259

3.6. Perform the Ladder Rung Test.

261

NOTE: This test is used for assessing forelimb strength, stepping, placing, and coordination³¹.

revised May 2019

Page 5 of 19

3.6.1. Place the rat at the bottom of the ladder (120 cm x 9 cm x 2 cm with 18 steps 1.5 cm-thick,
 spaced 4 cm apart) and gently touch the rat's tail. Ensure that the ladder is placed at an inclination of 10° and leads to a 13.20 cm x 11 cm opening on a dark wooden 31.5 cm x 35 cm x 35 cm box.

267

3.6.2. Start the timer once the rat starts climbing the ladder and stop the timer once the rat's snout crosses the box's entrance.

270

3.6.3. Record the time and repeat the test 3x, each separated at least by a 1 min interval.

272

273 3.7. Rope Climbing

274

NOTE: This test is used for assessing grasping strength, which is dependent on MN recovery³².

276

- 3.7.1. Put the rat at the bottom of the rope and persuade it to climb by gently touching its tail.
 Start the timer once the animal starts climbing and stop it the moment the rats' snout crosses
- the platform's entrance.

280

- 3.7.2. For each test, record the time taken to climb to the platform and the number of slips of
- the injured paw while the rat climbs up the rope. Consider the test valid if the animal does not
- hesitate during the task or does not stop climbing. Provide the rat with a snack after performing
- the task correctly.

285286

3.7.3. Record the time and repeat the test 3x, each separated at least by a 1 minute interval.

287

288 3.8. Walking Tracks

289290

NOTE: This test is used for the evaluation of forelimb motor recovery^{33,34}.

291292

293

294

3.8.1. Set up an apparatus consisting of a confined walkway 16.5 cm in height x 8.7 cm in width x 43 cm in length. Ensure that this leads to a rectangular 8.8 cm x 8.2 cm opening in one of the walls of a black wooden 23 cm x 36 cm x 28 cm box. Include a vertical sliding door to close the box's entrance rapidly. Include a removable top to be used for retrieving the $rat^{33,34}$.

295296297

298

299

3.8.2. Place a piece of graph paper on the corridor's floor. Grab the rat by its tail and let it hold a painting brush soaked in methylene blue. Position the rat at the entrance of the corridor to make it walk inside the box. Remove the graph paper from the corridor's floor and repeat the test until a good representative impression of both forepaws is obtained.

300 301

3.8.3. From the obtained prints, select one with clear successive forepaw prints, photograph them in a tiff or jpeg format, and measure the following parameters using the open access software FIJI³⁵.

305

NOTE: First, calibrate each image using the markings in the graph paper (Analyze | Set scale)

Page 6 of 19

307 Second, convert each image to an 8-bit format (Image | Type | 8-bit). Subsequently, use the 308 **Rectangular Selection Tool** to select the paw print. Crop this portion of the image (Image | Crop). 309

In each image, highlight the pawprints and remove the background by thresholding the image

310 (Image | Adjust | Threshold).

311

312 3.8.3.1. Measure the stance factor by measuring the paw impression area. Use the Rectangular 313 **Selection Tool** to select the paw print and press **Control + M**.

314

315 3.8.3.2. Measure the print length factor by measuring the longest length of the paw impression 316 (for steps 3.8.3.2–3.8.3.6, use the Straight-Line Selection Tool for selecting the two most distant 317 points and press Control + M).

318

319 3.8.3.3 Measure the finger spread factor by measuring the widest width of the paw impression.

320

321 3.8.3.4. Measure the intermediate finger spread factor by measuring the widest width between 322 the second and third fingers.

323

324 3.8.3.5. Measure the stride length by measuring the distance between homologous points of 325 successive paw impressions on a given side.

326

327 3.8.3.6. Measure the base of the support by measuring the perpendicular distance between the central portion of the paw impression and the direction of movement^{29,33,36}. 328

329

330 NOTE: Perform the last two measurements in two pairs of representative consecutive bilateral 331 paw impressions³³.

332 333

4. Physiological measurements

334

4.1 Infrared Thermography (IRT)³⁷⁻³⁹. 335

336

337 4.1.1. Ensure that the temperature of the room where the measurements will be performed is 338 between 18 °C-25 °C using a normal digital hydrothermometer with a thermal resolution of 0.1 339 °C. Ensure that no significant heat sources (e.g., computers or refrigerators) are present.

340 341

4.1.2. Acclimate the rats by bringing them to the evaluation room 2 h prior to the evaluation. Before starting the experiment, anesthetize the rat as described above (steps 1.3-1.6) or following the institution's protocol. Check for the lack of the response to a toe pinch before starting the experiment.

344 345

342

343

346 4.1.3. Switch on the infrared thermographic camera 15 min prior to the acquisition and do not 347 turn it off during the evaluations. Set the emissivity parameter of the camera to match that of 348 the rat's skin ($\epsilon = 0.98$)^{37,40,41}.

349

350 4.1.4. Place the rat on its dorsum on a clean and stable surface with a polyethylene sponge.

Page 7 of 19

Ensure that there are no reflective materials and other possible sources of artefacts. Fix its forepaws carefully in supination with double face glue tape. Insert a digital thermometer 2 cm inside the rectum to monitor the rat's central temperature during all evaluations.

4.1.5. Hold the thermographic camera at a 90° angle and 30 cm distance from the rat. Focus the camera on the whole animal's body. Obtain three infrared thermography images spaced 30 s apart.

4.1.6. Transfer the acquired thermograms to a computer and analyze them using analysis software. Define the temperature of the plantar surface of both forepaws using a fixed rectangular region of interest (e.g., 9 x 11 pixels) in the plantar territory of the MN, for example in the center of the first metacarpal foot pad (**Figure 1**). Using the free FLIR Tools software, select the thermography by double clicking on it. On the left tools bar select the button "**Add box measurement tool**" and draw a rectangle of 9*11 pixels over the plantar area of both forepaws. While adjusting the rectangle its dimension in pixels can be confirmed. Perform it on both forepaws. On the right side of the image find the maximum, minimum, and average temperatures.

4.1.7. Over the previously drawn ROI, right click and select export. The mean, maximum, and minimal temperatures, as well as a matrix of temperatures of the ROI are then exported to a .csv document. These data can later be explored using data analysis software.

373 4.2. Electroneuromyographic (ENMG) Evaluation

4.2.1. Set up an electrical stimulator. Tape a pair of disposable acupuncture needles (0.25 mm x 25 mm) with a negligible impedance [$<1~\Omega$]) and 25 mm between them to create electrodes for stimulation. Now connect the stimulator and the electrode to a data acquisition unit to take the incoming signals and convert them into digital signals that can be processed with the computer software.

4.2.1. Perform the evaluations in the same room, and always under the same controlled environmental conditions⁴²⁻⁴⁴. Pinch the forepaw to ensure that the rats are deeply anesthetized before starting data acquisition.

NOTE: Deep anesthesia is of paramount importance to minimize variability associated with spontaneous voluntary and/or involuntary movements by the rats⁴³.

4.2.2. Expose the MN on both sides under the surgical microscope as described in steps 1.8–1.13.
 Use a number 15 scalpel blade to prolong the brachial incisions into the forearms with a ventral midline incision.

4.2.3. Expose the superficial aspect of the flexor digitorum sublimis muscles by bluntly separating the overlying antebrachial fascia using iris scissors. Insert the ground needle in the quadriceps femoris muscle of the left hindlimb to connect the signal ground plug.

Page 8 of 19 revised May 2019

4.2.4. Start with the right forepaw and place the recording electrodes into the flexor digitorum sublimis muscle belly of the forepaw and the stimulation electrode proximal to the lesion site in the MN. Moisten these electrodes with saline.

4.2.5. Ensure that the software is set as follows: channel input port 1 (CH1) – stimulator to 0–10 V; and channel input port 2 (CH2) - EMG to 30–1,000 Hz. Start by choosing a stimulation amplitude of 10 mV and record the compound muscle action potentials CMAPs sample rate of 50 kHz for a duration of 40,000 ms. Gradually increase the stimulation amplitude in 10 mV steps until reaching 2,000 mV. Repeat the same for the left paw $^{42-44}$.

NOTE: The signal is amplified to 1,000x and filtered using a 30-1,000 Hz band. The stimulation output is set for a single pulse with a duration of 1 ms⁴²⁻⁴⁴.

4.2.6. Open the recorded file in the recording apparatus software.

NOTE: By default, the screen will show tow windows on top in red, the stimulator pulses, and below in blue the recorder ENMGs. Sliding the horizontal scroll bar underneath the time scale allows visualization of the full record. The two main tools, **Zoom tool** and **I-Beam tool**, are on the bottom right side of the panel. Using the **Zoom tool**, it is possible to optimize the visualization of the CMAPs and explore the graphics. To guarantee a good fitting on the visualization screen, it may be necessary to adjust the display after zooming. To do so, select **Display|Autoscale Waveforms**. The **I-beam tool** allows the selection of specific areas of the graphs and performance of the desired measurements. On top of the graphs, there are three small windows where the measurements are displayed. **P-P** shows the average amplitude value of the selected area in volts (both in the stimulator record and in ENMGs), whereas **Delta-T** shows the time interval of that selection.

4.2.7. Measure the parameters from the compound muscle action potential (CMPAs, described in **Table 1**) using the homonymous measurement tools from the software plug in "*Toolbox for unsupervised classification of MUAPs and action potentials in EMG*"⁴⁵.

4.2.8. For each rat, determine a minimal value of stimulation voltage after which the CMAPs amplitude does not increase further. Start from a 0.05 mV stimulus, and give successive increasing stimuli in incremental voltages of 0.05 mV.

431 4.2.9. Apply a stimulus 20% above this voltage in order to obtain a supramaximal stimulation value.

4.2.10. After the latter value is determined and the corresponding stimulus applied, record the next CMAPs parameters.

437 4.3. Flexion strength evaluation

4.3.1. Use the same stimulator and stimulation electrodes to electrically stimulate the MN as in step 4.2. Set the input channel CH1 as the stimulator (0–10 V) and the output settings for stimuli duration of 30 s with pulses of 1 ms duration and 1 Hz frequency. Link a dynamometer, with a resolution of d = 0.001 N to a computer

resolution of d = 0.001 N to a computer.

450

453

458

461

464

468

470 471

474

477

479 480

481

NOTE: Real time visualization of data can be obtained by building a plot of force per time (N/s) using the software previously installed on the computer and linked to a dynamometer⁴⁶.

4.3.2. Place the rat as described in step 4.1.4. Place a 5/0 silk suture loop through the second interosseous space of both forepaws. Attach the suture loop to the dynamometer's hook and the forepaw aligned with the dynamometer without putting excessive strain on the suture line.

4.3.3. Fix the contralateral paw with tape to avoid spurious movement interferences in the dynamometer readings.

- 4.3.4. Set the dynamometer to zero by clicking on the **ZERO** button. 455
- 4.3.5 Adjust the stimulator to a supramaximal amplitude stimulation of 1.5 V by adjusting the voltage knot.
- 4.3.5. On the PC, open the software AFH-01. Open the separator "Device" and select the device
 FH5. Create a new file ("Measurements1" is the name given by default) and rename the file.
- 4.3.6 Place the electrode on the proximal part of the MN, click on **play** at the bottom of the program, record the pull on the dynamometer for 30 s.
- 4.3.7. Import the values obtained to a data analysis software. Calculate the maximum and average force values and the area under the curve (AUC) for the strength x time graph for each evaluation.
- 469 4.3.8. Repeat for the left forepaw.

4.4. Muscle weight

- 472
 473 4.4.1. Euthanize the rats under general anesthesia by exsanguination^{47,48}.
- 4.4.2. Harvest the flexor carpi radialis muscle from both forearms, dissecting the muscle from its origin until its distal tendon insertion, using a number 15 scalpel blade.
- 4.4.3. Weigh the muscles with a precision scale^{9,49}.

REPRESENTATIVE RESULTS:

482 A total of 34 rats were randomly divided into the following groups: Sham (n = 17), Excision (n =

Page 10 of 19 revised May 2019

17), and *Nerve Graft* (n = 10) for the operation. All rats survived surgery and the postoperative period uneventfully. One week after surgery and for the subsequent 100 days, all animals underwent the functional tests described above once a week. The representative results of each of these tests are described below.

Grasping Test

The percentage of rats with a positive response in the grasping test was highest for the *Sham* group. This value gradually increased over time in rats from the *Crush* and *Nerve Graft* groups (Figure 3).

Pin Prick Test

Rats from the *Sham* group had the best scores in the cumulative pin prick test relative to rats from the *Nerve Graft* group. Both had better scores than the rats in the *Excision* group (**Figure 4**).

Ladder Running Test

The rats' velocity in the ladder running test was highest in the *Sham* group than in the rats submitted to MN lesion. Among the latter, the time to run the ladder tended to decrease over time, paralleling MN recovery (**Figure 5**).

Rope Test

As in the ladder running test, the time the rats took to climb the rope was shorter in the *Sham* group compared to the groups in which the MN was injured. The rats' speed in this test increased when the MN was allowed to recover (**Figure 6**).

Walking Track Analysis

Analysis of walking tracks tended to show changes in the morphology of paw prints (**Figure 7**). These changes were often more pronounced in crushing injuries than in segmental nerve lesions⁵⁰.

Infrared Thermography

Thermography was useful when examining temperature differences between the forepaws in the first 30 days after surgery. Temperature differences were more noticeable in rats with a more severely injured MN, such as in those from the *Excision* group (**Figure 8** and **Figure 9**).

Electroneuromyography

Table 1 summarizes the biological importance of the electroneuromyography measurements, providing representative results for the different experimental groups. Various patterns were observed with electroneuromyography. A normal CMAP was typical of a rat from the *Sham* group, while a polyphasic CMAP was associated with a variable degree of lesion of the MN, as in the *Crush* and in the *Nerve Graft* groups (**Figure 10**). In the *Excision* group, no CMAPs were observed.

Wrist Flexion Strength

526 Given that wrist flexion is mainly dependent on the MN, this test was used to evaluate motor

Page 11 of 19 revised May 2019

recovery in this nerve's territory. Wrist flexion strength was closest to normal when recovery was maximal (Figure 11).

528 529 530

531

532

533

527

Muscle Weight and Morphology

The weight and morphology of the flexor carpis radialis muscle were dependent on MN recovery, as this muscle is innervated exclusively by the MN^{9,10}. Thus, normal weight and morphology were observed in the *Sham* group. A loss of weight and muscle trophism was observed in the *Crush*, *Nerve Graft*, and *Excision* groups (**Figure 12**).

534535536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

FIGURE AND TABLE LEGENDS:

Figure 1: Schematic representation of the anatomy of the median nerve of the rat. (1) Origin and termination of the median nerve in the rat brain (green area = primary motor area; blue area = primary sensory area). (2) Transverse section of the spinal cord at C7 segment level; (3) Axillary nerve; (4) Musculocutaneous nerve; (5) Radial nerve; (6) Median nerve; (7) Ulnar nerve; (8) Medial cutaneous branch of the arm; (9) Medial cutaneous branch of the forearm; (10) Axillary artery; (11) Brachial artery; (12) Median artery; (13) Superficial radial artery; (14) Ulnar artery; (15) Motor branch of the median nerve to the pronator teres muscle; (16) Motor branch of the median nerve to the flexor carpis radialis muscle; (17) Motor branch of the median nerve to the flexor digitorum superficialis muscle; (18) Motor branch of the median nerve to the flexor digitorum profundus muscle; (19) Sensory branch of the median nerve to the thenar region; (20) Common palmar artery of the first interosseous space; (21) Radial palmar digital artery of the first digit; (22) Motor branch of the median nerve to the thenar muscles; (23) Palmar arterial arch; (24) Radial palmar digital nerve of the first digit; (25) Ulnar palmar digital nerve of the first digit; (26) Common palmar artery of the third interosseous space; (27) Motor branches of the terminal divisions of the median nerve to the first three lumbrical muscles; (28) Ulnar palmar digital nerves of the second, third, and fourth digits; (29) Ulnar palmar digital arteries to the fourth and fifth digits; (30) Radial palmar digital nerves of the second, third, and fourth digits; (31) Radial palmar digital artery of the fifth digit; (32) Skin territory of the median nerve in the forepaw (blue-shaded region).

555556557

Figure 2: Photograph of the right forelimb of the rat showing the surgical anatomy of the median nerve in the arm and axillary regions. Cr, cranial; Me, medial

558559560

Figure 3: Percentage of rats with a positive grasping test in the different experimental group over a period of 100 days after surgery.

561562563

564

565

Figure 4: Nociception evaluation using cumulative pin prick test results in the operated forepaw normalized to the contralateral paw in the different experimental groups. Vertical bars represent 95% confidence intervals. Horizontal lines in the upper part of the figure indicate statistically significant differences between experimental groups, ***p<0.001.

566567568

569

570

Figure 5: Average speed in the ladder running test in the different experimental groups. Vertical bars represent 95% confidence intervals. Asterisks in the upper portion of the figure indicate statistically significant differences between groups, *p<0.001.

Page 12 of 19 revised May 2019

Figure 6: Average climbing velocity in the rope test in the *Sham* **and** *Excision* **groups.** Vertical bars represent 95% confidence intervals. Asterisks in the upper portion of the figure show statistically significant differences between groups, *p<0.05; **p<0.01.

Figure 7: Walking track parameters in the different experimental groups. Values on the operated limb are expressed as percentages of means normalized to the contralateral limb. (**A**) Stance factor; (**B**) Print length; (**C**) Finger spread factor; (**D**) Intermediate finger spread factor; (**E**) Stride length; (**F**) Base of support. Vertical bars represent 95% confidence intervals. Horizontal lines in the upper portion of the figure indicate statistically significant differences between experimental groups. D30, D60, D90 = 30, 60, and 90 days after surgery, *p<0.05; **p<0.01; ***p<0.001.

Figure 8: Mean temperature difference registered by infrared thermography. The box plots represent the temperature difference between the palmar region of the median nerve on the operated side (right side) and the contralateral side (left) in the *Sham* (n = 17) and *Excision* (n = 17) groups, *p<0.05; **p<0.01.

Figure 9: Typical infrared thermography pattern of an animal from the excision group during the first 45 days after surgery.

Figure 10: Typical patterns of Compound Muscle Action Potentials (CMAPs) from an animal from the *Sham* and *Nerve Graft* groups 90 days after surgery.

Figure 11: Evaluation of wrist flexion strength on both forepaws 90 days postoperatively in different experimental groups. Wrist flexion strength was assessed using the area under the curve (AUC) over a time period of 30 s and using supratetanic stimulation. Vertical lines denote 95% confidence intervals. Horizontal lines in the upper portion of the figure highlight statistically significant differences between groups, **p<0.01.

 Figure 12: Flexor carpi radialis muscle weight and macroscopic appearance 100 days after surgery. (A) Box plots depicting the normalized flexor carpi radialis muscle weight in different experimental groups, **p<0.01; ***p<0.001. (B) Photographs of the muscles on the right and left sides in the Sham and Excision experimental groups.

Page 13 of 19 revised May 2019

DISCUSSION:

This paper presents a protocol to create different types of MN lesions and repair in the rat. Additionally, it illustrates how to evaluate the functional recovery of this nerve using several noninvasive behavioral tests and physiological measurements.

Notably, several of the functional tests described in this paper, namely the Ladder Running Test and the Rope Test, are significantly dependent on the rat's willingness to perform the task with the expectation of obtaining the food reward⁵¹⁻⁵³. It should be noted that certain rat strains are more amenable to training and performing reproducibly in this type of tests⁵¹⁻⁵³. For example, Lewis rats perform poorly in these tests both in the training phase and subsequently⁵¹⁻⁵³.

Rat housing should permit ample freedom of movement in agreement with their natural exploratory behavior, in addition to allowing experimental animals to get familiar with some of the elements present in the functional tests¹⁹. Therefore, different forms of housing allowing higher freedom of movement are shown. The big cages are personalized with enrichment elements that are later used in the functional tests (e.g., ropes and ladders).

Arguably, these enriching elements as well as the cages with incorporated running wheels and the individual training spheres provide a form of postoperative physiotherapy similar to that offered to human patients operated on the peripheral nervous system¹⁰.

Significantly, although some authors advocate dissecting the subcutaneous tissues and muscle fasciae bluntly or by clean cutting with a number 15 scalpel, the use of thermocautery when dissecting these structures is recommended to minimize the risk of postoperative hematoma.

It should be noted that numerous tests have been devised to test different aspects of peripheral nerve repair in the rat, namely axonal regeneration, target reinnervation, and functional recovery, some of which are beyond the scope of this study^{29,54-56}. For example, kinematic analysis^{29,36,55} and histomorphometric assessment^{29,36,57} are widely employed by multiple authors. Additionally, several of these tests involve variations to maximize efficiency and/or reproducibility⁵⁴. For example, mechanical algisemetry (i.e., evaluation of responses to mechanical painful stimuli) can be assessed qualitatively using a given von Frey filament, as described in the present paper, or semiquantitatively using successively stronger von Frey filaments, or even quantitatively using electronic devices that apply increasing pressures until a withdrawal response is observed^{30,54}.

 Similarly, although several authors use walking track analysis to evaluate forelimb nerve repair in the rat, other authors argue that single MN lesions frequently fail to produce reproducible changes in pawprints^{10,58,59}. Furthermore, some have stated that these changes may not be proportional to muscle recovery^{10,60}. Bearing this in mind, some researchers have advocated the use of walking track analysis in the forepaw mainly when assessing recovery after crushing neve lesions rather than after segmental nerve reconstruction^{10,50,61}.

The Grasping Test is widely used to evaluate motor recovery of the muscles controlled by the

Page 14 of 19 revised May 2019

MN^{16,27}. To guarantee uniformity and reproducibility of the data obtained with this test, applying the Grasping Test using the well-established methodology proposed by Bertelli et al.¹⁶ is recommended. However, the current protocol differs in that it does not routinely immobilize the contralateral paw to prevent undue stress^{11,27}. It should also be noted that other authors, after immobilizing the uninjured paw, quantitatively assess the Grasping Test using a dynamometer or a scale^{27,56}. However, this quantitative evaluation may be affected by the strength the researcher applies to the rat's tail²⁶. Furthermore, it is difficult to distinguish between the strength generated by the digital flexor muscles (solely innervated by the MN in the rat and the object of the Grasping Test⁹) from the strength produced by the wrist flexors, which include the flexor carpi ulnaris that receives its innervation from the ulnar nerve^{9,10,27}. In order to try to circumvent these potential biases, this protocol uses an ordinal scale similar to the Medical Research Council Scale commonly used to grade muscle strength in humans^{10,11,62}. Alternatively, other authors have described detailed assessment of grasping using video analysis and a video-based scoring system^{11,63}.

A potential disadvantage of using the MN compared to the sciatic nerve is that a greater amount of information is available regarding the latter nerve. This, in turn, can make comparison of data obtained with the MN with that of prior experimental works more difficult^{46,48,64}. Additionally, the smaller size of the MN compared to the sciatic nerve makes surgical manipulation more challenging^{8,12,27,56,65}.

Contrary to the methodology described in this paper, the electroneuromyography evaluation can be performed using transcutaneous monopolar electrodes placed in the arm and thenar regions⁵¹. Despite being less invasive, this method carries the risk of potential confusion due to the possibility of costimulation of the ulnar nerve in the arm region^{9,51}.

Most authors concur that not all tests used in the rat provide concordant results, as peripheral nerve repair depends on a complex array of factors, comprising neuron survival, axonal elongation and pruning, synaptogenesis, successful recapture of the denervated sensory organs and motor units, and brain plasticity^{7,10,50,66,67}.

Finally, it should be noted that a significant caveat of rodent models is that rat peripheral nerves are much closer to their end organs and have much smaller cross-sectional areas than the homologous human structures. However, this size difference guarantees faster experimental data in rodents, and better overall results in rats in comparison to humans are to be expected⁶⁸. Indeed, several authors warn that care must be used when trying to extrapolate experimental data obtained in peripheral nerve repair using rodents to humans^{7,69}. Primate models are considered more comparable⁷⁰. Nevertheless, their use is associated with vexing ethical, logistical, and budget constraints⁷¹.

 Even though the sciatic nerve is the most commonly used nerve in peripheral nerve research, the rat MN presents multiple advantages. For example, MN lesions are associated with a smaller incidence of joint contractures and automutilation of the affected paw^{11,12,16,56}. Significantly, autotomy subsequent to sciatic nerve transection afflicts 11–70% of rats. This may make current

Page 15 of 19 revised May 2019

evaluations like the sciatic index impossible¹⁴. This, in turn, makes the estimate of the number of animals required to obtain a given statistical power cumbersome¹⁵.

In addition, as the MN is shorter than the sciatic nerve, nerve recovery is observed sooner^{58,72-76}. Furthermore, the MN is not covered by muscle masses, making its dissection technically easier than that of the sciatic nerve¹⁶. Additionally, the MN has a parallel path to the ulnar nerve in the arm. Hence, the ulnar nerve can easily be used as nerve graft for repairing MN injuries. Finally, in humans, most peripheral nerve lesions occur in the upper limb, which further supports the use of this nerve in the rat^{77,78}.

Arguably, rodents are the experimental animals most commonly used in the realm of peripheral nerve repair^{48,79}. As shown, the rat MN is a convenient model of peripheral nerve lesion and repair. In fact, there are multiple standardized strategies available to assess motor and sensory recovery, permitting an easier comparison of results^{36,46,60,80-82}. Many of these methods are noninvasive, allowing for daily assessment.

Moreover, physiotherapy is part of the standard of care of patients recovering from peripheral nerve injuries. As demonstrated in this paper, there are multiple strategies to provide a postoperative physiotherapy-like environment to rats submitted to MN injuries^{4,5}. Hence, this model is particularly suitable to replicate the clinical scenario, facilitating extrapolation of results to the human species^{12,27,48,56,58,83}.

As shown in this paper, multiple standardized strategies are available to assess motor and sensory recovery in the MN model of the rat. The majority of these are noninvasive procedures, allowing frequent assessment. Moreover, as most peripheral nerve lesions in the human species occur in the upper limb, the mentioned experimental physiotherapy settings can more aptly mimic recovery in the clinical context. Arguably, this can facilitate extrapolation of results to the human species, further validating the use of this nerve in the rat.

ACKNOWLEDGMENTS:

Diogo Casal received a grant from The Program for Advanced Medical Education, which is sponsored by Fundação Calouste Gulbenkian, Fundação Champalimaud, Ministério da Saúde e Fundação para a Ciência e Tecnologia, Portugal. The authors are very grateful to Mr. Filipe Franco for the illustrative drawing in **Figure 1**. The authors would like to thank the technical help of Mr. Alberto Severino in filming and editing the video. Finally, the authors would like to thank Ms. Sara Marques for her help in all the logistical aspects pertaining to animal acquisition and maintenance.

DISCLOSURES:

734 The authors have nothing to disclose.

REFERENCES:

1. Lad, S. P., Nathan, J. K., Schubert, R. D., Boakye, M. Trends in median, ulnar, radial, and brachioplexus nerve injuries in the United States. *Neurosurgery.* **66** (5), 953-960 (2010).

Page 16 of 19 revised May 2019

- 739 2. Murovic, J. A. Upper-extremity peripheral nerve injuries: a Louisiana State University
- 740 Health Sciences Center literature review with comparison of the operative outcomes of 1837
- 741 Louisiana State University Health Sciences Center median, radial, and ulnar nerve lesions.
- 742 *Neurosurgery.* **65** (4 Suppl), A11-17 (2009).
- 743 3. Dy, C. J., Isaacs, J. in American Society for Surgery of the Hand surgical anatomy: nerve
- 744 reconstruction Vol. 1 eds. C. J. Dy and J. Isaacs) xi (American Society for Surgery of the Hand,
- 745 2017).
- 746 4. Trehan, S. K., Model, Z., Lee, S. K. Nerve Repair and Nerve Grafting. Hand Clinics. 32 (2),
- 747 119-125 (2016).
- 748 5. Boyd, K. U., Fox, I. K. in *Nerve surgery* Vol. 1 (ed. S. E. Mackinnon) Ch. 4, pp. 75-100
- 749 (Thieme, 2015).
- 750 6. Geuna, S. et al. Update on nerve repair by biological tubulization. *Journal of Brachial*
- 751 *Plexius Peripheral Nerve Injury.* **9** (1), 3 (2014).
- 752 7. Sulaiman, W., Gordon, T. Neurobiology of peripheral nerve injury, regeneration, and
- functional recovery: from bench top research to bedside application. Ochsner Journal. 13 (1),
- 754 100-108 (2013).
- 755 8. Angelica-Almeida, M. et al. Brachial plexus morphology and vascular supply in the wistar
- 756 rat. *Acta Medica Portuguesa*. **26** (3), 243-250 (2013).
- 757 9. Bertelli, J. A., Taleb, M., Saadi, A., Mira, J. C., Pecot-Dechavassine, M. The rat brachial
- 758 plexus and its terminal branches: an experimental model for the study of peripheral nerve
- 759 regeneration. *Microsurgery.* **16** (2), 77-85 (1995).
- 760 10. Casal, D. et al. Reconstruction of a 10-mm-long median nerve gap in an ischemic
- 761 environment using autologous conduits with different patterns of blood supply: A comparative
- 762 study in the rat. *PLoS One.* **13** (4), e0195692 (2018).
- 763 11. Stößel, M., Rehra, L., Haastert-Talini, K. Reflex-based grasping, skilled forelimb reaching,
- and electrodiagnostic evaluation for comprehensive analysis of functional recovery—The 7-mm
- rat median nerve gap repair model revisited. *Brain and Behavior.* **7** (10), e00813 (2017).
- 766 12. Manoli, T. et al. Correlation analysis of histomorphometry and motor neurography in the
- 767 median nerve rat model. *Eplasty.* **14**, e17 (2014).
- 768 13. Ronchi, G. et al. The Median Nerve Injury Model in Pre-clinical Research A Critical Review
- on Benefits and Limitations. Frontiers in Cellular Neuroscience. 13, 288 (2019).
- 770 14. Weber, R. A., Proctor, W. H., Warner, M. R., Verheyden, C. N. Autotomy and the sciatic
- 771 functional index. *Microsurgery.* **14** (5), 323-327 (1993).
- 772 15. Charan, J., Kantharia, N. D. How to calculate sample size in animal studies? *Journal of*
- 773 *Pharmacology & Pharmacotherapeutics.* **4** (4), 303-306 (2013).
- 774 16. Bertelli, J. A., Mira, J. C. The grasping test: a simple behavioral method for objective
- 775 quantitative assessment of peripheral nerve regeneration in the rat. Journal of Neuroscience
- 776 *Methods.* **58** (1-2), 151-155 (1995).
- 777 17. Casal, D. et al. A Model of Free Tissue Transfer: The Rat Epigastric Free Flap. *Journal of*
- 778 *Visualized Experiments.* (119), e55281 (2017).
- 779 18. Bertens, A. P. M. G. et al. Anaesthesia, analgesia and euthanasia. In: Principles of
- 780 Laboratory Animal Science. Eds. Van Zuthphen, L. F., Baumans, V., Beynen, A.C. Elsevier. pp. 277-
- 781 311 (2001).
- 782 19. Pritchett-Corning, K. R., Luo, Y., Mulder, G. B., White, W. J. Principles of rodent surgery

Page 17 of 19 revised May 2019

- 783 for the new surgeon. *Journal of Visualized Experiments*. (47), e2586 (2011).
- 784 20. Lee-Parritz, D. Analgesia for rodent experimental surgery. *Israel Journal of Veterinary*
- 785 *Medicine.* **62** (3), 74 (2007).
- 786 21. Roughan, J. V., Flecknell, P. A. Evaluation of a short duration behaviour-based post-
- operative pain scoring system in rats. *European Journal of Pain.* **7** (5), 397-406 (2003).
- 788 22. Bauder, A. R., Ferguson, T. A. Reproducible mouse sciatic nerve crush and subsequent
- assessment of regeneration by whole mount muscle analysis. *Journal of Visualized Experiments*.
- 790 (60), e3606 (2012).
- 791 23. Ronchi, G. et al. Functional and morphological assessment of a standardized crush injury
- of the rat median nerve. *Journal of Neuroscience Methods.* **179** (1), 51-57 (2009).
- 793 24. Matsumine, H. et al. Vascularized versus nonvascularized island median nerve grafts in
- the facial nerve regeneration and functional recovery of rats for facial nerve reconstruction study.
- 795 *Journal of Reconstructive Microsurgery.* **30** (2), 127-136 (2014).
- 796 25. Mickley, A. G., Hoxha, Z., Biada, J. M., Kenmuir, C. L., Bacik, S. E. Acetaminophen Self-
- 797 administered in the Drinking Water Increases the Pain Threshold of Rats (Rattus norvegicus).
- 798 Journal of the American Association for Laboratory Animal Science. **45** (5), 48-54 (2006).
- 799 26. Mandillo, S. et al. Reliability, robustness, and reproducibility in mouse behavioral
- phenotyping: a cross-laboratory study. *Physiological Genomics.* **34** (3), 243-255 (2008).
- 801 27. Papalia, I., Tos, P., Stagno d'Alcontres, F., Battiston, B., Geuna, S. On the use of the
- 802 grasping test in the rat median nerve model: a re-appraisal of its efficacy for quantitative
- assessment of motor function recovery. *Journal of Neuroscience Methods.* **127** (1), 43-47 (2003).
- 804 28. Costa, L. M., Simoes, M. J., Mauricio, A. C., Varejao, A. S. Chapter 7: Methods and
- protocols in peripheral nerve regeneration experimental research: part IV-kinematic gait analysis
- to quantify peripheral nerve regeneration in the rat. International Reviews in Neurobiology. 87,
- 807 127-139 (2009).
- 808 29. Geuna, S., Varejao, A. S. Evaluation methods in the assessment of peripheral nerve
- 809 regeneration. *Journal of Neurosurgery.* **109** (2), 360-362; author reply 362, (2008).
- 810 30. Howard, R. F., Hatch, D. J., Cole, T. J. Fitzgerald, M. Inflammatory pain and hypersensitivity
- 811 are selectively reversed by epidural bupivacaine and are developmentally regulated.
- 812 *Anesthesiology.* **95** (2), 421-427 (2001).
- 813 31. Metz, G. A., Whishaw, I. Q. Cortical and subcortical lesions impair skilled walking in the
- ladder rung walking test: a new task to evaluate fore- and hindlimb stepping, placing, and co-
- 815 ordination. *Journal of Neuroscience Methods.* **115** (2), 169-179 (2002).
- 816 32. Thallmair, M. et al. Neurite growth inhibitors restrict plasticity and functional recovery
- following corticospinal tract lesions. *Nature Neuroscience*. **1** (2), 124-131 (1998).
- 818 33. Brown, C. J. et al. Self-evaluation of walking-track measurement using a Sciatic Function
- 819 Index. *Microsurgery.* **10** (3), 226-235 (1989).
- 820 34. Hruska, R. E., Kennedy, S., Silbergeld, E. K. Quantitative aspects of normal locomotion in
- 821 rats. Life Science. 25 (2), 171-179 (1979).
- 822 35. Ferreira, T., Rasband, W. ImageJ user guide. *ImageJ/Fiji.* **1**, 155-161 (2012).
- 823 36. Dijkstra, J. R., Meek, M. F., Robinson, P. H., Gramsbergen, A. Methods to evaluate
- functional nerve recovery in adult rats: walking track analysis, video analysis and the withdrawal
- 825 reflex. *Journal of Neuroscience Methods.* **96** (2), 89-96 (2000).
- 826 37. Ludwig, N., Formenti, D., Gargano, M., Alberti, G. Skin temperature evaluation by infrared

Page 18 of 19 revised May 2019

- thermography: Comparison of image analysis methods. *Infrared Physics & Technology.* **62**, 1-6
- 828 (2014).
- 829 38. Bennett, G. J., Ochoa, J. L. Thermographic observations on rats with experimental
- 830 neuropathic pain. *Pain.* **45** (1), 61-67 (1991).
- 831 39. Wakisaka, S., Kajander, K. C., Bennett, G. J. Abnormal skin temperature and abnormal
- 832 sympathetic vasomotor innervation in an experimental painful peripheral neuropathy. Pain. 46
- 833 (3), 299-313 (1991).
- 834 40. Muntean, M. V. et al. Using dynamic infrared thermography to optimize color Doppler
- ultrasound mapping of cutaneous perforators. *Medical Ultrasonography.* **17** (4), 503-508 (2015).
- 836 41. Shterenshis, M. Challenges to Global Implementation of Infrared Thermography
- 837 Technology: Current Perspective. Central Asian Journal of Global Health. 6 (1), 289 (2017).
- Wilbourn, A. J. in *Nerve surgery* Vol. 1 (ed. S. E. Mackinnon) Ch. 3, pp. 59-74 (Thieme,
- 839 2015).
- 840 43. Wu, Y., Martínez, M. Á. M., Balaguer, P. O. in *Electrodiagnosis in New Frontiers of Clinical*
- 841 Research. (ed. Hande Turker) Ch. 01 (InTech, 2013).
- 842 44. Werdin, F. et al. An improved electrophysiological method to study peripheral nerve
- regeneration in rats. *Journal of Neuroscience Methods.* **182** (1), 71-77 (2009).
- 844 45. Sedghamiz, H., Santonocito, D. *Unsupervised Detection and Classification of Motor Unit*
- Action Potentials in Intramuscular Electromyography Signals. 2015 E-health and Bioengineering
- 846 Conference IEEE. pp. 1-6. (2015).
- 847 46. Hadlock, T. A., Koka, R., Vacanti, J. P., Cheney, M. L. A comparison of assessments of
- functional recovery in the rat. *Journal of the Peripheral Nervous System.* **4** (3-4), 258-264 (1999).
- 849 47. Carstens, E., Moberg, G. P. Recognizing pain and distress in laboratory animals. *Ilar*
- 850 Journal. 41 (2), 62-71 (2000).
- 851 48. Tos, P. et al. Chapter 4: Methods and protocols in peripheral nerve regeneration
- 852 experimental research: part I-experimental models. International Reviews in Neurobiology. 87,
- 853 47-79 (2009).
- 49. Galtrey, C. M., Fawcett, J. W. Characterization of tests of functional recovery after median
- and ulnar nerve injury and repair in the rat forelimb. *Journal of the Peripheral Nervous System.*
- 856 **12** (1), 11-27 (2007).
- 857 50. Giusti, G. et al. Return of motor function after segmental nerve loss in a rat model:
- 858 comparison of autogenous nerve graft, collagen conduit, and processed allograft (AxoGen).
- 859 Journal of Bone and Joint Surgery American Volume. 94 (5), 410-417 (2012).
- 860 51. Stossel, M., Rehra, L., Haastert-Talini, K. Reflex-based grasping, skilled forelimb reaching,
- and electrodiagnostic evaluation for comprehensive analysis of functional recovery-The 7-mm
- rat median nerve gap repair model revisited. *Brain and Behavior.* **7** (10), e00813 (2017).
- 863 52. Nikkhah, G., Rosenthal, C., Hedrich, H. J., Samii, M. Differences in acquisition and full
- performance in skilled forelimb use as measured by the 'staircase test' in five rat strains.
- 865 *Behavioral Brain Research.* **92** (1), 85-95 (1998).
- 866 53. Whishaw, I. Q., Gorny, B., Foroud, A., Kleim, J. A. Long-Evans and Sprague-Dawley rats
- have similar skilled reaching success and limb representations in motor cortex but different
- 868 movements: some cautionary insights into the selection of rat strains for neurobiological motor
- 869 research. *Behavioral Brain Research*. **145** (1-2), 221-232 (2003).
- 870 54. Navarro, X. Functional evaluation of peripheral nerve regeneration and target

Page 19 of 19 revised May 2019


- reinnervation in animal models: a critical overview. European Journal of Neuroscience. 43 (3),
- 872 271-286 (2016).
- 873 55. Costa, L. M., Simões, M. J., Maurício, A. C., Varejão, A. S. P. in *International Review of*
- 874 *Neurobiology*. Vol. 87, pp. 127-139 (Academic Press, 2009).
- 875 56. Ronchi, G. et al. Functional and morphological assessment of a standardized crush injury
- of the rat median nerve. *Journal of Neuroscience Methods.* **179** (1), 51-57 (2009).
- 877 57. Raimondo, S. et al. Chapter 5: Methods and protocols in peripheral nerve regeneration
- 878 experimental research: part II-morphological techniques. *International Reviews in Neurobiology.*
- 879 **87**, 81-103 (2009).
- 880 58. Bontioti, E. K. M., Dahlin L. B. Regeneration and functional recovery in the upper extermity
- of rats after various types of nerve injuries. *Journal of the Peripheral Nervous System.* **8**, 159-168
- 882 (2003).
- 883 59. Schönfeld, L.-M., Dooley, D., Jahanshahi, A., Temel, Y., Hendrix, S. Evaluating rodent
- motor functions: Which tests to choose? *Neuroscience & Biobehavioral Reviews.* **83,** 298-312
- 885 (2017).
- 886 60. Urbancheck, M. S. Rat walking tracks do not reflect maximal muscle force capacity.
- 887 *Journal of Reconstructive Microsurgery.* **15** (2), 143-149 (1999).
- 888 61. Cudlip, S. A., Howe, F. A., Griffiths, J. R., Bell, B. A. Magnetic resonance neurography of
- peripheral nerve following experimental crush injury, and correlation with functional deficit.
- 890 *Journal of Neurosurgery.* **96** (4), 755-759 (2002).
- 891 62. Wang, Y., Sunitha, M., Chung, K. C. How to measure outcomes of peripheral nerve surgery.
- 892 *Hand Clinics.* **29** (3), 349-361 (2013).
- 893 63. Wang, H., Spinner, R. J., Sorenson, E. J., Windebank, A. J. Measurement of forelimb
- function by digital video motion analysis in rat nerve transection models. *Journal of the Peripheral*
- 895 *Nervous System.* **13** (1), 92-102 (2008).
- 896 64. Yanase, Y. in Experimental and Clinical Reconstructive Microsurgery eds S. Tamai, M. Usui,
- 897 T. Yoshizu) Ch. 2, pp. 44-51 (Springer-Verlag, 2004).
- 898 65. Barton, M. J. et al. Morphological and morphometric analysis of the distal branches of the
- rat brachial plexus. Italian Journal of Anatomy and Embryology. 121 (3), 240-252 (2016).
- 900 66. Vincent, R. Adult and obstetrical brachial plexus injuries. In: Peripheral Nerve Surgery:
- 901 Practical applications in the upper extremity. Eds. Slutsky D. J., Hentz, V. R. Churchill Livingstone.
- 902 pp. 299-317 (2006).
- 903 67. Dahlin, L. B. in Peripheral Nerve Surgery: Practical Applications in the Upper Extremity.
- 904 eds. Slutsky, D. J., Hentz, V. R.) Ch. 1, pp. 1-22 (Elsevier, 2006).
- 905 68. Vargel, I. et al. A comparison of various vascularization-perfusion venous nerve grafts with
- 906 conventional nerve grafts in rats. *Journal of Reconstructive Microsurgery.* **25** (7), 425-437 (2009).
- 907 69. Grinsell, D., Keating, C. Peripheral nerve reconstruction after injury: a review of clinical
- and experimental therapies. *BioMed Research International.* **2014**, 698256 (2014).
- 909 70. Wang, D. et al. A simple model of radial nerve injury in the rhesus monkey to evaluate
- 910 peripheral nerve repair. Neural Regeneration Research. 9 (10), 1041-1046 (2014).
- 911 71. Casal, D. et al. Unconventional Perfusion Flaps in the Experimental Setting: A Systematic
- 912 Review and Meta-Analysis. *Plastic Reconstructive Surgery.* **143** (5), 1003e-1016e (2019).
- 913 72. Bontioti, E. End-to-side nerve repair. A study in the forelimb of the rat. PhD thesis, Lund,
- 914 (2005).


Page 20 of 19 revised May 2019


- 915 73. Bodine-Fowler, S. C., Meyer, R. S., Moskovitz, A., Abrams, R. Botte, M. J. Inaccurate
- 916 projection of rat soleus motoneurons: a comparison of nerve repair techniques. *Muscle Nerve*.
- 917 **20** (1), 29-37 (1997).
- 918 74. Valero-Cabre, A., Navarro, X. H reflex restitution and facilitation after different types of
- 919 peripheral nerve injury and repair. Brain Research. 919 (2), 302-312 (2001).
- 920 75. Wall, P. D. et al. Autotomy following peripheral nerve lesions: experimental anaesthesia
- 921 dolorosa. *Pain.* **7** (2), 103-111 (1979).
- 922 76. Bertelli, J. A., Taleb, M., Saadi, A., Mira, J. C., Pecot-Dechavassine, M. The rat brachial
- 923 plexus and its terminal branches: an experimental model for the study of peripheral nerve
- 924 regeneration. *Microsurgery.* **16**, 77-85 (1995).
- 925 77. Wood, M. J., Johnson, P. J., Myckatyn, T. M. in Nerve Surgery Vol. 1 eds. Mackinnon, S. E.,
- 926 Yee, A.) Ch. 1, pp. 1-40 (Thieme, 2015).
- 927 78. Rosberg, H. E. Epidemiology of hand injuries in a middle-sized city in southern Sweden a
- 928 retrospective study with an 8-year interval. Scandinavian Journal of Plastic and Reconstructive
- 929 *Surgery and Hand Surgery.* **38**, 347-355 (2004).
- 930 79. Gordon, T., Borschel, G. H. The use of the rat as a model for studying peripheral nerve
- 931 regeneration and sprouting after complete and partial nerve injuries. Experimental Neurology.
- 932 **287** (Pt 3), 331-347 (2017).
- 933 80. Bertelli, J. A., Ghizoni, M. F. Concepts of nerve regeneration and repair applied to brachial
- 934 plexus reconstruction. *Microsurgery.* **26** (4), 230-244 (2006).
- 935 81. Bertelli, J. A., Mira, J. C. Behavioural evaluating methods in the objective clinical
- 936 assessment of motor function after experimental brachial plexus reconstruction in the rat.
- 937 *Journal of Neuroscience Methods.* **46**, 203-208 (1993).
- 938 82. Bertelli, J. A., Mira, J. C. The grasping test: a simple behavioral method for objective
- 939 quantitative assessment of peripherla nerve regeneration in the rat. Journal of Neuroscience
- 940 *Methods.* **58** (1-2), 151-155 (1995).


943


- 941 83. Ronchi, G. et al. Standardized crush injury of the mouse median nerve. Journal of
- 942 Neuroscience Methods. **188** (1), 71-75 (2010).

























Normal CMAP pattern


Polyphasic CMAP pattern



Sham Group

Nerve graft Group





Parameter	Parameter significance	Sham	Excision	NG
Neurological	Evaluation of nerve regeneration, as there is a minimal number of nerve	group 281.63 ±	group 5359.98 ±	group 2108.12 ±
stimulation threshold (%)	fibers required to produce either a CMAP or a visible muscle contraction 12	271.65	3466.52	2115.13
Motor stimulation threshold (%)	Evaluation of nerve regeneration, as there is a minimal number of nerve fibers required to produce either a	462.52 ± 118.91	1694.10 ± 503.24	1249.50 ± 503.24
Latency (%)	Assessment of nerve conduction velocity in the fastest nerve fibers, that is to say the largest myelinated fibers ⁴⁴	113.55 ± 25.04	N/A	132.80 ± 69.95
Neuromuscular transduction velocity (%)	Assessment of nerve conduction velocity in the fastest nerve fibers, that is to say the largest myelinated fibers ⁴⁴	92.01 ± 20.88	N/A	91.30 ± 26.51
CMAPs amplitude (%)	Evaluation of the number of reinnervated motor units ³⁴	110.63 ±45.66	N/A	41.60 ± 24.84
CMAPs duration	Assessment of synchrony of muscle innervation, which is dependent on the degree of muscle reinnervation and myelination of the innervating motor fibers 44,45	101.12 ± 23.92	N/A	151.06 ± 54.52
(%)				

Table 1. Electroneuromyographic assessment at the end of the experiment

NG, nerve graft

CMAPs, compound muscle action potential.

N/A, non-applicable

All parameters are expressed as percentages of the average contralateral values.

Numeric variables are expressed as average ± standard deviation.

Acteaminophen Acland clamps Fine Science Tools O398 V Acland Single Clamps B-1V (Pair) Fine Science Tools Biogel Surgical Gloves Medex Supply BIOPAC Systems Castroviejo needle holders Cimpapplicator Constante voltage stimulator Constante voltage stimulator Bofflon 10-0 Cutasept skin disinfectant Dafilon 10-0 Beflon 10-0 Beflon 10-0 Beflon 10-0 Beflon 10-0 Beflon 10-0 Beflon 10-0 Cutasept skin disinfectant Dafilon 10-0 Beflon 10-0 Befl	Name of Material/ Equipment	Company	Catalog Number
Acland Single Clamps B-1V (Pair) Biogel Surgical Gloves Medex Supply Biogel Surgical Gloves BLAnalysis Castroviejo needle holders Clamp applicator Fine Science Tools Clamp applicator Fine Science Tools Clamp applicator Fine Science Tools Cutasept skin disinfectant Dafilon 10-0 Cutasept skin disinfectant Dafilon 10-0 Fine Science Tools Derf Needle Holders 12 cm TC Fine Science Tools Dry heat sterilizer Quirumed Quirumed Quirumed Quirumed Quirumed PHS Electroneuromiography setup BIOPAC Systems FH5 Electroneuromiography setup FILIR Software Graeffe forceps 0.8 mm tips curved FILIR Software Graeffe forceps 0.8 mm tips curved Fine Science Tools FILIR Software Heat Lamp HL-1 Hear Lamp HL-1 Hear Lamp HL-1 Hearry Apparatus Fine Science Tools High-Temperature Cautery Fine Science Tools Fine	Acetaminophen	Amazon	
Biogel Surgical Gloves BSL Analysis BIOPAC Systems Castroviejo needle holders Ciamp applicator Ciamp applicator Constante voltage stimulator Cutasept skin disinfectant Bode Chemie Dafilon 10-0 Derf Needle Holders 12 cm TC Dry heat sterilizer Dynamometer Electroneuromiography setup Electroneuromiography setup Elethilon 5-0 FILIR Graeffe forceps 0.8 mm tips curved Graph paper Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 1000IU/ml) High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scisors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution Medex Supply BIOPAC Systems Fine Science Tools To	Acland clamps	Fine Science Tools	00398 V
BSL Analysis Castroviejo needle holders Castroviejo needle holders Ciastroviejo needle holders Clamp applicator Ciamp applicator Constante voltage stimulator Constante voltage stimulator Cutasept skin disinfectant Dafilon 10-0 Bode Chemie Dafilon 10-0 Fine Science Tools Offline 10-0 Fine Science Tools Offline 10-0 Fine Science Tools Offline Science T	Acland Single Clamps B-1V (Pair)	Fine Science Tools	396
Castroviejo needle holders Clamp applicator Fine Science Tools Clamp applicator Fine Science Tools CAF-4 Constante voltage stimulator BIOPAC Systems STM200 Cutasept skin disinfectant Bode Chemie Dafilon 10-0 Fine Science Tools Todallange Derf Needle Holders 12 cm TC Fine Science Tools Todallange Dynamometer SAUTER Fine Science Tools Dynamometer SAUTER FILS Electroneuromiography setup BIOPAC Systems MP36 Ethilon 5-0 FLIR Graeffe forceps 0.8 mm tips curved FILR Graeffe forceps 0.8 mm tips curved FILR Graph paper Heat Lamp HL-1 Harvard Apparatus Hear Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) Universal Drugstore High-Temperature Cautery High-Temperature Cautery Fine Science Tools Harvard Apparatus FILR FIR FINE Science Tools FIRE	Biogel Surgical Gloves	Medex Supply	30465
Clamp applicatorFine Science ToolsCAF-4Constante voltage stimulatorBIOPAC SystemsSTM200Cutasept skin disinfectantBode ChemieDafilon 10-0G1118099Derf Needle Holders 12 cm TCFine Science Tools703DE12Dry heat sterilizerQuirumed2432DynamometerSAUTERFH5Electroneuromiography setupBIOPAC SystemsMP36Ethilon 5-0W1618FLIR SoftwareFLIRGraeffe forceps 0.8 mm tips curvedFine Science Tools11052-10Graph paperAmbarHeat Lamp HL-1Harvard Apparatus727562Heparin Sodium Solution (Heparin LEOUniversal Drugstore10000IU/ml)Universal DrugstoreAA03Homeothermic Blanket System with FlexibleFine Science ToolsAA03ProbeHarvard Apparatus507220FInfrared cameraFLIRE6Instrapac - Adson Toothed Forceps (Extra Fine)Fine Science Tools7973Iris Scissors 11.5 cm Curves EASY-CUTFine Science ToolsEA7613-11Ketamine hydrochloride/xylazine hydrochlorideSigma- AldrichK113	BSL Analysis	BIOPAC Systems	
Constante voltage stimulator Cutasept skin disinfectant Dafilon 10-0 Derf Needle Holders 12 cm TC Dry heat sterilizer Dry heat sterilizer Ouirumed Cutasept skin disinfectant Dry heat sterilizer Ouirumed Cutasept skin disinfectant Combined Cutasept skin disinfectant Dry Needle Holders 12 cm TC Fine Science Tools Tourumed Cutasept skin disinfectant Combined Cutasept skin disinfectant Combined Combi	Castroviejo needle holders	Fine Science Tools	12565-14
Cutasept skin disinfectantBode ChemieDafilon 10-0G1118099Derf Needle Holders 12 cm TCFine Science Tools703DE12Dry heat sterilizerQuirumed2432DynamometerSAUTERFH5Electroneuromiography setupBIOPAC SystemsMP36Ethilon 5-0W1618FLIR SoftwareFLIRGraeffe forceps 0.8 mm tips curvedFine Science Tools11052-10Graph paperAmbarHeat Lamp HL-1Harvard Apparatus727562Heparin Sodium Solution (Heparin LEO10000IU/ml)Universal DrugstoreHigh-Temperature CauteryFine Science ToolsAA03Homeothermic Blanket System with FlexibleFine Science ToolsAA03ProbeHarvard Apparatus507220FInfrared cameraFLIRE6Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solutionFine Science ToolsEA7613-11Ketamine hydrochloride/xylazine hydrochloride solutionSigma- AldrichK113	Clamp applicator	Fine Science Tools	CAF-4
Dafilon 10-0 Derf Needle Holders 12 cm TC Dry heat sterilizer Quirumed Quirumed 2432 Dynamometer SAUTER FH5 Electroneuromiography setup Electroneuromiography setup Ell Software Graeffe forceps 0.8 mm tips curved Fine Science Tools FLIR Graeffe forceps 0.8 mm tips curved Fine Science Tools Graph paper Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) Universal Drugstore High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution Fine Science Tools	Constante voltage stimulator	BIOPAC Systems	STM200
Derf Needle Holders 12 cm TCFine Science Tools703DE12Dry heat sterilizerQuirumed2432DynamometerSAUTERFH5Electroneuromiography setupBIOPAC SystemsMP36Ethilon 5-0W1618FLIR SoftwareFLIRGraeffe forceps 0.8 mm tips curvedFine Science Tools11052-10Graph paperAmbarHeat Lamp HL-1Harvard Apparatus727562Heparin Sodium Solution (Heparin LEOUniversal Drugstore10000IU/ml)Universal DrugstoreHigh-Temperature CauteryFine Science ToolsAA03Homeothermic Blanket System with FlexibleProbeHarvard Apparatus507220FInfrared cameraFLIRE6Instrapac - Adson Toothed Forceps (Extra Fine)Fine Science Tools7973Iris Scissors 11.5 cm Curves EASY-CUTFine Science ToolsEA7613-11Ketamine hydrochloride/xylazine hydrochlorideSigma- AldrichK113	Cutasept skin disinfectant	Bode Chemie	
Dry heat sterilizerQuirumed2432DynamometerSAUTERFH5Electroneuromiography setupBIOPAC SystemsMP36Ethilon 5-0W1618FLIR SoftwareFLIRGraeffe forceps 0.8 mm tips curvedFine Science Tools11052-10Graph paperAmbarHeat Lamp HL-1Harvard Apparatus727562Heparin Sodium Solution (Heparin LEO10000IU/ml)Universal DrugstoreHigh-Temperature CauteryFine Science ToolsAA03Homeothermic Blanket System with FlexibleHarvard Apparatus507220FProbeHarvard Apparatus507220FInfrared cameraFLIRE6Instrapac - Adson Toothed Forceps (Extra Fine)Fine Science Tools7973Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solutionFine Science ToolsEA7613-11Ketamine hydrochloride/xylazine hydrochloride solutionSigma- AldrichK113	Dafilon 10-0		G1118099
Dynamometer SAUTER FH5 Electroneuromiography setup BIOPAC Systems MP36 Ethilon 5-0 W1618 FLIR Software FLIR Graeffe forceps 0.8 mm tips curved Fine Science Tools 11052-10 Graph paper Ambar Heat Lamp HL-1 Harvard Apparatus 727562 Heparin Sodium Solution (Heparin LEO 10000IU/ml) Universal Drugstore High-Temperature Cautery Fine Science Tools AA03 Homeothermic Blanket System with Flexible Probe Harvard Apparatus 507220F Infrared camera FLIR E6 Instrapac - Adson Toothed Forceps (Extra Fine) Iris Science Tools 7973 Iris Scissors 11.5 cm Curves EASY-CUT Fine Science Tools EA7613-11 Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113	Derf Needle Holders 12 cm TC	Fine Science Tools	703DE12
Electroneuromiography setup Electroneuromiography setup Ethilon 5-0 FLIR FLIR Graeffe forceps 0.8 mm tips curved Graph paper Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) Universal Drugstore High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Instrapac - Adson Toothed Forceps (Extra Fine) Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution BIOPAC Systems MP36 W1618 FLIR Fine Science Tools Ambar Harvard Apparatus Fine Science Tools EA7613-11 Ketamine hydrochloride/xylazine hydrochloride solution K113	Dry heat sterilizer	Quirumed	2432
Ethilon 5-0 FLIR Software Graeffe forceps 0.8 mm tips curved Fine Science Tools Graph paper Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Infrared camera Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution FLIR W1618 Harvard Apparatus FLIR Fine Science Tools	Dynamometer	SAUTER	FH5
FLIR Software Graeffe forceps 0.8 mm tips curved Fine Science Tools Graph paper Ambar Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Infrared camera Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution Fine Science Tools	Electroneuromiography setup	BIOPAC Systems	MP36
Graeffe forceps 0.8 mm tips curved Graph paper Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) Universal Drugstore High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Infrared camera Harvard Apparatus Fine Science Tools Harvard Apparatus Fine Science Tools	Ethilon 5-0		W1618
Graph paper Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) Universal Drugstore High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Infrared camera Harvard Apparatus Fine Science Tools	FLIR Software	FLIR	
Heat Lamp HL-1 Heparin Sodium Solution (Heparin LEO 10000IU/ml) Universal Drugstore High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Infrared camera Harvard Apparatus Fine Science Tools FLIR Fine Science Tools	Graeffe forceps 0.8 mm tips curved	Fine Science Tools	11052-10
Heparin Sodium Solution (Heparin LEO 10000IU/ml) High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Infrared camera FilR Fine Science Tools Harvard Apparatus FLIR E6 Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113	Graph paper	Ambar	
10000IU/ml)Universal DrugstoreHigh-Temperature CauteryFine Science ToolsAA03Homeothermic Blanket System with FlexibleHarvard Apparatus507220FProbeHarvard ApparatusE6Instrapac - Adson Toothed Forceps (Extra Fine)Fine Science Tools7973Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochlorideFine Science ToolsEA7613-11Ketamine hydrochloride/xylazine hydrochlorideSigma- AldrichK113	Heat Lamp HL-1	Harvard Apparatus	727562
High-Temperature Cautery Homeothermic Blanket System with Flexible Probe Infrared camera Harvard Apparatus FilR Fine Science Tools Harvard Apparatus FLIR E6 Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution Fine Science Tools Fine Science Tools Fine Science Tools EA7613-11 K113	Heparin Sodium Solution (Heparin LEO		
Homeothermic Blanket System with Flexible Probe Harvard Apparatus 507220F Infrared camera FLIR E6 Instrapac - Adson Toothed Forceps (Extra Fine) Fine Science Tools Iris Scissors 11.5 cm Curves EASY-CUT Fine Science Tools Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113	10000IU/ml)	Universal Drugstore	
Probe Harvard Apparatus Infrared camera FLIR E6 Instrapac - Adson Toothed Forceps (Extra Fine) Fine Science Tools Iris Scissors 11.5 cm Curves EASY-CUT Fine Science Tools Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113	High-Temperature Cautery	Fine Science Tools	AA03
Instrapac - Adson Toothed Forceps (Extra Fine) Iris Scissors 11.5 cm Curves EASY-CUT Ketamine hydrochloride/xylazine hydrochloride solution FLIR Fine Science Tools	Homeothermic Blanket System with Flexible		
Instrapac - Adson Toothed Forceps (Extra Fine) Fine Science Tools 7973 Iris Scissors 11.5 cm Curves EASY-CUT Fine Science Tools EA7613-11 Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113	Probe	Harvard Apparatus	507220F
Iris Scissors 11.5 cm Curves EASY-CUT Fine Science Tools EA7613-11 Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113	Infrared camera	FLIR	E6
Iris Scissors 11.5 cm Curves EASY-CUT Fine Science Tools EA7613-11 Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113			
Ketamine hydrochloride/xylazine hydrochloride solution Sigma- Aldrich K113	Instrapac - Adson Toothed Forceps (Extra Fine)	Fine Science Tools	7973
solution Sigma- Aldrich K113	Iris Scissors 11.5 cm Curves EASY-CUT	Fine Science Tools	EA7613-11
0 1 1	Ketamine hydrochloride/xylazine hydrochloride		
Lacri-lube Eye Ointment 5g Express Chemist LAC101F	solution	Sigma- Aldrich	K113
	Lacri-lube Eye Ointment 5g	Express Chemist	LAC101F

Mayo Scissors 14 cm Straight Chamfered Blades		
EASY-CUT	Fine Science Tools	EA7652-14
Meloxicam	Recropharma	Mobic
Methylene Blue solution	Sigma- Aldrich	
Micro Jewellers Forceps 11 cm straight 00108	Fine Science Tools	JF-5
Micro Jewellers Forceps 11cm angulated 00109	Fine Science Tools	JFA-5b
Micro retractor	Fine Science Tools	RS-6540
Micro Scissors Round Handles 15 cm Straight	Fine Science Tools	67
Where Seissors Round Handles 15 cm Straight	Time Science 100is	0,7
Micro-vessel dilators 11 cm 0.3 mm tips 00124	Fine Science Tools	D-5a.2
Monosyn 5-0		15423BR
Normal saline for irrigation	Hospira, Inc.	0409-6138-22
-	Leica Surgical	
Operating microscope	Microsystems	
Skin Skribe Surgical Skin Marker	Moore Medical	31456
Snacks	Versele-Laga	Complete Crock-Berry
Straight mosquito forcep	Fine Science Tools	91308-12
Surgical drapes	Barrier	800430
Veet Sensitive Skin Hair Removal Cream Aloe		

Veet

Vera and Vitamin E 100 ml

Comments/Description

https://www.amazon.com/Childrens-Tylenol-grape-flavor-ages/dp/B0051VVVZG

http://www.merciansurgical.com/aclandclamps.pdf

http://www.merciansurgical.com

https://www.medexsupply.com

https://www.biopac.com/

http://s-and-t.ne

http://www.merciansurgical.com/acland-clamps.pdf

https://www.biopac.com/product/constant-voltage-stimulator-unipolar-pulse/

http://www.productcatalogue.bode-chemie.com/products/skin/cutasept f.php

http://www.bbraun.com/cps/rde/xchg/bbraun-com/hs.xsl/products.html?prid=PRID00000816

http://www.merciansurgical.com

http://www.quirumed.com/pt/material-de-esterilizac-o/esterilizadores

https://www.sauter.eu/shop/en/measuring-instruments/force-measurement/FH-S/

https://www.biopac.com/product/biopac-student-lab-basic-systems/

http://www.farlamedical.co.uk/

http://www.finescience.de

https://www.harvardapparatus.com/webapp/wcs/stores/servlet/haisku3 10001 11051 39108 -1 HAI ProductDetail N 37610 37611 37613

http://www.universaldrugstore.com/medications/Heparin+LEO/10000IU%2Fml

http://www.boviemedical.com/products_aaroncauteries_high.asp

https://www.harvardapparatus.com/webapp/wcs/stores/servlet/haisku3 10001 11051 39108 -1 HAI ProductDetail N 37610 37611 37613

http://www.flir.eu/instruments/e6-wifi/

http://www.millermedicalsupplies.com

http://www.merciansurgical.com

https://www.sigmaaldrich.com/catalog/product/sigma/k113?lang=pt®ion=PT

http://www.expresschemist.co.uk/lacri-lube-eye-ointment-5g.html

http://www.merciansurgical.com

https://www.recropharma.com/product-pipeline/meloxicam

https://www.sigmaaldrich.com/catalog/product

http://www.merciansurgical.com

http://www.merciansurgical.com

http://www.finescience.de

http://www.merciansurgical.com

http://www.merciansurgical.com

http://www.mcfarlanemedical.com.au/15423BR/SUTURE-MONOSYN-5 or 0-16MM-70CM-(C0023423)-

BOX or 36/pd.php

http://www.hospira.com/en/search?q=sodium+chloride+irrigation%2C+usp&fq=contentType%3AProducts

http://www.leica-microsystems.com/products/surgical-microscopes/

www.mooremedical.com/index.cfm?/Skin-Skribe-Surgical-Skin-Marker/&PG=CTL&CS=HOM&FN=ProductDetail&PID=1740&spx=1

http://www.versele-laga.com/en/complete/products/complete-crock-berry

http://www.finescience.de

http://www.molnlycke.com/surgical-drapes/

http://www.veet.co.uk/products/creams/creams/veet-hair-removal-cream-sensitive-skin/

Dear Professor Vineeta Bajaj

Editor of the Journal of Visualized Experiments,

We are now resubmitting a revised version of the paper entitled "Functional and physiological methods of evaluating median nerve regeneration in the rat" (JoVE59767_R2). We have performed all the suggested changes to the manuscript and to the video.

We would like to start with by once more thanking you and the referees for the time you have taken to thoroughly review our paper, and for your remarks and suggestions.

We have performed all the changes you suggested, as detailed below:

Editorial comments:

1. The editor has formatted the manuscript to match the journal's style. Please retain the same.

We kept the formatting introduced by the editorial team.

2. Please address all the specific comments marked in the manuscript.

We performed all the changes suggested by the reviewers throughout the article.

3. Please reword 376-378, 380-381, 388-389, 438-439, 520-521, 642-645, 649-651, 682-685, 694-695 as it matches with previously published literature.

We rephrased the mentioned sections of the text. These changes have been highlighted in the manuscript using the "track changes mode".

4. Figure legends for Figure 4,5,6,7 matches with previously published literature. If the figures are reprinted, please include reprint permission. If not then please reword.

These figures are original and have not been published elsewhere. We reworded the mentioned figure legends.

Please ensure that the protocol length is n	o more than 10	O pages including	headings and
spacings.			

Presently, the protocol is composed of 9 pages (pages 3 to 11 of the manuscript).

Video:

- 1. 0:10 Please remove the titles (MD, PhD) from the name. Also, do not include plastic and reconstructive surgeon, instead please include the hospital/institute affiliation.

 2. 2:49 When showing the name of the talent, please remove MSci, and Biomedical Engineering. Please include the name of the hospital, university, etc (e.g., NOVA Medical School).
- 3. 0:46 Please change the subheading to match the section title in the protocol text. 4. 2:04 – Please remove the subheading "experimental groups" as this is not present in the text. make this Please section 5. Please have the same subheadings both in the text and the video. Please remove 3.1Median Nerve exposure from 0.46 and change it to Median nerve surgery as in the text. 6. Please remove the numbering from the subtitle cards throughout the video and from the representative result and conclusion title card 7. 6:01: The VO is cut at this part.

We have performed all the requested changes to the video.

Once more, we believe that the modifications we have performed in the video and manuscript according to the reviewers' specifications have significantly improved the original paper.

As we noted earlier, arguably, using the median nerve (MN) of the rat, it is possible to adequately replicate peripheral nerve lesions in humans.¹⁻³ In this paper we present a model of peripheral nerve lesion and repair in the rat. In particular, we demonstrate in a detailed fashion the steps required to create and repair different types of MN lesions in the rat. Moreover, we introduce different settings used to simulate postoperative physiotherapy. Finally, we illustrate how to evaluate functional recovery of this nerve using several tests.

We strongly believe that this model is particularly indicated to replicate the clinical scenario, facilitating extrapolation of results to the human species.

We base this description in our groups' 12-year experience with the use of this model for both teaching and research purposes.^{1,4} To make this subject more perceptible to a wider audience, we have included an original professional-drawn diagram illustrating the relevant anatomy of the MN in the rat (Figure 1).

Hence, we believe this paper will undoubtedly be of great interest to the readers of *JoVE*, as the MN model has multiple advantages relatively to the most commonly used sciatic nerve model.^{1,5-7}

We very much hope you decide to publish it!

If you have any doubts or queries, please do not hesitate to contact us.

Thank you so much for your time and kind attention.

The authors

Bibliographic references

- Casal, D. *et al.* Reconstruction of a 10-mm-long median nerve gap in an ischemic environment using autologous conduits with different patterns of blood supply: A comparative study in the rat. *PLoS One.* **13** (4), e0195692, doi:10.1371/journal.pone.0195692, (2018).
- Stößel, M., Rehra, L. & Haastert-Talini, K. Reflex-based grasping, skilled forelimb reaching, and electrodiagnostic evaluation for comprehensive analysis of functional recovery—The 7-mm rat median nerve gap repair model revisited. *Brain and Behavior.* **7** (10), e00813, doi:10.1002/brb3.813, (2017).
- 3 Manoli, T. *et al.* Correlation analysis of histomorphometry and motor neurography in the median nerve rat model. *Eplasty.* **14** e17 (2014).
- 4 Angelica-Almeida, M. *et al.* Brachial plexus morphology and vascular supply in the wistar rat. *Acta Med Port.* **26** (3), 243-250 (2013).
- Ronchi, G. *et al.* Functional and morphological assessment of a standardized crush injury of the rat median nerve. *J Neurosci Methods.* **179** (1), 51-57, doi:10.1016/j.jneumeth.2009.01.011, (2009).
- Ronchi, G. *et al.* Standardized crush injury of the mouse median nerve. *J Neurosci Methods.* **188** (1), 71-75, doi:10.1016/j.jneumeth.2010.01.024, (2010).
- Tos, P. *et al.* Employment of the mouse median nerve model for the experimental assessment of peripheral nerve regeneration. *J Neurosci Methods.* **169** (1), 119-127, doi:10.1016/j.jneumeth.2007.11.030, (2008).

jove	1 Algorite Center #200 Cembridge, MA 02140 tol. 817.845.9051 www.jove.com		ND VIDEO LICENS		
Title of Article:	Functional	and physiological pr	methods of eval	neting median	re,ue
Author(s):	Jan Alwi Fener of	end physiological on the rest Eduque to testing Clarkingen has to have the Materials	Myseshastenss Vessilen Kon Paul s be made available	Just Ference 19 (as described a	Silve Goy 10'Nell
http://www.jove	.com/publish) vi	a:	Open Access		
Item 2: Please se	lect one of the fo	ollowing items:			
The Auth	or is NOT a Unit	ed States government emp	ployee.		
The Auth	nor is a United S f his or her dutie	states government employ s as a United States govern	yee and the Materials on nment employee.	were prepared in th	е
The Auth	or is a United Sta f his or her duties	ates government employed s as a United States govern	e but the Materials were nment employee.	e NOT prepared in th	e

ARTICLE AND VIDEO LICENSE AGREEMENT

Defined Terms. As used in this Article and Video License Agreement, the following terms shall have the following meanings: "Agreement" means this Article and Video License Agreement; "Article" means the article specified on the last page of this Agreement, including any associated materials such as texts, figures, tables, artwork, abstracts, or summaries contained therein; "Author" means the author who is a signatory to this Agreement; "Collective Work" means a work, such as a periodical issue, anthology or encyclopedia, in which the Materials in their entirety in unmodified form, along with a number of other contributions, constituting separate and independent works in themselves, are assembled into a collective whole; "CRC License" means the Creative Commons Attribution-Non Commercial-No Derivs 3.0 Unported Agreement, the terms and conditions of which can be found at: http://creativecommons.org/licenses/by-nc-

nd/3.0/legalcode; "Derivative Work" means a work based upon the Materials or upon the Materials and other preexisting works, such as a translation, musical arrangement, dramatization, fictionalization, motion picture version, sound recording, art reproduction, abridgment, condensation, or any other form in which the Materials may be recast, transformed, or adapted; "Institution" means the institution, listed on the last page of this Agreement, by which the Author was employed at the time of the creation of the Materials; "JoVE" means MyJove Corporation, a Massachusetts corporation and the publisher of The Journal of Visualized Experiments; "Materials" means the Article and / or the Video; "Parties" means the Author and JoVE; "Video" means any video(s) made by the Author, alone or in conjunction with any other parties, or by JoVE or its affiliates or agents, individually or in collaboration with the Author or any other parties, incorporating all or any portion

of the Article, and in which the Author may or may not appear.

- 2. **Background.** The Author, who is the author of the Article, in order to ensure the dissemination and protection of the Article, desires to have the JoVE publish the Article and create and transmit videos based on the Article. In furtherance of such goals, the Parties desire to memorialize in this Agreement the respective rights of each Party in and to the Article and the Video.
- Grant of Rights in Article. In consideration of JoVE agreeing to publish the Article, the Author hereby grants to JoVE, subject to Sections 4 and 7 below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Article in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Article into other languages, create adaptations, summaries or extracts of the Article or other Derivative Works (including, without limitation, the Video) or Collective Works based on all or any portion of the Article and exercise all of the rights set forth in (a) above in such translations, adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. If the "Open Access" box has been checked in Item 1 above, JoVE and the Author hereby grant to the public all such rights in the Article as provided in, but subject to all limitations and requirements set forth in, the CRC License.



ARTICLE AND VIDEO LICENSE AGREEMENT

- 4. Retention of Rights in Article. Notwithstanding the exclusive license granted to JoVE in Section 3 above, the Author shall, with respect to the Article, retain the non-exclusive right to use all or part of the Article for the non-commercial purpose of giving lectures, presentations or teaching classes, and to post a copy of the Article on the Institution's website or the Author's personal website, in each case provided that a link to the Article on the JoVE website is provided and notice of JoVE's copyright in the Article is included. All non-copyright intellectual property rights in and to the Article, such as patent rights, shall remain with the Author.
- 5. Grant of Rights in Video Standard Access. This Section 5 applies if the "Standard Access" box has been checked in Item 1 above or if no box has been checked in Item 1 above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby acknowledges and agrees that, Subject to Section 7 below, JoVE is and shall be the sole and exclusive owner of all rights of any nature, including, without limitation, all copyrights, in and to the Video. To the extent that, by law, the Author is deemed, now or at any time in the future, to have any rights of any nature in or to the Video, the Author hereby disclaims all such rights and transfers all such rights to JoVE.
- Grant of Rights in Video Open Access. This 6 Section 6 applies only if the "Open Access" box has been checked in Item 1 above. In consideration of JoVE agreeing to produce, display or otherwise assist with the Video, the Author hereby grants to JoVE, subject to Section 7 below, the exclusive, royalty-free, perpetual (for the full term of copyright in the Article, including any extensions thereto) license (a) to publish, reproduce, distribute, display and store the Video in all forms, formats and media whether now known or hereafter developed (including without limitation in print, digital and electronic form) throughout the world, (b) to translate the Video into other languages, create adaptations, summaries or extracts of the Video or other Derivative Works or Collective Works based on all or any portion of the Video and exercise all of the rights set forth in (a) above in such translations, adaptations, summaries, extracts, Derivative Works or Collective Works and (c) to license others to do any or all of the above. The foregoing rights may be exercised in all media and formats, whether now known or hereafter devised, and include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. For any Video to which this Section 6 is applicable, JoVE and the Author hereby grant to the public all such rights in the Video as provided in, but subject to all limitations and requirements set forth in, the CRC License.
- 7. Government Employees. If the Author is a United States government employee and the Article was prepared in the course of his or her duties as a United States government employee, as indicated in Item 2 above, and any of the licenses or grants granted by the Author hereunder exceed the scope of the 17 U.S.C. 403, then the rights granted hereunder shall be limited to the maximum

- rights permitted under such statute. In such case, all provisions contained herein that are not in conflict with such statute shall remain in full force and effect, and all provisions contained herein that do so conflict shall be deemed to be amended so as to provide to JoVE the maximum rights permissible within such statute.
- 8. Protection of the Work. The Author(s) authorize JoVE to take steps in the Author(s) name and on their behalf if JoVE believes some third party could be infringing or might infringe the copyright of either the Author's Article and/or Video.
- 9. Likeness, Privacy, Personality. The Author hereby grants JoVE the right to use the Author's name, voice, likeness, picture, photograph, image, biography and performance in any way, commercial or otherwise, in connection with the Materials and the sale, promotion and distribution thereof. The Author hereby waives any and all rights he or she may have, relating to his or her appearance in the Video or otherwise relating to the Materials, under all applicable privacy, likeness, personality or similar laws.
- Author Warranties. The Author represents and 10. warrants that the Article is original, that it has not been published, that the copyright interest is owned by the Author (or, if more than one author is listed at the beginning of this Agreement, by such authors collectively) and has not been assigned, licensed, or otherwise transferred to any other party. The Author represents and warrants that the author(s) listed at the top of this Agreement are the only authors of the Materials. If more than one author is listed at the top of this Agreement and if any such author has not entered into a separate Article and Video License Agreement with JoVE relating to the Materials, the Author represents and warrants that the Author has been authorized by each of the other such authors to execute this Agreement on his or her behalf and to bind him or her with respect to the terms of this Agreement as if each of them had been a party hereto as an Author. The Author warrants that the use, reproduction, distribution, public or private performance or display, and/or modification of all or any portion of the Materials does not and will not violate, infringe and/or misappropriate the patent, trademark, intellectual property or other rights of any third party. The Author represents and warrants that it has and will continue to comply with all government, institutional and other regulations, including, without limitation all institutional, laboratory, hospital, ethical, human and animal treatment, privacy, and all other rules, regulations, laws, procedures or guidelines, applicable to the Materials, and that all research involving human and animal subjects has been approved by the Author's relevant institutional
- 11. JoVE Discretion. If the Author requests the assistance of JoVE in producing the Video in the Author's facility, the Author shall ensure that the presence of JoVE employees, agents or independent contractors is in accordance with the relevant regulations of the Author's institution. If more than one author is listed at the beginning of this Agreement, JoVE may, in its sole



ARTICLE AND VIDEO LICENSE AGREEMENT

discretion, elect not take any action with respect to the Article until such time as it has received complete, executed Article and Video License Agreements from each such author. JoVE reserves the right, in its absolute and sole discretion and without giving any reason therefore, to accept or decline any work submitted to JoVE. JoVE and its employees, agents and independent contractors shall have full, unfettered access to the facilities of the Author or of the Author's institution as necessary to make the Video, whether actually published or not. JoVE has sole discretion as to the method of making and publishing the Materials, including, without limitation, to all decisions regarding editing, lighting, filming, timing of publication, if any, length, quality, content and the like.

12 Indemnification. The Author agrees to indemnify JoVE and/or its successors and assigns from and against any and all claims, costs, and expenses, including attorney's fees, arising out of any breach of any warranty or other representations contained herein. The Author further agrees to indemnify and hold harmless JoVE from and against any and all claims, costs, and expenses, including attorney's fees, resulting from the breach by the Author of any representation or warranty contained herein or from allegations or instances of violation of intellectual property rights, damage to the Author's or the Author's institution's facilities, fraud, libel, defamation, research, equipment, experiments, property damage, personal injury, violations of institutional, laboratory, hospital, ethical, human and animal treatment, privacy or other rules, regulations, laws, procedures or guidelines, liabilities and other losses or damages related in any way to the submission of work to JoVE, making of videos by JoVE, or publication in JoVE or elsewhere by JoVE. The Author shall be responsible for, and shall hold JoVE harmless from, damages caused by lack of sterilization, lack of cleanliness or by contamination due to

CORRESPONDING AUTHOR

612542.6

the making of a video by JoVE its employees, agents or independent contractors. All sterilization, cleanliness or decontamination procedures shall be solely the responsibility of the Author and shall be undertaken at the Author's expense. All indemnifications provided herein shall include JoVE's attorney's fees and costs related to said losses or damages. Such indemnification and holding harmless shall include such losses or damages incurred by, or in connection with, acts or omissions of JoVE, its employees, agents or independent contractors.

Fees. To cover the cost incurred for publication, JoVE must receive payment before production and publication of the Materials. Payment is due in 21 days of invoice. Should the Materials not be published due to an editorial or production decision, these funds will be returned to the Author. Withdrawal by the Author of any submitted Materials after final peer review approval will result in a US\$1,200 fee to cover pre-production expenses incurred by JoVE. If payment is not received by the completion of filming, production and publication of the Materials will be suspended until payment is received.

Transfer, Governing Law. This Agreement may be assigned by JoVE and shall inure to the benefits of any of JoVE's successors and assignees. This Agreement shall be governed and construed by the internal laws of the Commonwealth of Massachusetts without giving effect to any conflict of law provision thereunder. This Agreement may be executed in counterparts, each of which shall be deemed an original, but all of which together shall be deemed to me one and the same agreement. A signed copy of this Agreement delivered by facsimile, e-mail or other means of electronic transmission shall be deemed to have the same legal effect as delivery of an original signed copy of this Agreement.

A signed copy of this document must be sent with all new submissions. Only one Agreement is required per submission.

Name:	
Department:	Diogo Casal
Institution:	Nova Me Lice / School
Title:	MD; PhD
Signature:	Dioys and Date: 79th
Please submit a 1. Upload 2. Fax the	signed and dated copy of this license by one of the following three methods:

2. Fax the document to +1.866.381.2236 on on the JoVE submission site

3. Mail the document to JoVE / Attn: JoVE Editorial / 1 Alewife Center #200 / Cambridge, MA 02140