

## Readings

## Controls



5.0 Watts

STAGE 1 Turn ON ▶

5.0 Watts

STAGE 2 Turn ON ▶

5.0 Watts

STAGE 3 Turn ON ▶

5.0 Watts

STAGE 4 Turn ON ▶

5.0 Watts

AUX CH Turn ON ▶

FEED NaN mL/min TM Offline

STAGE 1 0.0W NaN mL/min TM Offline

STAGE 3 0.0W NaN mL/min TM Offline

STAGE 2 0.0W NaN mL/min TM Offline

STAGE 4 0.0W NaN mL/min TM Offline

11:30:41 AM

ver. 1.0.4