


6. Put the petri dish under the rig so the steel plate can be seen when looking through the tube



7. Line the ball bearing up with the top of the tube and drop making sure not to move the rig or the fish- change tubes and ball bearings as

